

KLIM 3396-000

KLIM Tundra HTD Rechargeable Heated Winter Gauntlet Gloves User Manual

Model: 3396-000

INTRODUCTION

This manual provides essential instructions for the safe and effective use, setup, operation, and maintenance of your KLIM Tundra HTD Rechargeable Heated Winter Gauntlet Gloves. Please read this manual thoroughly before using the product and retain it for future reference.

SAFETY INFORMATION

Warning: This product is made with PFAS chemicals. For detailed safety guidelines and proper handling, consult local regulations and product safety data sheets if available. Always prioritize personal safety when using heated apparel.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- KLIM Tundra HTD Rechargeable Heated Winter Gauntlet Gloves (1 pair)
- Rechargeable Batteries (2 units)
- Battery Charger with Power Adapter (1 unit)
- Storage/Carry Bag (1 unit)



Image: Complete package contents including the pair of KLIM Tundra HTD gloves, two rechargeable batteries, a battery charger, and a mesh carry bag.

SETUP

1. Charging the Batteries

1. Connect the battery charger to a standard electrical outlet.
2. Insert the rechargeable batteries into the charger. Ensure proper orientation.
3. Allow batteries to charge fully before first use. The charger's indicator light will typically change color to indicate a full charge.

2. Inserting Batteries into Gloves

1. Locate the battery pocket on the cuff of each glove. This is usually secured with a zipper or hook-and-loop closure.
2. Open the pocket and connect a fully charged battery to the glove's internal connector cable.
3. Carefully place the battery into the pocket and secure the closure.





Image: Side view of the KLIM Tundra HTD glove, showing the integrated heating control button and the adjustable wrist strap. The battery pocket is typically located within the gauntlet cuff.

OPERATING INSTRUCTIONS

1. Powering On and Adjusting Heat Settings

1. Once batteries are inserted, press and hold the power button (usually located on the back of the glove or cuff) for 2-3 seconds to turn on the heating system.
2. The indicator light on the button will illuminate, typically in a color corresponding to the current heat setting (e.g., Red for High, White for Medium, Blue for Low).
3. Press the power button briefly to cycle through the available heat settings.
4. To power off, press and hold the power button again for 2-3 seconds until the indicator light turns off.

2. Recommended Usage

- For optimal battery life, start with a higher heat setting to warm your hands quickly, then reduce to a lower setting for sustained warmth.
- Avoid prolonged exposure to extreme cold without adequate insulation, even with heated gloves.

MAINTENANCE

1. Cleaning

- **Before cleaning, always remove batteries from the gloves.**
- Spot clean with a damp cloth and mild soap. Do not submerge gloves in water.
- Do not machine wash, tumble dry, iron, or dry clean. These actions can damage the heating elements and internal wiring.
- Allow gloves to air dry completely before storing or reinserting batteries.

2. Storage

- Store gloves and batteries in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, remove batteries from the gloves.
- It is recommended to charge batteries periodically (e.g., every 3-6 months) during extended storage to maintain battery health.





Image: The mesh carry bag provided with the KLIM Tundra HTD gloves, designed for convenient storage and transport.

TROUBLESHOOTING

- **Gloves not heating:**
 - Ensure batteries are fully charged and correctly inserted.

- Check that the battery connector is securely plugged into the glove's internal cable.
- Press and hold the power button for the required duration to activate.

• **Short battery life:**

- Battery life varies significantly with heat setting. Higher settings consume power faster.
- Ensure batteries are fully charged before each use.
- Extreme cold can reduce battery efficiency.

• **Indicator light not working:**

- Verify batteries are charged and connected.
- If the issue persists, contact customer support.

SPECIFICATIONS

Brand	KLIM
Model Number	3396-000
Product Type	Rechargeable Heated Winter Gauntlet Gloves
Material	Acrylic (Fabric Type)
Department	Men
Origin	Imported

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official KLIM website or contact KLIM customer service directly. Details regarding specific warranty periods and coverage are typically provided with your purchase documentation.

KLIM Official Store: [Visit the KLIM Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question