Iwell B097P1H9QX

Iwell Storage Cabinet with 3 Drawers and Adjustable Shelf Instruction Manual

Model: B097P1H9QX
Brand: Iwell

1. Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Anti-Tip Device:** This cabinet includes an anti-tip device. It is crucial to install this device securely to a wall to prevent the cabinet from tipping over, which can cause serious injury.
- **Weight Limit:** Do not exceed the maximum weight limit of 150 pounds for the entire cabinet. Distribute weight evenly.
- **Assembly:** Assemble the cabinet on a soft, clean surface to prevent scratches. Ensure all parts are correctly aligned and fasteners are tightened before use.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the cabinet.



Figure 1.1: Illustration of the anti-tip device installation. Securely attach the bracket to the top rear of the cabinet and then to a wall stud using appropriate hardware.

2. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Cabinet Panels (top, bottom, sides, back)
- 3 Drawer Fronts and Components
- 1 Cabinet Door and Hinges
- 1 Adjustable Shelf
- 4 Legs
- Hardware Pack (screws, dowels, handles, magnetic catch, anti-tip kit)

3. Assembly Instructions

Assembly typically requires two adults and basic tools such as a screwdriver. Follow the numbered steps provided in the included assembly guide.

1. **Prepare the Area:** Clear a spacious, clean, and level area for assembly. Lay out all parts and hardware.

2. **Assemble the Main Frame:** Connect the side panels to the bottom and top panels using the provided cam locks and dowels. Ensure all connections are secure.
3. **Install Back Panel:** Attach the back panel to the assembled frame using small nails or screws.
4. **Assemble Drawers:** Construct the three drawers.**Important:** Insert the wooden dowels into the designated holes for the drawers to ensure they remain securely in place and do not fall out during use. Attach the drawer handles.
5. **Install Cabinet Door:** Attach the hinges to the cabinet door and then to the main frame. Ensure the door opens and closes smoothly. Install the magnetic catch for secure closure.
6. **Insert Adjustable Shelf:** Place the adjustable shelf into the cabinet section. The shelf can be positioned at three different heights to accommodate various items.
7. **Attach Legs:** Securely attach the four legs to the bottom of the cabinet.
8. **Install Anti-Tip Device:** Following the instructions in Section 1, install the anti-tip device to a wall stud. This step is critical for safety.



Figure 3.1: Detailed dimensions of the assembled cabinet, including drawer and internal shelf measurements.



Figure 3.2: The adjustable shelf can be moved to one of three height settings to customize storage space.

4. Usage

The Iwell Storage Cabinet is designed for versatile use in various rooms, providing organized storage for your belongings.

- **Drawer Functionality:** The three drawers are suitable for storing smaller items. Ensure the wooden dowels are properly installed to prevent drawers from sliding out unintentionally.
- **Adjustable Shelf:** Utilize the adjustable shelf within the cabinet section to customize storage for items of different heights.
- **Placement:** This cabinet is suitable for use as a sideboard, buffet cabinet, accent cabinet, or storage unit in living rooms, entryways, hallways, bedrooms, bathrooms, home offices, and kitchens.
- **Multi-Unit Configuration:** Multiple Iwell Storage Cabinets can be placed side-by-side to create a larger storage solution or a TV stand for televisions up to 75 inches.



Figure 4.1: The three spacious drawers provide convenient storage for various items.



Figure 4.2: Two cabinets can be combined to form a larger TV stand, suitable for up to a 75-inch TV.

5. Maintenance

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Re-tighten if necessary.

6. Troubleshooting

Problem	Possible Cause	Solution
Drawers slide out easily or feel unstable.	Wooden dowels not installed or not fully inserted.	Ensure the wooden dowels are fully inserted into the designated holes on the drawer sides to act as stops. If necessary, apply a small amount of wood glue to secure the dowels.
Cabinet feels wobbly or unstable.	Loose fasteners or uneven floor.	Check and tighten all screws and cam locks. Ensure the cabinet is on a level surface. Adjust leg levelers if present, or place shims under legs if needed. Confirm the anti-tip device is securely installed.
Cabinet door does not close properly.	Hinges are misaligned or magnetic catch is not engaging.	Adjust the hinges to align the door. Ensure the magnetic catch is properly installed and aligned with the metal plate on the door.

7. Specifications

Model: B097P1H9QX

Brand: Iwell

Color: Rustic Oak

Product Dimensions: 31.5" W x 11.81" D x 30.71" H (80cm W x 30cm D x 78cm H)

Item Weight: 43.2 pounds (19.64 Kilograms)

Material: Engineered Wood, Wood

Weight Limit: 150 Pounds

Special Feature: Adjustable Shelf (3 height settings)

Number of Drawers: 3

Number of Doors: 1

Mounting Type: Floor Mount (with optional wall anti-tip attachment)



Figure 7.1: The Iwell Storage Cabinet features a rustic oak finish with three drawers and one cabinet door.

8. Warranty and Support

For warranty information or technical support, please refer to the contact details provided at the point of purchase or visit the official Iwell website. Keep your purchase receipt for warranty claims.

© 2026 Iwell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question