

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Flujoy](#) /

› Flujoy CS-ECH007BL 700mAh/7.2V Ni-MH Replacement Battery User Manual

Flujoy CS-ECH007BL

Flujoy CS-ECH007BL 700mAh/7.2V Ni-MH Replacement Battery User Manual

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Flujoy CS-ECH007BL 700mAh/7.2V Ni-MH replacement battery. Please read this manual thoroughly before using the battery to ensure proper operation and longevity. This battery is designed for specific ELCA devices.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent injury or damage to the battery and your device:

- **DO NOT** attempt to disassemble, open, or service the battery pack.
- **REPLACE ONLY** with the battery pack designated for this product.
- **DO NOT** crush, puncture, short external contacts, or dispose of in fire or water.
- **DO NOT** store above 60°C (140°F).
- Keep the battery away from children.
- If the battery shows signs of damage, swelling, or leakage, discontinue use immediately.



Image: Close-up of the battery label, detailing model number, specifications, and critical safety warnings regarding disassembly, storage temperature, and disposal.

3. PRODUCT OVERVIEW

The Flujoy CS-ECH007BL is a Ni-MH replacement battery designed to provide reliable power for compatible ELCA devices. Its robust construction and specified capacity ensure consistent performance.

3.1 Key Features

- **Battery Type:** Ni-MH
- **Voltage:** 7.2V
- **Capacity:** 700mAh (5.04Wh)
- **Dimensions:** 75.8 x 42.5 x 42.0mm (approximately 2.98 x 1.67 x 1.65 inches)
- **Certifications:** ISO9001, RoHS, CE, UN38.3, MSDS

3.2 Compatible Devices and Part Numbers

This battery is compatible with the following ELCA device models and part numbers:

- **Compatible Device Models:** GENIO-P, CONTROL-07, TECHNO-M, CONTROL-07MH-A, GENIO-M, CONTROL-07MH-D
- **Compatible Part Numbers:** REC-PINC-07J, PINC 07MH, PINC-07MH



Image: Angled view of the Flujoy CS-ECH007BL battery, highlighting its overall design and the information printed on its label.

4. SETUP

4.1 Initial Charge

Before first use, it is recommended to fully charge the battery. Refer to your specific ELCA device's instruction manual for detailed charging procedures and recommended charging times.

4.2 Battery Installation

1. Ensure your ELCA device is powered off before attempting battery installation or removal.
2. Locate the battery compartment on your device.
3. Carefully insert the Flujoy CS-ECH007BL battery, ensuring the contacts align correctly with those in the device's compartment.
4. Close the battery compartment cover securely.

5. OPERATING THE BATTERY

Once the battery is installed and charged, your ELCA device is ready for use. Operate your device according to its specific instruction manual. The battery will provide power until its charge level is low.

5.1 Recharging

When your device indicates a low battery, recharge the Flujoy CS-ECH007BL battery using the original charger or a compatible charger specified by your ELCA device manufacturer. Avoid overcharging or completely draining the battery frequently, as this can affect its lifespan.

6. MAINTENANCE

6.1 Storage

- Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures.
- For long-term storage, charge the battery to approximately 50% capacity.
- Avoid storing the battery in a completely discharged state for extended periods.

6.2 Cleaning

If necessary, clean the battery contacts with a dry, clean cloth. Do not use liquids or abrasive cleaners, as these can damage the battery or device.

6.3 Disposal

Dispose of used batteries responsibly according to local regulations. Do not dispose of in household waste or fire. Many retailers and recycling centers offer battery recycling programs.

7. TROUBLESHOOTING

If you encounter issues with your Flujoy CS-ECH007BL battery, consider the following common solutions:

- **Battery not charging:** Ensure the charger is properly connected and functional. Verify the battery is correctly inserted into the device or charger.
- **Short operating time:** The battery may not be fully charged, or its capacity may have diminished over time. Ensure full charge cycles. If issues persist, consider battery replacement.
- **Device not powering on:** Check battery installation. Ensure the battery is charged. Consult your ELCA device's manual for further troubleshooting steps.



Image: Side view of the battery, providing a clear look at the warning label and physical dimensions.

8. SPECIFICATIONS

Model Number	CS-ECH007BL
Part Numbers	REC-PINC-07J, PINC 07MH, PINC-07MH
Battery Type	Ni-MH
Voltage	7.2V
Capacity	700mAh
Energy	5.04Wh
Dimensions (L x W x H)	75.8 x 42.5 x 42.0mm (2.98 x 1.67 x 1.65 inches)
Item Weight	5.9 ounces
Certifications	ISO9001, RoHS, CE, UN38.3, MSDS

9. WARRANTY AND SUPPORT

This Flujoy battery comes with a 60-day policy for a full refund or a free replacement if you encounter any issues. For further support or warranty claims, please contact your retailer or the point of purchase.