

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR V-511 Professional Hair Straightener User Manual](#)

VGR V-511

VGR V-511 Professional Hair Straightener User Manual

Model: V-511

INTRODUCTION

Thank you for choosing the VGR V-511 Professional Hair Straightener. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new hair styling tool. Please read these instructions carefully before use and retain them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- The appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.
- Do not place the heated appliance directly on any surface while it is hot or plugged in.

PRODUCT OVERVIEW

The VGR V-511 Professional Hair Straightener features ceramic-coated plates and uniform heat technology for efficient hair styling. It is designed for various hair types with adjustable temperature settings.



Figure 1: VGR V-511 Hair Straightener showing its closed and open positions, highlighting the ceramic plates and the digital temperature display.

Key Features:

- **Ceramic Coated Plates:** Ensures smooth gliding and even heat distribution.
- **Adjustable Temperature:** Settings from 140°C to 220°C for various hair types.
- **LED Display:** Shows current temperature.
- **360° Swivel Cord:** Provides flexibility and prevents tangling during use.
- **Fast Heat-up:** Reaches desired temperature in approximately 30 seconds.

SETUP

1. **Unpack:** Carefully remove the hair straightener from its packaging.
2. **Inspect:** Check the appliance for any visible damage. Do not use if damaged.
3. **Placement:** Place the straightener on a heat-resistant, flat surface.
4. **Plug In:** Insert the power cord into a suitable electrical outlet. Ensure the voltage matches the appliance's requirements.

OPERATING INSTRUCTIONS

1. **Power On:** Press and hold the power button (if available, otherwise it powers on when plugged in and temperature is set) or turn the temperature dial to your desired setting. The LED display will illuminate.
2. **Set Temperature:** Adjust the temperature using the controls. The temperature range is 140°C to 220°C. Select a lower temperature for fine or damaged hair and a higher temperature for thick or coarse hair.
3. **Heat Up:** Allow approximately 30 seconds for the straightener to reach the selected temperature. The LED display will show the current temperature.
4. **Prepare Hair:** Ensure hair is clean, dry, and detangled. Divide hair into small, manageable sections.
5. **Straighten Hair:** Take one section of hair and place it between the heating plates, close to the roots. Gently clamp the plates together and glide the straightener slowly down the hair section from root to tip. Repeat until the desired straightness is achieved for that section.

6. **Power Off:** After use, press and hold the power button to turn off the appliance. Unplug the straightener from the electrical outlet.
7. **Cool Down:** Allow the straightener to cool completely before storing.



Figure 2: The VGR V-511 Hair Straightener in an open position, showcasing the wide ceramic plates and the VGR branding. This view is typical during operation.

MAINTENANCE

- **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Wipe the exterior surfaces and heating plates with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Storage:** Store the straightener in a cool, dry place, away from moisture. Do not wrap the power cord tightly around the appliance, as this can damage the cord.
- **Cord Care:** Regularly inspect the power cord for any signs of damage. If the cord is damaged, discontinue use and contact customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; Power outlet issue; Appliance fault.	Ensure the plug is fully inserted. Test the outlet with another device. If still not working, contact customer support.
Appliance not heating up.	Temperature setting too low; Internal heating element fault.	Increase the temperature setting. Allow sufficient time to heat. If problem persists, contact customer support.
Hair is not straightening effectively.	Temperature too low for hair type; Hair sections too large; Hair not fully dry.	Increase temperature if suitable for hair type. Use smaller hair sections. Ensure hair is completely dry before styling.

SPECIFICATIONS



Figure 3: A close-up view of the VGR V-511 Hair Straightener's ceramic-coated heating plates, emphasizing the smooth surface and construction.

Model Number	V-511
Brand	VGR
Plate Material	Ceramic (Tourmaline coated)
Temperature Range	140°C - 220°C
Heat-up Time	Approx. 30 seconds
Cord Type	360° Swivel Cord
Power Source	Corded Electric
Item Weight	940 g
Dimensions (LxWxH)	14 x 8 x 8 cm

WARRANTY AND SUPPORT

The VGR V-511 Professional Hair Straightener comes with a **12-month quality warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical assistance, or any product-related inquiries, please contact VGR customer service.

Refer to your purchase documentation for specific contact details or visit the official VGR website.

Please retain your proof of purchase for warranty validation.