Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fjords Fjords-Magnus-LRG-Power-Java

Fjords Magnus Large Dual Motion Recliner Instruction Manual

Model: Fjords-Magnus-LRG-Power-Java | Brand: Fjords

Introduction

The Fjords Magnus Relaxer Power Recliner offers a contemporary design combined with exceptional seating comfort. This chair features a dual motorized system that provides continuous support for your legs and back, allowing independent control of the footrest and back positions. The base swivels 170 degrees, enhancing versatility. The Magnus recliner includes a manual release angle and height-adjustable headrest, and is available in two sizes, medium and large. This manual provides essential information for the safe and effective use of your Fjords Magnus recliner.



The Fjords Magnus recliner, shown in Java Premium Leather, features a sleek design with a matte black base.

Setup

Unpacking and Placement

1. Carefully remove all packaging materials from the recliner. Ensure no components are left behind.
2. Place the recliner in your desired location, ensuring sufficient space for full recline and swivel functionality. The chair requires approximately 37 inches of depth when fully reclined and 33 inches of width.
3. Ensure the chair is placed on a stable, level surface. The swivel base is designed for hard floors but can be used on carpets with appropriate protection.

Power Connection and Battery

- Locate the power adapter and connect it to the recliner's power input.
- Plug the power adapter into a standard electrical outlet.
- The recliner includes a battery for wireless operation. For initial use, ensure the battery is fully charged by keeping

the chair plugged in for several hours. The battery provides power for wireless use, allowing flexibility in placement.

Operating Instructions

Dual Motor Recline Function

The Fjords Magnus recliner features a dual motor system, allowing independent adjustment of the backrest and footrest.

- **Footrest Control:** Use the designated button on the side control panel to extend or retract the concealed footrest. Press and hold to achieve the desired position.
- **Backrest Control:** Use the separate button on the control panel to recline or bring the backrest upright. Press and hold to adjust the angle.
- You can adjust both the footrest and backrest simultaneously or independently to find your optimal comfort position.



A user demonstrates the reclined position of the Fjords Magnus chair, highlighting the extended footrest and adjustable headrest for optimal comfort.

Adjustable Headrest

The headrest can be manually adjusted for angle and height to provide personalized neck and head support. Gently pull or push the headrest to adjust its position.

Swivel Function

The chair's base allows for a 170-degree swivel motion. Simply rotate the chair to face your desired direction.



This side view shows the Fjords Magnus recliner in its fully reclined position, with the footrest extended and the backrest tilted.

Maintenance

Leather Care

The Fjords Magnus recliner is upholstered in premium Soft Line Leather. Proper care will ensure its longevity and appearance.

- **Regular Cleaning:** Dust the leather regularly with a soft, dry cloth. For light cleaning, wipe with a damp cloth and then dry immediately with a clean, soft cloth.
- **Spills:** Blot spills immediately with a clean, absorbent cloth. Do not rub. For stubborn stains, use a mild leather cleaner specifically designed for aniline or semi-aniline leather, following the product instructions carefully.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause leather to fade and dry out. Position your chair away from direct sunlight or use window coverings.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or household detergents, as these can damage the leather finish.



The Fjords Soft Line Leather chart displays various available colors and provides information on the leather type and care.

Base and Mechanism Care

- Periodically check all bolts and screws to ensure they are tight.
- Wipe the matte black base with a soft, damp cloth to remove dust and debris.
- Avoid exposing the electrical components to moisture.

Troubleshooting

Recliner Not Responding

- **Check Power Connection:** Ensure the power adapter is securely plugged into both the chair and a working electrical outlet.
- **Battery Charge:** If operating wirelessly, check if the battery is charged. Connect the chair to power and allow the

battery to charge for several hours.

- **Circuit Breaker:** Verify that the electrical outlet is functional by testing it with another appliance. Check your home's circuit breaker if necessary.

Unusual Noises During Operation

- **Inspect for Obstructions:** Check for any objects that might be caught in the reclining mechanism or under the footrest.
- **Tighten Fasteners:** Ensure all visible bolts and screws are tight. Loose components can sometimes cause creaking or squeaking.
- If unusual noises persist, contact customer support.

Headrest Adjustment Issues

- Ensure the headrest mechanism is free of obstructions.
- Apply gentle, even pressure when adjusting. Do not force the mechanism.

Specifications



This image illustrates the key dimensions of the Fjords Magnus recliner: 37 inches deep, 33 inches wide, and 44 inches high.

Feature	Detail
Model Name	Fjords-Magnus-LRG-Power-Java
Product Dimensions (D x W x H)	37" x 33" x 44"
Item Weight	145 Pounds
Seat Height	18.5 Inches
Material	Premium Leather (Java Premium Leather)

Feature	Detail
Maximum Weight Recommendation	250 Pounds
Power Type	Electric (Dual Motor)
Battery Included	Yes, for wireless operation
Swivel Function	170 Degrees
Headrest	Manual release angle and height adjustable
Room Type	Living Room
Recommended Uses	Relaxing

Warranty Information

Fjords provides a factory one-year parts warranty for this product. This warranty covers manufacturing defects and material flaws under normal use. Please retain your proof of purchase for warranty claims.
Extended 5-year in-home parts and labor warranties are also available for purchase (ASIN: B073ZPXCLH). All warranties are applicable to the original purchaser only and do not cover rental or commercial use.
For detailed warranty terms and conditions, please refer to the official Fjords warranty documentation or contact customer support.

Customer Support

Should you require assistance with your Fjords Magnus recliner, including troubleshooting, parts replacement, or warranty inquiries, please contact Fjords customer support.
You can find more information and contact details by visiting the official Fjords store online: Fjords Official Store
When contacting support, please have your model number (Fjords-Magnus-LRG-Power-Java) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B097PWCRKM

More documents and user manuals: **https://manuals.plus/**