Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > SUBSONIC /
- > SUBSONIC Superdrive GS750 Racing Steering Wheel User Manual

SUBSONIC SA5156-NG

SUBSONIC Superdrive GS750 Racing Steering Wheel User Manual

Model: SA5156-NG | Brand: SUBSONIC

INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, and maintaining your SUBSONIC Superdrive GS750 Racing Steering Wheel. Designed for an immersive racing experience, this steering wheel is compatible with Xbox Series X/S, PS4, Xbox One, PS3, and PC, featuring dual vibration motors, a 270° rotation angle, and programmable keys.

PRODUCT OVERVIEW

The SUBSONIC Superdrive GS750 includes the steering wheel unit, pedal set, and shifter. Familiarize yourself with the components before setup.



Figure 1: Complete SUBSONIC Superdrive GS750 Racing Steering Wheel setup, showing the steering wheel, pedal unit, and shifter.



Figure 2: Compatibility overview for the GS750, indicating support for PC, Switch, Switch 2, Xbox Series X/S, Xbox One, PS3, PS4, and PS5.

KEY FEATURES

- Wide Compatibility: Compatible with Xbox Series X/S, PS4, Xbox One, PS3, and PC.
- **Dual Vibration Motors:** Provides immersive haptic feedback for realistic racing sensations.
- 270° Rotation Angle: Offers precise steering control for various racing games.
- Sensitivity Adjustment: Three levels of sensitivity (Low, Mid, High) to customize your driving experience.
- Programmable Keys: Customize button assignments for optimal gameplay across different titles.
- Versatile Mounting: Can be fixed to a desk using suction cups or comfortably positioned on the thighs with its curved base.

Follow these steps to connect your Superdrive GS750 Racing Steering Wheel to your console or PC.

- 1. **Connect the Steering Wheel:** Plug the USB cable from the steering wheel into an available USB port on your console (Xbox Series X/S, PS4, Xbox One, PS3) or PC.
- 2. Connect the Pedals: Connect the pedal unit cable to the designated port on the steering wheel unit.
- 3. Connect the Shifter: Connect the shifter unit cable to the designated port on the steering wheel unit.
- 4. **Power On:** Ensure your console or PC is powered on. The steering wheel should be automatically detected.
- 5. **Controller Connection (for Consoles):** For PS4 and Xbox One, connect your official console controller to the steering wheel's USB port (if available and required for authentication). Ensure the console controller is powered off before connecting.




Figure 3: Setup diagram illustrating connections for PS4 and Xbox One consoles, including the requirement to connect an official controller.

OPERATING INSTRUCTIONS

Sensitivity Adjustment

The GS750 offers three sensitivity modes: Low, Mid, and High. Use the sensitivity switch on the steering wheel base to select your preferred setting. Higher sensitivity means less physical wheel movement is needed for in-game steering.

Programmable Keys

The steering wheel features programmable keys, allowing you to assign specific functions to buttons for a personalized gaming experience. Refer to the video below for a detailed programming procedure.

Your browser does not support the video tag.

Video 1: This video demonstrates the programming procedure for the Superdrive GS750 steering wheel, showing how to assign functions to programmable keys. (Source: SUBSONIC INC)

Sequential Gearshift and Paddles

Utilize the sequential gear shifter or the digital paddles located behind the steering wheel for gear changes, providing flexible control options during gameplay.

Your browser does not support the video tag.

Video 2: This video provides an overview of the Superdrive GS750 steering wheel, highlighting its features including the sequential gearshift and digital paddles. (Source: SUBSONIC INC)

MAINTENANCE

To ensure the longevity and optimal performance of your Superdrive GS750, follow these simple maintenance guidelines:

- Cleaning: Use a soft, dry cloth to wipe down the steering wheel, pedals, and shifter. Avoid abrasive cleaners or solvents that could damage the finish.
- Storage: When not in use, store the unit in a cool, dry place away from direct sunlight and extreme temperatures.
- Cable Care: Avoid sharp bends or kinks in the cables. Do not pull on the cables to disconnect the unit.
- Suction Cups: Ensure suction cups are clean and free of dust for optimal grip on smooth surfaces.

Troubleshooting

Problem	Possible Cause	Solution
Steering wheel not recognized by console/PC.	Incorrect connection, driver issue, or console controller not authenticated.	Ensure all cables are securely connected. For consoles, connect the official controller to the steering wheel's USB port (if applicable) and ensure it's powered off before connecting. Try a different USB port. Update drivers on PC.

Problem	Possible Cause	Solution
No vibration feedback.	Game does not support vibration, or vibration setting is off.	Check in-game settings for vibration feedback. Ensure the game supports force feedback or vibration.
Suction cups not holding firmly.	Surface is not clean or smooth, or suction cups are dirty.	Clean the surface and the suction cups thoroughly. Ensure the surface is smooth and non-porous. Apply slight pressure when attaching.
Settings reset after powering off.	This model may not retain custom settings after power cycle.	Some settings, particularly programming, may need to be re-applied each time the device is powered on. This is a characteristic of the device.

SPECIFICATIONS

Model Number: SA5156-NG

Compatibility: Xbox Series X/S, PS4, Xbox One, PS3, PC

Rotation Angle: 270°

Vibration: Dual vibration motors

Sensitivity Modes: 3 (Low, Mid, High)

Connectivity: Wired USB

Product Dimensions: 12.8 x 10.83 x 17.32 inches

Item Weight: 7.72 pounds **Manufacturer:** Subsonic

First Available: June 21, 2021

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please refer to the official SUBSONIC website or contact their customer service directly. Protection plans may also be available for extended coverage.

Visit the official SUBSONIC Store: SUBSONIC Store on Amazon

© 2024 SUBSONIC. All rights reserved.

Related Documents - SA5156-NG



DRIVE PRO SPORT GS 850-X Racing Wheel User Manual

Comprehensive user manual for the DRIVE PRO SPORT GS 850-X racing wheel, covering features, installation, button configuration, programming, and troubleshooting for PS4, Xbox Series X/S, and Xbox One.



Subsonic GS 650-X Racing Wheel: Safety, Precautions, and Environmental Guidelines

Comprehensive safety warnings, usage precautions, handling instructions, cleaning advice, storage tips, and environmental disposal guidelines for the Subsonic GS 650-X racing wheel (Model SA5658) by SUPERDRIVE.



Handleiding Subsonic Superdrive SV200 Gaming Stuur | Installatie & Gebruik

Vind de complete handleiding voor het Subsonic Superdrive SV200 gaming stuur. Leer hoe u het stuur installeert, configureert en gebruikt op PC, PS4, Xbox One en Nintendo Switch.



DRIVE PRO SPORT GS 850-X: Guida all'uso e configurazione

Manuale di istruzioni completo per il volante DRIVE PRO SPORT GS 850-X, che copre l'installazione, la configurazione dei pulsanti, la programmazione, la sensibilità e la risoluzione dei problemi per PS4, Xbox Series X/S e Xbox One.



Subsonic Astra Gaming Headset: User Manual and Setup Guide

Detailed instructions and specifications for the Subsonic Astra Gaming Headset. Learn how to connect and use the headset with PS5, PS4, Xbox Series X/S, Xbox One, PC, Nintendo Switch, and mobile devices. Includes safety precautions and environmental information.



Subsonic Spectra LED Gaming Headset: User Manual & Specifications

Comprehensive user manual and specifications for the Subsonic Spectra LED Gaming Headset, covering setup, features, precautions, and compatibility with PS5, PS4, Xbox, PC, and Nintendo Switch.