

- Manuals.plus /
- > [WLIVE](#) /
 - > WLIVE 7 Drawer Dresser TV Stand Instruction Manual

WLIVE ASNG045HH

WLIVE 7 Drawer Dresser TV Stand Instruction Manual

Model: ASNG045HH

PRODUCT OVERVIEW

The WLIVE 7 Drawer Dresser TV Stand is a versatile storage solution designed for bedrooms, living rooms, closets, and entryways. It features a sturdy metal frame, a water-resistant wood top, and seven foldable fabric drawers, offering ample storage and serving as a media console table for televisions up to 45 inches.



Image: The WLIVE 7 Drawer Dresser TV Stand in dark grey, shown with a television placed on its wood top, demonstrating its dual functionality as a storage unit and media console.



Image: The dresser integrated into a bedroom environment, showcasing its compact design and how it complements interior decor while providing storage.

SETUP AND ASSEMBLY

Assembly of the WLIVE 7 Drawer Dresser TV Stand is designed to be straightforward, typically taking 15-20 minutes. All necessary hardware and detailed instructions are included. An installation video guide is also available for visual assistance.

Required Tools:

- L-wrench (included)
- Phillips head screwdriver (not included, recommended for handle assembly)

Assembly Steps:

1. Unpack all components and verify against the parts list in the instruction manual. Ensure all pieces are present and

undamaged.

2. Lay out the metal frame components on a soft, clean surface to prevent scratches.
3. Assemble the steel frame according to the numbered diagrams in the manual. Secure all connections firmly.
4. Attach the water-resistant wood top to the assembled frame.
5. Install the anti-tip device to the back of the dresser and secure it to a wall stud as per the instructions. This is a crucial safety measure to prevent tipping.
6. Assemble the fabric drawers by inserting the bottom panels and attaching the arch handles. Note: Some users find a personal Phillips head screwdriver provides better leverage for attaching handles than the included tool.
7. Insert the assembled fabric drawers into their respective slots in the frame.
8. Adjust the four adjustable feet at the base of the dresser to ensure stability on uneven floors and to protect your flooring from scratches.

PRODUCT SIZE



Image: A detailed view of the dresser's sturdy steel frame construction, highlighting the integrated anti-tip device for enhanced safety and stability.

3-Tier Design More Durable



Ours ✓



Others ✗




Image: An illustration comparing the durable 3-tier fabric drawer design with the ergonomic arch handles, contrasting them with less robust alternatives.

OPERATING INSTRUCTIONS

The WLIVE 7 Drawer Dresser is designed for versatile use, providing organized storage and functioning as a media console.

Storage Utilization:

- The dresser features seven foldable deep drawers: three medium-sized and four large-sized.
- Use the drawers to store clothing, accessories, linens, toys, or other household items.
- The arch handles allow for smooth and easy opening and closing of the fabric drawers.

TV Stand Functionality:


- The wood top surface is suitable for placing televisions up to 45 inches.
- The drawers can be used to store media accessories such as CDs, DVDs, game controllers, and remote controls.

STURDY STEEL FRAME

PLUS ANTI-TIP DESIGN



Anti-Tilt Device



Prevent Incidents



Image: An illustrative guide detailing the approximate storage capacity of the medium and large fabric drawers for various clothing items like socks, t-shirts, and jeans.



Image: The dresser shown with a television, emphasizing its suitability as a TV stand for screens up to 45 inches, providing a cozy viewing height.

MAINTENANCE AND CARE

Proper care ensures the longevity and appearance of your WLIVE dresser.

- **Cleaning the Wood Top:** Wipe the water-resistant wood top with a dry cloth to remove dust and spills. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning Fabric Drawers:** For the fabric drawers, spot clean with a damp cloth and mild detergent if necessary. Allow to air dry completely. Do not machine wash or tumble dry.
- **Weight Distribution:** Distribute weight evenly across the wood top and within the drawers. Avoid placing excessively heavy items in the fabric drawers to prevent deformation or fraying over time.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

This section addresses common issues you might encounter during assembly or use.

Common Issues and Solutions:

- **Difficulty Screwing Handles:** If the screws for the fabric drawer handles are hard to tighten, use a personal Phillips head screwdriver with sufficient force. The included L-wrench may not provide enough torque for this specific step.
- **Plastic/Chemical Odor:** A new product may have a slight plastic smell upon unpacking. This is normal and typically dissipates quickly. To accelerate this, clean the unit with a dry cloth and ensure good ventilation in the room by opening windows.
- **Dresser Not Sitting Flush Against Wall:** If a thick baseboard prevents the dresser from sitting flat against the wall, adjust the anti-tip device's placement or consider using spacers behind the device to bridge the gap. Ensure the anti-tip device is securely anchored to a wall stud.
- **Dresser Stability Issues:** Ensure all frame connections are securely tightened. Adjust the four adjustable feet at the bottom of the dresser to compensate for uneven flooring, ensuring the unit is level and stable.

SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Model Name	ASNG045 Fabric 7 Drawer-High Storage Cabinet / HH
Product Dimensions	11.8"D x 39.4"W x 30.5"H
Color	Dark Grey
Room Type	Bedroom, Living Room, Closet, Entryway, College Dorm
Furniture Finish	Walnut (Wood Top)
Drawer Type	Center Mounted Slide (Fabric Drawers)
Assembly Required	Yes
Item Weight	25.6 Pounds
Number of Pieces	1
Suitable TV Size	Up to 45 inches



Reference TV Size : 43 "

Image: A detailed diagram illustrating the precise dimensions of the WLIVE 7 Drawer Dresser TV Stand, including length, width, and height.

WARRANTY INFORMATION

The WLIVE 7 Drawer Dresser TV Stand comes with a **Full Warranty**. For specific details regarding the terms, conditions, and duration of the warranty, please refer to the warranty card included with your product or contact WLIVE customer support directly.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your WLIVE 7 Drawer Dresser TV Stand, please contact WLIVE customer support. You can typically find contact information on the product packaging, the included manual, or by visiting the official WLIVE store online.

Visit the [WLIVE Store on Amazon](#) for more information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B097Y285VC>

More documents and user manuals: <https://manuals.plus/>