mloong playpen

Mloong Baby Playpen with Mat (59x59 Inch) - Instruction Manual

Model: Playpen | Brand: Mloong

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Mloong Baby Playpen. Please read all instructions carefully before use to ensure the safety and proper function of the product.

Important Safety Information

- Always supervise children in the playpen. Never leave a child unattended.
- Ensure all parts are correctly assembled and securely fastened before placing a child inside.
- Discontinue use if any part is damaged, broken, or missing. Contact customer support for replacement parts.
- Keep small objects, cords, and potential choking hazards out of the playpen.
- Do not modify the product in any way, as this may compromise its safety and structural integrity.
- The playpen is designed for infants and toddlers. Adhere to the maximum weight recommendation of 36 pounds (approximately 16.3 kg).
- Place the playpen on a flat, stable surface away from stairs, windows, and heat sources.

Package Contents

Verify that all components are present before beginning assembly:

- Fabric Playpen Cover (320D Oxford material)
- Steel Frame Poles (various lengths)
- Connectors (for assembling the frame)
- Foldable Play Mat (59x59 inches)
- Pull-Up Handles
- Net Storage Bag

Setup Instructions

Follow these steps to assemble your Mloong Baby Playpen:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble the Base Frame:** Connect the shortest steel poles using the appropriate connectors to form the base rectangle. Ensure all connections click securely into place.
3. **Attach Vertical Poles:** Insert the longer vertical poles into the base connectors.
4. **Install Fabric Cover:** Slide the fabric playpen cover over the assembled frame. Ensure the mesh sides are correctly oriented. The cover should fit snugly.
5. **Assemble Top Frame:** Connect the remaining steel poles to the top of the vertical poles using the remaining connectors, securing the fabric cover in place.
6. **Insert Play Mat:** Lay the foldable play mat flat inside the playpen. Ensure it covers the entire base and fits without gaps.
7. **Attach Handles:** Clip the pull-up handles onto the top railing of the playpen at desired locations.
8. **Final Check:** Verify that all poles are firmly connected, the fabric is taut, and the playpen is stable before use.



Image: Assembled Mloong baby playpen, showing its spacious design and overall dimensions.




Image: Close-up of the playpen's construction, highlighting the durable 320D Oxford cloth, sturdy stitching, thick steel pipes, and foam covers for safety.

Video: A detailed review demonstrating the Mloong Baby Playpen, including its features and benefits as a safe space for babies and toddlers.

Operating Instructions

The Mloong Baby Playpen is designed for ease of use and child safety:

- **Zipper Door:** The playpen features an easy-access zipper door. To open, simply unzip the door. To close, zip it up completely to secure the child inside. This allows for easy entry and exit for parents and older children.
- **Pull-Up Handles:** The included handles can be attached to the top railing, providing support for babies learning to stand and walk. Ensure they are securely clipped before use.
- **Visible Mesh Sides:** The breathable mesh sides allow for clear visibility of your child at all times, ensuring they are safe and engaged.
- **Spacious Interior:** The extra-large design provides ample space for your baby to play, crawl, and explore comfortably, even allowing a parent to join inside.



Image: A parent interacting with a baby inside the playpen, showcasing the spacious interior and transparent mesh sides.

Video: A demonstration highlighting the safety features and practical use of the Mloong Baby Playpen.

Maintenance and Cleaning

To keep your Mloong Baby Playpen clean and hygienic:

- **Fabric Cover:** The 320D Oxford material is waterproof and easy to clean. Wipe down the fabric with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before reassembly or storage.
- **Play Mat:** The play mat can be wiped clean with a damp cloth and mild soap. For spills, promptly clean the area to prevent staining. Ensure the mat is dry before placing it back in the playpen.

- **Frame:** Wipe the steel frame and connectors with a damp cloth as needed.
- **Regular Inspection:** Periodically check all components for wear and tear, especially the fabric, zippers, and connectors.



Image: Features of the playmat, including its easy-to-clean surface and soft, thick material.

Troubleshooting

If you encounter any issues with your Mloong Baby Playpen, refer to the following common solutions:

- **Playpen is Unstable:** Ensure all frame poles are fully inserted into their connectors and that the connectors are securely locked. Check that the non-slip suction cups on the bottom are clean and pressed firmly to a smooth, flat floor

surface.

- **Mat Does Not Lie Flat:** The mat is designed to fit snugly. Ensure it is laid out correctly and that its corners are aligned with the playpen's corners. If recently unpacked, allow some time for the mat to flatten out.
- **Zipper is Stuck:** Gently try to move the zipper pull back and forth. Ensure no fabric is caught in the zipper teeth. Do not force the zipper, as this may cause damage.
- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, or during use, please contact Mloong customer service for assistance.

Specifications

Brand	mloong
Model Number	playpen
Item Dimensions	59.06 x 59.06 x 25.59 inches (150 x 150 x 65 cm)
Floor Area	24.17 Square Feet
Item Weight	5.15 Kilograms
Maximum Weight Recommendation	36 Pounds (16.3 kg)
Material Type	320D Oxford Cloth
Color	Medium Grey
Age Range Description	Infant

Warranty and Support

For warranty information, product support, or to order replacement parts, please contact Mloong customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question