

JolyWell JW-CL002

JolyWell Night Light for Kids User Manual

Model: JW-CL002

Brand: JolyWell

INTRODUCTION

The JolyWell Night Light for Kids is a versatile and safe lighting solution designed for nurseries and children's rooms. It features multiple lighting modes, including warm white and 7 color-changing options, stepless dimming, and touch control for ease of use. Its rechargeable battery provides long-lasting illumination, and the BPA-free material ensures safety for your child.

SAFETY INFORMATION

- Keep the device away from water and excessive moisture.
- Do not disassemble or attempt to repair the device yourself.
- Use only the provided charging cable or a certified equivalent.
- Ensure the device is placed on a stable, flat surface.
- This product is designed for indoor use only.
- Keep out of reach of small children when not in use or during charging to prevent accidental damage or ingestion of small parts.

PRODUCT OVERVIEW

The JolyWell Night Light is designed with a soft, egg-shaped silicone exterior, making it safe and pleasant to touch.




Figure 1: JolyWell Egg Night Light - Front View.

Key Features:

- **BPA-Free Material:** Made from top-grade, safe PC, ABS plastic, and BPA-free material.
- **Eye-Caring LED Light:** Delivers 360° uniform, gentle, and flicker-free lamplight.
- **Warm Light Mode:** Provides a soft, ambient warm light.
- **7 Changeable RGB Colors:** Cycle through 7 vibrant colors or select a favorite.
- **Touch Control:** Simple tap and hold gestures for power, dimming, and color selection.
- **1-Hour Timer:** Automatic shut-off feature to conserve energy.

- **Rechargeable Battery:** Built-in 2000 mAh battery for portability.



Figure 2: Overview of JolyWell Night Light's main features including BPA-free material, eye-caring LED, warm light, 7 RGB colors, touch control, and 1-hour timer.

SETUP

1. **Unpack:** Carefully remove the night light and all accessories from the packaging.
2. **Initial Charge:** Before first use, fully charge the night light using the provided USB charging cable. Connect the cable to the USB charging port located at the bottom of the device and plug the other end into a compatible USB power adapter (not included). The LED indicator will blink red when the battery is low and will likely change color or turn off when fully charged.



Figure 3: The night light connected to a USB charging cable.

3. **Power Switch:** Locate the main power switch on the bottom of the night light. Slide it to the "ON" position to activate the device.



Figure 4: Bottom view of the night light, highlighting the USB charging port, 1-hour timer switch, and the main ON/OFF switch.

OPERATING INSTRUCTIONS

The JolyWell Night Light features intuitive touch controls for various functions.

Power ON/OFF and Brightness Adjustment

1. **Turn On/Off:** Double-tap the top surface of the night light to turn it ON or OFF.
2. **Adjust Brightness (Warm Light Mode):** Once the light is on in warm white mode, press and hold the top surface to seamlessly adjust the brightness from dim to bright, or bright to dim. Release your finger when the desired brightness is reached.



Figure 5: Demonstrating touch control for adjusting brightness from high to low.

Color Changing Mode

1. **Activate Color Mode:** With the light on, locate the switch on the bottom of the device (next to the ON/OFF switch) and slide it to the "RGB" position. The light will begin to cycle through 7 different colors.
2. **Select a Color:** While the colors are cycling, tap the top surface once to pause on your favorite color. The light will remain on that color until you tap it again to resume cycling or switch back to warm white mode.

Enchanting RGB Lights

8 whimsical colors for learning and play Tap once to get your desired color



Figure 6: The night light displaying various enchanting RGB colors.

1-Hour Timer Function

The night light includes a 1-hour timer to automatically turn off the light, saving energy.

1. **Activate Timer:** Locate the "1H Timer" switch on the bottom of the device. Slide it to the "ON" position. The light will automatically turn off after 1 hour.
2. **Deactivate Timer:** Slide the "1H Timer" switch to the "OFF" position to disable the timer function.



Figure 7: Close-up of the bottom of the night light showing the 1-hour timer switch.

MAINTENANCE

- **Cleaning:** Wipe the surface of the night light with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** When not in use for extended periods, store the night light in a cool, dry place away from direct sunlight. Ensure it is fully charged before storing to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted. Main power switch is OFF.	Charge the night light. Slide the main power switch to "ON".
Touch control is unresponsive.	Device is in standby mode. Surface is dirty.	Double-tap to activate. Clean the touch surface.
Light flickers or dims unexpectedly.	Low battery.	Recharge the night light.
Colors are not changing.	Stuck on a single color. Not in RGB mode.	Tap the top surface to resume cycling. Slide the bottom switch to "RGB" mode.

SPECIFICATIONS

Model Number	JW-CL002
Dimensions	3"D x 3"W x 4"H
Item Weight	0.7 Ounces (approx. 19.8g)
Light Source Type	LED
Brightness	100 Lumen
Wattage	1.5 watts
Voltage	5 Volts
Power Source	Battery Powered (1 Lithium Ion battery required, included)
Material	Silicone Rubber, PC, ABS Plastic
Control Method	Touch
Special Features	Touch Control, Energy Efficient, Dimmable, Color Changing

WARRANTY AND SUPPORT

The JolyWell Night Light comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

For technical support, warranty claims, or any questions regarding your product, please contact JolyWell customer service through their official channels. Refer to the product packaging or the JolyWell brand store on Amazon for contact information.

JolyWell Brand Store: [Visit JolyWell Store on Amazon](#)