

[Manuals.plus](#) /

› [SuperHandy](#) /

› SuperHandy Mini Wood Chipper Shredder Mulcher GUO035 User Manual

SuperHandy GUO035

SuperHandy Mini Wood Chipper Shredder Mulcher

Model: GUO035

Brand: SuperHandy

INTRODUCTION

This manual provides essential information for the safe and efficient operation and maintenance of your SuperHandy Mini Wood Chipper Shredder Mulcher, Model GUO035. This compact, heavy-duty machine is designed for high-volume chipping, shredding, and mulching of garden debris, including branches and limbs up to 3 inches in diameter. It features a powerful 7HP 4-stroke single-cylinder OHV gas-powered engine and a 15:1 reduction ratio.

Chip and Shred with Ease

Dispose of the unwanted garden mess in no time.

15:1 Reduction Ratio

Chipping 15 bags worth of garden waste into 1.

3" Limb Capacity

Chip and shred branches that are less than 3" in diameter.



Image: The SuperHandy Mini Wood Chipper Shredder Mulcher, Model GUO035, shown in its operational state.

SAFETY INFORMATION

Always prioritize safety when operating this equipment. Failure to follow safety guidelines can result in serious injury or property damage.

- Read and understand the entire user manual before operation.
- Always wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and heavy-duty gloves.
- Ensure the work area is clear of bystanders, children, and pets.
- Never operate the machine under the influence of alcohol or medication.
- Do not wear loose clothing or jewelry that could get caught in moving parts.
- Ensure the machine is on a stable, level surface before starting.
- Never place hands or feet into the feeding chute or discharge chute while the engine is running.
- Turn off the engine and disconnect the spark plug before performing any maintenance, clearing clogs, or making adjustments.
- Use only 87+ unleaded gasoline (NO ETHANOL recommended) and the correct type and amount of engine oil (ENGINE OIL NOT INCLUDED).
- This machine is EPA/CARB Certified.

SETUP

1. Unpacking and Assembly

Carefully remove all components from the packaging. Refer to the assembly diagrams in your printed manual for detailed steps. Ensure all bolts and fasteners are securely tightened before initial use.

2. Fuel and Oil Filling

Before starting the engine, fill the fuel tank with 87+ unleaded gasoline (ethanol-free is recommended). Add the appropriate engine oil to the crankcase. Refer to the engine manual for specific oil type and capacity. Do not overfill.

Powerful and Stable **212cc Robust Engine**

Crafted with the robust AlphaWorks engine, this tool is adept at effortlessly tackling any gardening or lawn-related task with unparalleled efficiency.

Cylinder:

4-Stroke

Horsepower:

7HP

- ◆ **Stable Performance**
- ◆ **Powerful Engine**
- ◆ **Low Maintenance**



Image: Close-up of the 7HP engine, showing the fuel cap and oil fill point.

3. Initial Checks

- Verify that the spark plug wire is securely connected.
- Check the air filter for cleanliness.
- Ensure the discharge chute is properly positioned and secured.

- Confirm that all safety guards are in place.

Setup and Operation Video

Your browser does not support the video tag.

Video: Official SuperHandy video demonstrating the setup and initial operation of the Mini Wood Chipper.


OPERATING INSTRUCTIONS

1. Starting the Engine

- Ensure the fuel valve is open and the engine switch is in the "ON" position.
- If the engine is cold, apply choke as needed.
- Pull the recoil starter handle firmly until the engine starts.
- Once started, gradually move the choke to the "OFF" position.

2. Feeding Material

The chipper is designed for branches, limbs, leaves, and corn stalks. The maximum cutting capacity is 3 inches for branches. Feed material into the large extended feeding chute one piece at a time. Avoid feeding fresh greens, pine cones, palm branches (fronds may jam), petrified wood, or vines.



Large Hopper

Load in the greenery with ease. Easily stuff in a great amount of leaves, twigs, and branches.

Image: The large hopper designed for easy loading of garden debris.

3. Adjusting the Discharge Chute

The vertical extended discharge chute features an adjustable guide with an angled range of 90°-145° degrees. Adjust the guide to direct chipped material into a collection container, wheelbarrow, or desired area.



Precise Control

Crafted with a vertical discharge chute.

Multi-Position Chute

90-145 Degrees

Easily load the debris directly into a pickup bed or bucket. Saving you r back from picking debris off the ground.

Image: Close-up of the adjustable discharge chute, allowing precise control over debris direction.

Operation Demonstration Video

Your browser does not support the video tag.

Video: Official SuperHandy video showcasing the Mini Wood Chipper in action, demonstrating material feeding and discharge.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your wood chipper. Always turn off the engine and disconnect the spark plug before performing any maintenance.

1. Engine Oil Check and Change

Check the engine oil level before each use. Change the engine oil according to the schedule in your engine manual. Proper oil levels and clean oil are crucial for engine health.

2. Air Filter Cleaning

Clean the air filter every 10 hours of operation, or more frequently in dusty conditions. A dirty air filter can reduce engine performance and lifespan. Refer to the engine manual for specific cleaning instructions.

3. Blade Inspection

Regularly inspect the cutting blades for sharpness and damage. Dull or damaged blades can reduce efficiency and put strain on the engine. Replace blades as needed, following the instructions in your manual.



Built to Last Durable Housing

Suitable for various work environments, easily transportable.

All Steel Construction

Completely heat treated with powder coating for corrosion and rust resistance.

x2 Cutting Blades

Crafted out of high-strength industrial steel to easily shred garden waste.

Image: The durable steel housing and internal cutting blades, which require periodic inspection and maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Engine does not start	No fuel, old fuel, engine switch off, choke incorrect, spark plug issue, pinched fuel line.	Check fuel level and freshness. Ensure engine switch is ON. Adjust choke. Inspect and clean/replace spark plug. Check for kinks in the fuel line.
Engine runs poorly or bogs down	Dirty air filter, incorrect fuel/oil mixture, feeding too much material, dull blades.	Clean or replace air filter. Use recommended fuel and oil. Feed material slowly and avoid overloading. Inspect and sharpen/replace blades.

Problem	Possible Cause	Solution
Material jams in chute	Overfeeding, incorrect material type (e.g., palm fronds, vines), dull blades.	Turn off engine, disconnect spark plug, and carefully clear the jam. Avoid prohibited materials. Feed smaller quantities. Sharpen/replace blades.
Excessive vibration	Loose bolts, unbalanced blades, damaged components.	Check and tighten all bolts. Inspect blades for damage or imbalance. If vibration persists, contact customer support.

SPECIFICATIONS

- **Brand:** SuperHandy
- **Model Number:** GUO035
- **Power Source:** Gasoline-Powered
- **Engine:** 7HP Horizontal 4-stroke Single Cylinder OHV Gas Powered Engine
- **Max Cutting Capacity:** 3 inches
- **Reduction Ratio:** 15:1
- **Material:** Heat Treated Powder Coated Rust Resistant Steel
- **Operation Mode:** Gas powered
- **Color:** Orange
- **Wheel Size:** 10 inch
- **Weight:** Approximately 76 lbs
- **Discharge Chute Angle:** 90°-145° degrees (Adjustable)
- **Certifications:** EPA/CARB Certified



Portable Design

Easily transport the wood chipper from site to site with the lightweight design and all terrain wheels.



Wheel size:

10inch

Weight:

76lbs

Image: The chipper's portable design featuring 10-inch wheels for easy transport.

WARRANTY AND SUPPORT

For warranty information, technical support, or to order replacement parts, please refer to the contact details provided in your product packaging or visit the official SuperHandy website. Always provide your model number (GUO035) when contacting support.

You can also visit the [SuperHandy Store on Amazon](#) for additional product information and support resources.