

[manuals.plus](#) /

› [Altec Lansing](#) /

› [Altec Lansing Shockwave Wireless Party Speaker User Manual](#)

## Altec Lansing Shockwave

# Altec Lansing Shockwave Wireless Party Speaker User Manual

Model: Shockwave

## INTRODUCTION

Thank you for choosing the Altec Lansing Shockwave Wireless Party Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read these instructions carefully before using the product.



**150**  
**W**  
PEAK POWER



2 WAYS TO PLAY  
HORIZONTAL &  
VERTICAL

UP TO  
**10**  
HOURS  
PLAY TIME<sup>†</sup>



TRUE WIRELESS  
PAIRING



MULTI LIGHT  
PARTY MODES



**Bluetooth®**

Image: Front view of the Altec Lansing Shockwave speaker, highlighting its LED lights, 150W peak power, 10 hours play time, True Wireless Pairing, and multi-light party modes. A microphone is also shown as an included accessory.

## Key Features:

- **Powerful Audio Output:** 150W peak power for clear and crisp sound.
- **Dynamic LED Lights:** Built-in LED lights with 7 modes that sync with your music.
- **Versatile Connectivity:** Bluetooth 5.0 for stable wireless connection, USB, and AUX inputs.
- **Extended Playtime:** Rechargeable battery provides up to 10 hours of audio playback.
- **USB Smartphone Charger:** Integrated USB port to charge your mobile devices.
- **Microphone Input:** Supports microphone for karaoke or public speaking.
- **True Wireless Pairing:** Connect two Shockwave speakers for a stereo experience.

## SETUP GUIDE

---

### 1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided power adapter to the DC IN port on the speaker and plug it into a standard wall outlet. The charging indicator light will illuminate. Once fully charged, the indicator may change color or turn off, depending on the model. A full charge provides up to 10 hours of playtime.

### 2. Powering On/Off

Press and hold the **Power button** located on the control panel to turn the speaker on or off. You will hear an audible prompt indicating the power status.



Image: Close-up of the speaker's top control panel, showing inputs for MIC1, MIC2, USB-OUT, AUX, DC IN, and various control buttons including FM/AUX, BT/PAIR, LIGHTS, VOLUME-, VOLUME+, and Power.

### 3. Bluetooth Pairing

1. Ensure the speaker is powered on.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth indicator light.
3. On your mobile device, enable Bluetooth and search for available devices.
4. Select "**Altec Lansing Shockwave**" from the list.
5. Once paired, the Bluetooth indicator light will become solid, and you will hear a confirmation tone.

### 4. Connecting a Microphone

Connect a microphone to either the **MIC1** or **MIC2** input on the control panel. Adjust the microphone volume using the **MIC VOL+** and **MIC VOL-** controls.

## OPERATING INSTRUCTIONS

### 1. Audio Playback

- **Bluetooth:** Once paired, play audio from your connected device.
- **AUX Input:** Connect an audio device using a 3.5mm AUX cable to the **AUX** port. Press the **FM/AUX** button to switch to AUX mode.
- **FM Radio:** Press the **FM/AUX** button to cycle to FM radio mode. Use the volume buttons to scan for stations.

### 2. Adjusting Volume

Use the **VOLUME+** and **VOLUME-** buttons on the control panel to adjust the speaker's master volume.

### 3. LED Light Modes

Press the **LIGHTS** button to cycle through the 7 available LED light modes. The lights will pulse and strobe with your music.






Image: The Altec Lansing Shockwave speaker illuminated with red LED lights, demonstrating one of its multi-light party modes.

#### 4. True Wireless Pairing (TWS)

To connect two Altec Lansing Shockwave speakers for a stereo sound experience:

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, press and hold the **BT/PAIR** button until you hear a pairing tone.
3. The speakers will automatically connect to each other. Once connected, you will hear a confirmation.
4. Connect your mobile device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.

## 5. USB Smartphone Charging

Connect your smartphone or other USB-powered device to the **USB-OUT (5V 1A)** port on the control panel to charge it. This feature is active when the speaker is powered on.

## MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- Water Resistance:** While designed for outdoor use, avoid submerging the speaker in water.

## TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the speaker is charged. Connect the power adapter and try again.
No sound from the speaker.	<ul style="list-style-type: none"><li>Increase the speaker's volume and the volume on your connected device.</li><li>Ensure the correct input source (Bluetooth, AUX, FM) is selected.</li><li>Check if the device is properly paired via Bluetooth or if the AUX cable is fully inserted.</li></ul>
Bluetooth pairing fails.	<ul style="list-style-type: none"><li>Ensure the speaker is in pairing mode (flashing Bluetooth indicator).</li><li>Disable and re-enable Bluetooth on your device.</li><li>Move your device closer to the speaker.</li><li>Forget the speaker from your device's Bluetooth list and try pairing again.</li></ul>
Microphone not working.	<ul style="list-style-type: none"><li>Ensure the microphone is securely connected to the MIC1 or MIC2 port.</li><li>Adjust the MIC VOL+ control.</li><li>Test with another microphone if available.</li></ul>

## SPECIFICATIONS

Feature	Detail
Brand	Altec Lansing
Model	Shockwave
Power Output	150W Peak Power
Connectivity Technology	Bluetooth 5.0, USB, AUX
Power Source	Battery Powered (1 Lithium Ion battery required)
Battery Life	Up to 10 hours

Feature	Detail
Audio Input	Microphone (2 inputs)
USB Output	5V 1A (for smartphone charging)
Product Dimensions (L x W x H)	10.51 x 19.84 x 9.37 inches
Item Weight	13.02 pounds
UPC	656942160175
ASIN	B097Z48XFB

## WARRANTY AND SUPPORT

### Amazon Renewed Guarantee

This product is part of the Amazon Renewed program. Products purchased through Amazon Renewed are professionally inspected and tested to work and look like new. If you are not satisfied with your purchase, renewed products are eligible for replacement or refund under the Amazon Renewed Guarantee. Please refer to the Amazon Renewed Guarantee terms and conditions for full details regarding returns and support for renewed products.

### Contact Support

For further assistance or technical support, please refer to the contact information provided with your Amazon Renewed purchase or visit the Amazon Renewed support page.