

[manuals.plus](#) /

› [AIKE](#) /

› [AIKE Automatic Hand Dryer and Soap Dispenser Bundle Instruction Manual](#)

AIKE AK2630 & AK1205

AIKE Automatic Hand Dryer and Soap Dispenser Bundle

MODELS: AK2630 (HAND DRYER) & AK1205 (SOAP DISPENSER)

Your complete guide to installation, operation, and maintenance.



PRODUCT OVERVIEW

The AIKE Automatic Hand Dryer and Soap Dispenser Bundle provides a touch-free solution for hand hygiene, ideal for public restrooms and commercial spaces. This bundle includes the AK2630 Hand Dryer and the AK1205 Soap Dispenser, both designed for efficiency and cleanliness.

Key Features:

- **Bundle Included:** Hand Dryer AK2630 Black, Soap Dispenser AK1205 Matte Black
- **Sustainability and Cost Saving:** Save money from paper towel purchasing and daily maintenance.
- **Touch-free Germ Away:** Effectively clean your hands without coming into contact with dirty buttons in public restrooms to prevent cross-contamination.
- AIKE specializes in the production of hand hygiene products. Our store offers a wide range of hand hygiene products, including hand dryers, soap dispensers, and more, catering to all your needs.



Image: The AIKE Automatic Hand Dryer (left) and Soap Dispenser (right) in black finish.

SETUP AND INSTALLATION

Hand Dryer (Model AK2630) Installation:

- 1. Choose Location:** Select a suitable wall location, ensuring it's near a power outlet and away from direct water spray.
- 2. Mark Drilling Points:** Use the provided mounting template (if available) or measure the mounting holes on the back of the unit. Mark these points on the wall.
- 3. Drill Holes:** Drill holes at the marked points. Insert wall anchors if necessary for secure mounting.
- 4. Mount Unit:** Secure the hand dryer to the wall using the provided screws.
- 5. Connect Power:** Plug the hand dryer into a standard electrical outlet.



Image: The compact design of the AIKE Hand Dryer, suitable for various spaces.

Soap Dispenser (Model AK1205) Installation:

- 1. Choose Location:** Select a wall location, ideally above a sink or counter. Ensure a minimum of 10 inches (25 cm) clearance below the dispenser if installed above a countertop to allow for hand placement and soap dispensing.
- 2. Mark Drilling Points:** Use the mounting holes on the back of the dispenser to mark drilling points on the wall.
- 3. Drill Holes:** Drill holes and insert wall anchors if needed.
- 4. Mount Unit:** Secure the soap dispenser to the wall using the provided screws.
- 5. Fill with Soap:** Open the top cover and pour liquid soap into the reservoir. The wide funnel design makes refilling easy.

Required 10 inches Minimum Installation Gap

*If the device is installed above any countertop



Image: Illustration showing the recommended 10-inch minimum installation gap above a countertop for the AIKE Soap Dispenser.



EASY FILLING WIDE FUNNEL

Image: The AIKE Soap Dispenser with its top open, demonstrating the easy-filling wide funnel for liquid soap.

OPERATING INSTRUCTIONS

Using the Hand Dryer (Model AK2630):

- Activate:** Place your hands under the air outlet of the hand dryer. The infrared sensor will detect your hands and automatically activate the airflow.
- Dry Hands:** Move your hands slowly back and forth under the airflow until they are dry. The powerful airflow is designed for fast drying in 10-15 seconds.
- Deactivate:** Remove your hands from the sensor area. The hand dryer will automatically turn off.



Image: Hands placed under the AIKE Hand Dryer, showing the powerful airflow for quick drying.



Fast Dry in 10-15s



Smart-warm Wind

Image: Visual representation of the AIKE Hand Dryer's "Fast Dry in 10-15s" and "Smart-warm Wind" features.

Using the Soap Dispenser (Model AK1205):

- Activate:** Place your hands under the nozzle of the soap dispenser. The infrared sensor will detect your hands.
- Dispense Soap:** The dispenser will automatically release a measured amount of liquid soap into your hands.
- Deactivate:** Remove your hands from the sensor area. The dispenser will stop dispensing.



Image: The AIKE Soap Dispenser in action, dispensing liquid soap into a hand.

Touch-free, Germ Away



Image: The AIKE Soap Dispenser highlighting its "Touch-free, Germ Away" feature and 27 fl.oz. (800ml) capacity.

MAINTENANCE

Hand Dryer (Model AK2630):

- Exterior Cleaning:** Wipe the exterior surface with a soft, damp cloth and mild soap. Avoid abrasive cleaners or solvents.
- Air Inlet/Outlet:** Periodically check and clean any dust or debris from the air inlet and outlet grilles to ensure optimal airflow.

Soap Dispenser (Model AK1205):

- Refilling Soap:** When the soap level is low (visible through the transparent window), open the top cover and refill with liquid soap. Do not overfill.
- Cleaning:** Clean the exterior with a soft, damp cloth. If the nozzle becomes clogged, gently clear it with a small brush or toothpick.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Hand Dryer not activating.	No power; Sensor obstructed; Unit malfunction.	Check power connection; Clear sensor area; Contact support.
Weak airflow from Hand Dryer.	Blocked air inlet/outlet; Motor issue.	Clean grilles; Contact support.
Soap Dispenser not dispensing.	Empty reservoir; Clogged nozzle; Sensor obstructed.	Refill soap; Clear nozzle; Clear sensor area.
Soap Dispenser leaks.	Overfilled; Incorrect soap type; Seal issue.	Do not overfill; Use recommended liquid soap; Contact support.

SPECIFICATIONS

Feature	Detail
Brand	AIKE
Models Included	Hand Dryer AK2630, Soap Dispenser AK1205
Color	Black
Material	Plastic
Soap Dispenser Capacity	27 fl.oz. (800ml)
Hand Dryer Drying Time	10-15 seconds (approx.)
ASIN	B0982RZB2R

WARRANTY AND SUPPORT

For warranty information and technical support, please contact AIKE Direct customer service. Refer to your purchase documentation for specific warranty terms and conditions.

AIKE Direct Store: [Visit the AIKE Store on Amazon](#)

