

[Manuals.plus](#) /

> [iWALK](#) /

> iWALK Compact 9000mAh Portable Charger with Integrated Lightning Cable (Model UK-DBL10000)

iWALK UK-DBL10000

iWALK Compact 9000mAh Portable Charger

Model: UK-DBL10000

INTRODUCTION

Thank you for choosing the iWALK Compact 9000mAh Portable Charger. This device is designed to provide convenient and efficient power on the go for your compatible Apple devices. Its compact size and integrated Lightning cable make it an ideal companion for daily use and travel.

Key features include:

- **Integrated Lightning Cable:** Directly plug into your iPhone without needing extra cables.
- **Ultra-Compact Design:** Small and lightweight, easily fits into pockets or bags.
- **Fast Charging:** Delivers quick power to your device.
- **High Capacity:** 9000mAh battery provides multiple charges for most iPhones.

SAFETY INFORMATION

Please read all safety instructions before using this product to prevent injury or damage.

- Do not expose the power bank to extreme temperatures, direct sunlight, or fire.
- Do not immerse the power bank in water or other liquids.
- Avoid dropping or subjecting the power bank to strong impacts.
- Do not attempt to disassemble, repair, or modify the device.
- Keep out of reach of children.
- Use only certified charging cables and adapters.
- Dispose of the power bank responsibly according to local regulations.

PACKAGE CONTENTS

The package includes the following items:

- 1 x iWALK Compact 9000mAh Portable Charger (Model UK-DBL10000)
- 1 x USB-C Charging Cable (for recharging the power bank)

- 1 x Welcome Guide / User Manual



Image: The iWALK Compact 9000mAh Portable Charger in pink, shown connected to an iPhone, illustrating its compact size and integrated design.

PRODUCT OVERVIEW

Familiarize yourself with the components of your iWALK portable charger.



Image: A close-up view of the iWALK portable charger, highlighting its integrated Lightning plug, ready for direct connection to an iPhone.

1. **Integrated Lightning Connector:** For charging compatible iPhones.
2. **USB-C Input Port:** For recharging the power bank.
3. **Power Indicator Lights:** Shows remaining battery level.
4. **Power Button:** To check battery level or initiate charging (if not automatic).

SETUP

Initial Charging of the Power Bank

Before first use, fully charge your iWALK portable charger.

1. Connect the provided USB-C cable to the USB-C input port on the power bank.
2. Plug the other end of the USB-C cable into a compatible USB wall adapter (not included) or a computer's USB port.
3. The power indicator lights will illuminate to show the charging status. All lights will be solid when fully charged.

A full charge typically takes several hours, depending on the power source.

OPERATING INSTRUCTIONS

Charging Your iPhone

1. Carefully plug the integrated Lightning connector of the iWALK power bank directly into your iPhone's charging port.
2. The power bank should automatically begin charging your iPhone. If not, press the power button on the power bank once.
3. The power indicator lights on the power bank will show its remaining charge.
4. Once your iPhone is charged, or when you wish to stop charging, simply unplug the power bank from your iPhone.

Recharging the Power Bank

When the power indicator lights show a low charge, it's time to recharge the power bank.

1. Connect the provided USB-C cable to the power bank's USB-C input port.
2. Connect the other end of the USB-C cable to a power source (e.g., wall adapter, computer USB port).

3. The indicator lights will flash during charging and become solid when fully charged.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use liquid cleaners or aerosols.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. For long-term storage, it is recommended to charge the power bank to about 50-75% every three months to maintain battery health.
- **Handling:** Avoid bending or stressing the integrated Lightning connector.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging device.	Low battery on power bank; loose connection; device incompatibility.	Recharge power bank; ensure secure connection; verify device compatibility (iPhone models listed in specifications).
Power bank not recharging.	Faulty USB-C cable or adapter; loose connection; power source issue.	Try a different USB-C cable and adapter; ensure secure connection; try a different power outlet or USB port.
Slow charging.	Using a low-power adapter; device drawing high power; cable issue.	Use a higher wattage USB wall adapter for recharging the power bank; ensure your iPhone is not heavily in use while charging.

SPECIFICATIONS

Model Number	UK-DBL10000
Battery Capacity	9000 mAh (Lithium-ion)
Dimensions	11.6 x 8.4 x 3.4 cm
Weight	174 Grams
Input Port	USB Type C (5 Volts)
Output Connector	Integrated Lightning Cable
Compatible Phone Models	iPhone 14, 14 Plus, 14 Pro, 14 Pro Max, 13, 13 Pro, 13 Pro Max, 13 Mini, 12 Pro Max, 12 Pro, 12, 12 mini, 11 Pro, 11 Pro Max, 11, XS, XS Max, XR, X, 8, 8 Plus, 7, 7 Plus, 6, 6 Plus, SE (1st & 2nd Gen)

WARRANTY AND SUPPORT

iWALK products come with a 12-month worry-free warranty and friendly customer service. For any questions, issues, or support needs, please refer to the contact information provided in your Welcome Guide or visit the official iWALK website. Please retain your proof of purchase for warranty claims.

