

## Acer XC-830-UA91

# Acer Aspire XC-830-UA91 Desktop Computer User Manual

Model: XC-830-UA91

## INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Acer Aspire XC-830-UA91 Desktop Computer. Please read this guide thoroughly to ensure proper use and to maximize the performance and longevity of your device.

The Acer Aspire XC-830-UA91 is a compact desktop PC featuring an Intel Celeron J4125 Quad-Core Processor, 8GB DDR4 RAM, and a 256GB NVMe M.2 SSD, designed for everyday computing tasks, office work, and multimedia consumption. It comes pre-installed with Windows 10 Home.

## SETUP GUIDE

Follow these steps to set up your new Acer Aspire XC-830-UA91 Desktop Computer.

### 1. Unboxing and Component Identification

Carefully remove all components from the packaging. Ensure the following items are present:

- Acer Aspire XC-830-UA91 Desktop Unit
- USB Keyboard
- USB Mouse
- Power Cord
- Documentation (Quick Start Guide, Warranty Information)



Image: The Acer Aspire XC-830-UA91 desktop tower, a monitor, keyboard, and mouse set up on a desk, illustrating a typical workspace. An Intel Celeron logo is visible in the corner.

## 2. Connecting Peripherals

1. **Connect the Monitor:** Connect your monitor to the desktop using either the HDMI port or the VGA port located on the rear of the desktop.
2. **Connect the Keyboard and Mouse:** Plug the USB keyboard and USB mouse into any available USB ports on the desktop. The desktop features 2 USB 3.2 Gen 1 ports on the front and 4 USB 2.0 ports on the rear.
3. **Connect to Network (Optional):** For a wired internet connection, connect an Ethernet cable from your router or modem to the Gigabit Ethernet LAN (RJ45) port on the rear of the desktop. For wireless connectivity, the desktop supports 802.11ac Wi-Fi 5 and Bluetooth 4.2 LE.
4. **Connect Power:** Plug the power cord into the desktop's power input, then plug the other end into a wall outlet.

# Connect

with WiFi5, Bluetooth and Gigabit



Up to 3X faster  
802.11ac



1000Mbps

Gigabit LAN




Image: A close-up of the rear of the Acer Aspire XC-830-UA91 desktop, highlighting the various connectivity ports including USB, HDMI, VGA, and Ethernet. This image demonstrates where to connect external devices.

### 3. Initial Power On and Windows Setup

1. Press the power button on the front of the desktop.
2. Follow the on-screen instructions to complete the Windows 10 Home setup process. This typically involves selecting your region, language, creating a user account, and agreeing to terms and conditions.
3. The system may require updates after initial setup. Allow these updates to complete for optimal performance and security.

The desktop comes with Microsoft Office suite pre-installed, which may require activation or a subscription.

### Setup Video Guide

Your browser does not support the video tag.

Video: An unboxing and initial setup guide for the Acer Aspire XC-830-UA91 desktop. This video demonstrates the process of unpacking the computer, connecting peripherals, and the first boot-up sequence, including Windows 10 Home setup.

## OPERATING INSTRUCTIONS

### Power On/Off

- **To Power On:** Press the power button on the front of the desktop.
- **To Shut Down:** Click the Start button in Windows, then select Power > Shut down.
- **To Restart:** Click the Start button in Windows, then select Power > Restart.
- **To Sleep:** Click the Start button in Windows, then select Power > Sleep.

### Using the Optical Drive (DVD-RW)

The desktop includes an 8X DVD-Writer Double-Layer Drive (DVD-RW). To open the drive tray, locate the small button on the drive door and press it. Insert a disc and gently push the tray back in until it clicks.



Image: A front-facing view of the Acer Aspire XC-830-UA91 desktop, clearly showing the optical drive slot and the front USB and audio ports. This illustrates the location of the DVD-RW drive.

### Audio and Connectivity

The system supports High Def Audio with 5.1-Channel Surround Sound. Connect speakers or headphones to the

audio jacks on the front or rear of the desktop.

For wireless connections, ensure Wi-Fi and Bluetooth are enabled in Windows settings. The desktop supports 802.11ac Wi-Fi 5 and Bluetooth 4.2 LE for connecting to wireless networks and devices.



## High-Def Audio with 5.1-Channel Surround Sound Support

Image: The Acer Aspire XC-830-UA91 desktop tower with graphical representations of sound waves emanating from its base, indicating its 5.1-channel surround sound support.

### MAINTENANCE

#### Cleaning Your Desktop

- Always power off and unplug the desktop before cleaning.
- Use a soft, lint-free cloth to wipe down the exterior surfaces.
- For stubborn marks, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Use compressed air to clear dust from vents and ports. Avoid spraying liquid directly onto the device.

#### Software Updates

Regularly update your Windows operating system and drivers to ensure optimal performance, security, and compatibility. Windows 10 Home typically manages updates automatically, but you can manually check for updates

via **Settings > Update & Security > Windows Update**

## Data Backup

It is recommended to regularly back up your important data to an external drive or cloud storage to prevent data loss.

## TROUBLESHOOTING

If you encounter issues with your Acer Aspire XC-830-UA91, refer to the following common solutions:

Problem	Possible Solution
<b>No Power / System Not Turning On</b>	Ensure the power cord is securely connected to both the desktop and the wall outlet. Verify the wall outlet is functional by plugging in another device. Check the power button for any damage or obstruction.
<b>No Display on Monitor</b>	Confirm the monitor is powered on and connected correctly to the desktop's HDMI or VGA port. Try a different video cable or monitor if available. Ensure the correct input source is selected on your monitor.
<b>Keyboard or Mouse Not Responding</b>	Check USB cable connections. Try plugging them into different USB ports. If wireless, ensure batteries are charged and the receiver is properly connected. Restart the computer.
<b>Slow Performance</b>	Close unnecessary applications running in the background. Check for and install any pending Windows updates. Run a disk cleanup and defragmentation (for HDD, though this model has SSD). Ensure sufficient free space on the 256GB NVMe M.2 SSD.
<b>No Internet Connection</b>	For wired connection, check the Ethernet cable and router/modem status. For Wi-Fi, ensure Wi-Fi is enabled and you are connected to the correct network with the correct password. Restart your router/modem and the desktop.

If these steps do not resolve your issue, please contact Acer customer support for further assistance.

## SPECIFICATIONS

Below are the detailed technical specifications for the Acer Aspire XC-830-UA91 Desktop Computer:

Feature	Detail
<b>Processor</b>	Intel Celeron J4125 Quad-Core (Up to 2.7GHz)
<b>Operating System</b>	Windows 10 Home
<b>RAM</b>	8GB DDR4 2400MHz
<b>Storage</b>	256GB NVMe M.2 SSD

Feature	Detail
Graphics	Intel UHD Graphics 600 (Integrated)
Optical Drive	8X DVD-Writer Double-Layer Drive (DVD-RW)
Wireless Connectivity	802.11ac Wi-Fi 5, Bluetooth 4.2 LE
Wired Connectivity	10/100/1000 Gigabit Ethernet LAN (RJ45)
Front Ports	2 x USB 3.2 Gen 1, Headphone Jack, Microphone Jack
Rear Ports	4 x USB 2.0, 1 x HDMI, 1 x VGA, Ethernet (RJ45), Audio Jacks
Audio	High Def Audio with 5.1-Channel Surround Sound Support
Dimensions (LxWxH)	12.99 x 3.94 x 11.61 inches
Weight	10.13 pounds (system unit only)
Included Peripherals	USB Keyboard, USB Mouse

## WARRANTY INFORMATION

Your Acer Aspire XC-830-UA91 Desktop Computer comes with a **1 Year Parts and Labor Limited Warranty**. This warranty covers defects in materials and workmanship under normal use during the warranty period.

For detailed terms and conditions, please refer to the warranty documentation included with your product or visit the official Acer support website.

## CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Acer's customer support.

- **Toll-Free Tech Support:** Refer to your product documentation for the specific toll-free number.
- **Online Support:** Visit the official Acer support website for drivers, FAQs, and service requests.

When contacting support, please have your product model number (XC-830-UA91) and serial number ready.