Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PHILCO PMC01I

Philco Grano Aroma PMC01I Coffee Grinder User Manual

Model: PMC01I | Power: 200W | Voltage: 220V

1. Important Safety Instructions

Please read all instructions carefully before using the Philco Grano Aroma PMC01I Coffee Grinder. Retain this manual for future reference.

- **Electrical Safety:** Ensure the voltage of your electrical outlet matches the voltage specified on the appliance (220V). Do not use with an adapter if the voltage is incompatible.
- **Water and Liquids:** Do not immerse the motor base, cord, or plug in water or other liquids. Avoid contact with water.
- **Children:** This appliance is not intended for use by children. Keep the appliance and its cord out of reach of children.
- **Supervision:** Close supervision is necessary when any appliance is used near children.
- **Moving Parts:** Avoid contact with moving parts. Always ensure the lid is securely in place before operating.
- **Blades:** Blades are sharp. Handle with care during cleaning.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer support for assistance.
- **Unplug:** Always unplug the grinder from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- **Indoor Use:** This appliance is for household indoor use only.



Image: INMETRO and SGS safety certification logos, indicating compliance with Brazilian safety standards.

2. Product Overview

The Philco Grano Aroma PMC01I is a compact and efficient coffee grinder designed for home use. It features durable

stainless steel blades and a non-slip base for stability.



Image: Top-down view of the Philco Grano Aroma coffee grinder with coffee beans visible through the clear lid.



Image: Side view of the Philco Grano Aroma coffee grinder, showing the stainless steel body and power button.

Key Features:

- Grinds up to 50g of coffee beans.
- Durable stainless steel blades.
- Non-slip base for stability during operation.
- Integrated cord storage in the base.
- Compact and easy to store.

3. Setup

1. **Unpack:** Carefully remove the coffee grinder and all accessories from the packaging.

2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Clean:** Before first use, wipe the exterior of the grinder with a damp cloth. Clean the grinding chamber and lid with a dry cloth. Do not wash the motor base in water.
4. **Placement:** Place the grinder on a stable, flat, and dry surface.
5. **Power Connection:** Ensure your electrical outlet is 220V. Plug the power cord into the outlet.

4. Operating Instructions

Follow these steps to grind coffee beans with your Philco Grano Aroma PMC01I:

1. **Fill:** Remove the lid and add up to 50g of whole coffee beans into the grinding chamber. Do not overfill.
2. **Secure Lid:** Place the lid securely onto the grinder. The grinder will not operate unless the lid is properly closed due to the safety interlock.
3. **Grind:** Press and hold the power button located on the front of the grinder. The blades will begin to rotate.
4. **Monitor:** Grind for short intervals (e.g., 5-10 seconds) and check the consistency. Repeat until the desired grind size is achieved. For a coarser grind, grind for less time; for a finer grind, grind for longer.
5. **Stop:** Release the power button to stop grinding.
6. **Remove Grounds:** Unplug the grinder from the wall outlet. Carefully remove the lid and pour out the freshly ground coffee.

Note: For optimal performance and to prevent overheating, do not operate the grinder continuously for more than 30 seconds. Allow a short break between grinding cycles.

5. Cleaning and Maintenance

Regular cleaning ensures the longevity and hygiene of your coffee grinder.

1. **Unplug:** Always unplug the appliance before cleaning.
2. **Empty:** Ensure all coffee grounds are removed from the grinding chamber.
3. **Clean Grinding Chamber:** Use a small brush (not included) or a dry cloth to remove residual coffee grounds from the blades and interior of the chamber. Be careful as the blades are sharp.
4. **Clean Lid:** Wash the lid with warm, soapy water. Rinse thoroughly and dry completely before reattaching.
5. **Clean Exterior:** Wipe the exterior of the motor base with a damp cloth. Do not use abrasive cleaners or immerse the motor base in water.
6. **Storage:** Once clean and dry, store the grinder in a cool, dry place. The cord can be wrapped around the cord storage area in the base.

6. Troubleshooting

If you encounter issues with your coffee grinder, refer to the following table:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Grinder does not turn on.	1. Not plugged in. 2. Lid not properly secured. 3. Power outage.	1. Ensure the grinder is securely plugged into a 220V outlet. 2. Make sure the lid is fully closed and locked into place. 3. Check your household's power supply.
Grinder stops during operation.	1. Overheating. 2. Overfilled chamber.	1. Unplug and let the grinder cool down for at least 10-15 minutes. 2. Do not exceed the 50g capacity.
Coffee grounds are inconsistent.	Insufficient grinding time.	Grind for longer intervals, checking consistency periodically.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications



Image: Philco Grano Aroma coffee grinder with indicated dimensions: 10.5 cm (width), 10.5 cm (depth), 17.5 cm (height).

Feature	Detail
Brand	PHILCO
Model Number	PMC01I (53902060)
Power	200 Watts
Voltage	220 Volts
Capacity	50 grams (coffee beans)
Material	Stainless Steel (blades), Plastic (body)
Color	Inox (Stainless Steel finish)

Feature	Detail
Dimensions (L x W x H)	10.5 cm x 10.5 cm x 17.5 cm
Recommended Use	Grinding coffee beans
Country of Origin	China

8. Warranty

This Philco Grano Aroma PMC01I Coffee Grinder comes with a**12-month warranty** from the date of purchase.

The warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, accident, alteration, neglect, unauthorized repair, or commercial use.

Please retain your proof of purchase for any warranty claims.

9. Customer Support

For further assistance, technical support, or warranty inquiries, please contact Philco customer service.

Refer to the Philco official website or your product packaging for the most current contact information.

You can also visit the Philco Store on Amazon for more product information.

© 2026 PHILCO. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0985Y21ML

More documents and user manuals: **https://manuals.plus/**