Pemberly Row PR-4753-2106581

Pemberly Row Wood Twin Over Full Bunk Bed with Storage Boxes

Model: PR-4753-2106581

Introduction

This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your Pemberly Row Wood Twin Over Full Bunk Bed with Storage Boxes. Please read these instructions carefully before assembly and use to ensure safe and proper operation.

The Pemberly Row Collection bunk bed is designed to maximize sleep space, featuring a transitional style with a dark cherry finish. It includes a twin bed on top, a full bed on the bottom, and convenient under-bed storage boxes with casters.



Figure 1: The Pemberly Row Twin Over Full Bunk Bed in Dark Cherry with storage drawers pulled out.

Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always use the recommended mattress size for both the upper and lower bunks.
- Ensure all connections are tight and secure before use. Periodically check and tighten hardware.
- The top bunk is not suitable for children under 6 years of age.
- Prohibit more than one person on the upper bunk.
- Always use the ladder for entering and exiting the upper bunk. Do not use the bed as a play structure.
- Prohibit horseplay on or under the bed.
- Use guardrails on both sides of the upper bunk.
- Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.

- Keep these instructions for future reference.

Parts List

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Headboards (Twin & Full)
- Footboards (Twin & Full)
- Side Rails (Upper & Lower)
- Ladder
- Slats for both bunks
- Under-bed Storage Boxes with Casters
- Hardware Pack (bolts, nuts, washers, screws, Allen wrench)

Setup and Assembly

Assembly of this bunk bed requires two adults. Please follow the steps below carefully. It is recommended to assemble the bed in the room where it will be used.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface (like a carpet) to prevent scratching. Refer to the parts list to identify each component.
2. **Assemble Lower Bed Frame:** Attach the full-size side rails to the full-size headboard and footboard using the provided hardware. Do not fully tighten bolts until all components are aligned.
3. **Install Lower Bed Slats:** Place the full-size slats evenly across the lower bed frame and secure them according to the instructions.
4. **Assemble Upper Bed Frame:** Attach the twin-size side rails to the twin-size headboard and footboard.
5. **Install Upper Bed Slats:** Place the twin-size slats evenly across the upper bed frame and secure them.
6. **Attach Upper Bed to Lower Bed:** Carefully lift the assembled upper bed frame and align it with the designated connection points on the lower bed frame. Secure with the appropriate hardware. This step requires two people.
7. **Attach Ladder:** Securely attach the ladder to the upper bunk as indicated in the diagrams. Ensure it is firmly in place and does not wobble.
8. **Assemble Storage Boxes:** Follow the instructions to assemble the under-bed storage boxes. Install the casters on the bottom of each box.
9. **Final Tightening:** Once all components are in place and aligned, systematically tighten all bolts and screws using the provided Allen wrench. Do not overtighten.
10. **Safety Check:** Before use, double-check all connections to ensure they are secure and stable.

Note: Detailed diagrams and specific hardware identifiers are typically included in the physical assembly guide. This

section provides a general overview.

Operating Instructions

- **Mattress Placement:** Ensure mattresses are placed securely within the bed frames. The top bunk requires a mattress that does not exceed the height of the guardrails for safety. Foundation/box spring is not required.
- **Ladder Use:** Always use the ladder to access and exit the top bunk. Ensure the ladder is stable before climbing.
- **Storage Boxes:** The under-bed storage boxes are on casters for easy access. Pull them out gently to access contents and push them back fully when not in use to prevent tripping hazards.
- **Weight Capacity:** Adhere to the maximum weight capacity for each bunk as specified in the product details to prevent structural damage or injury.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the dark cherry finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Tighten any loose hardware to maintain structural integrity and safety.
- **Structural Integrity:** Regularly check for any signs of wear, cracks, or damage to the wood components. If significant damage is found, discontinue use and contact customer support.
- **Caster Maintenance:** Keep the casters on the storage boxes free of debris to ensure smooth operation.

Troubleshooting

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware connections.	Inspect and tighten all bolts and screws. Ensure all components are properly seated.
Ladder feels loose.	Ladder attachment hardware is not secure.	Re-tighten the bolts securing the ladder to the bunk bed frame.
Storage drawers are difficult to open/close.	Debris in casters or misaligned boxes.	Clean casters. Ensure boxes are not overloaded or jammed. Check for proper alignment under the bed.

Problem	Possible Cause	Solution
Squeaking noises.	Loose connections or friction between wood parts.	Tighten all hardware. Apply a small amount of furniture wax or silicone spray to friction points if necessary.

Specifications

Feature	Detail
Product Dimensions (Overall)	56.5"L x 78"W x 65.5"H
Bed Dimensions (Overall)	65.5"H x 78"W x 56.5"D
Headboard Dimensions	32.5"H x T 41.5"/F 56.5"W
Footboard Dimensions	32.5"H x T 41.5"/F 56.5"W
Rail to Floor Height	12"
Height of Bottom Bed (not incl. mattress)	12"
Height of Top Bunk Bed (not incl. mattress)	48"
Product Weight	179.25 lbs
Frame Material	Pine veneer, wood, and engineered wood
Finish Type	Dark Cherry
Assembly Required	Yes
Foundation/Box Spring	Not required
Included Components	Slats, Under-bed Storage Boxes with Casters



Figure 2: Detailed dimensions of the Pemberly Row Twin Over Full Bunk Bed.

Warranty Information

This Pemberly Row bunk bed comes with a **Limited Warranty**. The specifics of the warranty, including coverage duration and terms, are typically provided with your purchase documentation. Please refer to the warranty card or contact Pemberly Row customer support for detailed information regarding your product's warranty.
The warranty generally covers manufacturing defects under normal use. It does not cover damage resulting from misuse, abuse, accidents, modifications, or improper assembly.

Customer Support

For any questions, missing parts, assembly assistance, or warranty claims, please contact Pemberly Row customer support. When contacting support, please have your model number (PR-4753-2106581) and purchase information readily available.
Online Support: Visit the official Pemberly Row website for FAQs and support resources.Pemberly Row Store on Amazon
Product Care Instructions: For specific care instructions, please refer to the documentation included with your

product or contact customer support.

© 2023 Pemberly Row. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question