

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Easyfone](#) /

› [Easyfone Prime-A1 Pro GSM Flip Phone User Manual](#)

Easyfone Prime-A1 Pro

Easyfone Prime-A1 Pro GSM Flip Phone User Manual

Model: Prime-A1 Pro

1. INTRODUCTION

This manual provides detailed instructions for the Easyfone Prime-A1 Pro GSM flip phone. It covers essential information for setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly to ensure proper use and to maximize the phone's features.



Easyfone®
Prime-A1 Pro

Image: The Easyfone Prime-A1 Pro flip phone shown in both open and closed configurations, highlighting its design.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Handset (Easyfone Prime-A1 Pro)
- Battery (1 Lithium-ion)
- User Manual
- Lanyard
- Charging Dock
- Charger (Power Adapter)
- USB Cable

Image: An illustration of the Easyfone Prime-A1 Pro package contents, showing the phone, battery, user manual, lanyard, charging dock, charger, and USB cable.

3. PHONE OVERVIEW

The Easyfone Prime-A1 Pro features a classic flip design with large, easy-to-read buttons and dual screens for convenience.

3.1. Physical Features

- **Flip Design:** Open to answer calls, close to end them.
- **Large Buttons:** Clearly labeled, silicone keypad with large numbers for easy dialing.
- **Dual Screens:**
 - Main HD IPS Screen: 2.4 inches, located inside the flip.
 - External HD IPS Screen: 1.44 inches, displays time, date, battery, and incoming call information when closed.
- **SOS Button:** Dedicated button for emergency calls and GPS location sharing.
- **Blacklist Button:** Dedicated button to block unwanted numbers.
- **Photo Speed Dial Buttons:** 8 programmable buttons for quick dialing with associated photos.
- **Camera:** Integrated for basic photo capture.
- **Loud Speaker & Receiver:** Designed for clear audio, compatible with M4/T4 hearing aids.






Image: The Easyfone Prime-A1 Pro in its open position, displaying the internal screen and the large, clearly marked keypad.

HD IPS Screen Display Easy to Read



Image: A detailed view of the phone's dual screens, illustrating the main 2.4-inch HD IPS display and the 1.44-inch external HD IPS display.

Silicone Keyboard with Big Buttons



Image: A close-up of the phone's silicone keypad, emphasizing the large, tactile buttons designed for ease of use.

Designed for Elderly & Hard of Hearing



Image: A visual representation of the phone's enhanced audio features, including a loud receiver and powerful loudspeaker, designed for users with hearing difficulties and hearing aid compatibility.

4. SETUP

4.1. Battery Installation

1. Remove the back cover of the phone.
2. Insert the Lithium-ion battery into the battery compartment, ensuring the gold contacts align.
3. Replace the back cover until it clicks securely.

4.2. SIM Card Insertion

The Easyfone Prime-A1 Pro supports GSM 2G networks (850/900/1800/1900 MHz). Ensure your SIM card is compatible with these frequencies.

1. With the battery removed, locate the SIM card slot.
2. Insert your SIM card into the designated slot, following the orientation indicated on the phone.
3. Reinstall the battery and back cover.

How the Phone Works?

1



Select your Easyfone Device on Amazon

2



Activate the SpeedTalk Phone Plan

3



Insert the SIM Card & Ready to GO



Package Included a SpeedTalk SIM Card

Running on T-Mobile Network

* please check the network coverage before make the order.

SpeedTalk Easyfone Exclusive 4G Plan, Starting at \$11.99/mo

No Contracts No Credit Checks No Activation Fee

Keep your Existing Phone Number

Image: A three-step diagram showing how to select the device, activate a phone plan, and insert the SIM card to prepare the phone for use.

4.3. Charging the Phone

Before first use, fully charge the phone battery.

1. Connect the USB cable to the charger (power adapter).
2. Plug the charger into a wall outlet.
3. Place the phone into the charging dock, ensuring it sits correctly. The phone will begin charging automatically. Alternatively, connect the USB cable directly to the phone's charging port.
4. The battery icon on the screen will indicate charging status.



Image: The Easyfone Prime-A1 Pro resting in its dedicated charging dock, with the external screen showing the battery charging indicator.

1500 mAh



Standby Time 96H+



Easy to Charge



Image: The Easyfone Prime-A1 Pro being charged in its dock, accompanied by text highlighting its 1500mAh battery and over 96 hours of standby time.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

- **To Power On:** Press and hold the red End Call/Power button until the screen lights up.
- **To Power Off:** Press and hold the red End Call/Power button. Select "Power Off" from the options.

5.2. Making and Receiving Calls

- **Making a Call:** Open the flip, dial the number using the keypad, and press the green Call button.
- **Receiving a Call:** Open the flip to answer. Alternatively, press the green Call button when the phone is open.
- **Ending a Call:** Close the flip or press the red End Call button.

5.3. Sending and Receiving SMS Messages

- Navigate to the "Messages" menu.

- Select "New Message" to compose.
- Enter the recipient's number and your message.
- Press "Send".

5.4. SOS Emergency Button

The dedicated SOS button is located on the back of the phone. When activated, it will:

- Send an emergency SMS with your GPS location to pre-set emergency contacts.
- Automatically dial the emergency contacts in sequence until one answers.

To set up SOS contacts: Refer to the phone's settings menu under "SOS Settings".

5.5. Photo Speed Dial

The phone features 8 programmable photo speed dial buttons (1-8) for quick access to important contacts.

1. Navigate to the "Contacts" or "Speed Dial" settings.
2. Assign a contact and an associated photo to each speed dial number.
3. To use, press and hold the assigned number button.



Image: An illustration demonstrating the photo speed dial function, where users can assign photos to 8 direct dial buttons for easy contact recognition and calling.

5.6. Blacklist Feature

The dedicated blacklist button allows you to block unwanted calls directly.

- During an incoming call from an unwanted number, press the "BLOCK" button.
- The number will be added to your blacklist, preventing future calls from that number.



Image: The Easyfone Prime-A1 Pro's keypad with the "BLOCK" button highlighted, illustrating its function to prevent unwanted calls.

5.7. Additional Features

The Easyfone Prime-A1 Pro includes several practical tools:

- **FM Radio:** Listen to local radio stations.
- **Flashlight:** A built-in light for convenience.
- **MP3 Player:** Play audio files stored on the phone or an inserted memory card.
- **Memo:** Create and save short notes.
- **Voice Recorder:** Record audio.
- **Calculator:** Perform basic arithmetic.
- **Alarm Clock:** Set alarms.
- **Calendar:** View dates and schedule events.
- **Bluetooth:** Connect to compatible wireless accessories.



Practical Additional Features



Image: A collection of icons illustrating the various additional features available on the Easyfone Prime-A1 Pro, such as FM Radio, Flashlight, MP3 player, and more.

6. MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid liquid cleaners.
- Battery Care:**
 - Avoid extreme temperatures.
 - Do not expose the battery to water.
 - Charge the battery regularly, but avoid overcharging for extended periods.
- Storage:** Store the phone in a cool, dry place when not in use for extended periods.

7. TROUBLESHOOTING

Problem	Possible Solution
Phone does not power on.	Ensure the battery is correctly installed and charged. Connect to the charger and try again.
Cannot make or receive calls.	Check if the SIM card is properly inserted. Verify that your SIM card is active and compatible with 2G GSM networks (850/900/1800/1900 MHz). Check network signal strength.
Poor call quality or low volume.	Adjust the call volume. Ensure the speaker/receiver is not obstructed. If using a hearing aid, ensure it is properly configured with the phone's M4/T4 compatibility.
Battery drains quickly.	Reduce screen brightness. Close unused applications. Ensure the phone is not in an area with very weak signal, which can cause increased battery usage.

Problem	Possible Solution
Phone is unresponsive.	Remove the battery, wait a few seconds, then reinsert it and power on the phone.







8. SPECIFICATIONS

Feature	Detail
Brand	Easyfone
Model Name	Prime-A1 Pro
Color	Black
Form Factor	Flip
Operating System	Easyfone OS
Main Screen Size	2.4 Inches HD IPS
External Screen Size	1.44 Inches HD IPS
Cellular Technology	2G GSM (850/900/1800/1900 MHz)
Wireless Carrier	Unlocked (MVNO compatible)
Battery	1500 mAh Lithium-ion (included)
Internal Storage Capacity	16 GB
Memory Card Slot	1 slot (for MicroSD expansion)
Special Features	SOS Emergency Button with GPS, Dedicated Blacklist Button, Photo Speed Dial, Hearing Aid Compatible (M4/T4), Dual Screen, Charging Dock, Camera, FM Radio, Flashlight, MP3 Player, Memo, Voice Recorder, Calculator, Alarm Clock, Calendar, Bluetooth.
Total USB Ports	1
Manufacturer	Dongsen

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Easyfone customer service directly. Keep your proof of purchase for warranty claims.

Related Documents - Prime-A1 Pro

 <p>English Quick start guide Contents Congratulations on your purchase 4 Getting started 6 Common function setting paths 9 Shortcuts 10 Get to know your phone 11 Start up your phone 11 Start up word 11 Power on/off 11 Battery 11 Standby Mode 11 Keyboard 11 Adjust volume 12 Call 12 Call settings 12 Making a call 13 Answer a call 13 Call settings 14 Multi-tasking 14 Using the call 14 Contact 15 Contact 15 Speed dial with Photos 16 Message 18</p>	<p>Easyfone Prime-A1 Pro Quick Start Guide This document provides a quick start guide for the Easyfone Prime-A1 Pro unlocked senior cell phone, covering setup, basic functions, and features.</p>
 <p>English Quick start guide Contents Congratulations on your purchase 4 Getting started 6 Common function setting paths 9 Shortcuts 10 Get to know your phone 11 Start up your phone 11 Start up word 11 Power on/off 11 Battery 11 Standby Mode 11 Keyboard 11 Adjust volume 12 Call 12 Call settings 12 Making a call 13 Answer a call 13 Call settings 14 Multi-tasking 14 Using the call 14 Contact 15 Contact 15 Speed dial with Photos 16 Message 18</p>	<p>Easyfone Prime-A1 Pro User Manual and Quick Start Guide Comprehensive guide for the Easyfone Prime-A1 Pro senior flip phone, covering setup, essential features like SOS and GPS, call management, messaging, device settings, and troubleshooting tips.</p>
 <p>English Quick start guide Contents Congratulations on your purchase 4 Getting started 6 Common function setting paths 9 Shortcuts 10 Get to know your phone 11 Start up your phone 11 Start up word 11 Power on/off 11 Battery 11 Standby Mode 11 Keyboard 11 Adjust volume 12 Call 12 Call settings 12 Making a call 13 Answer a call 13 Call settings 14 Multi-tasking 14 Using the call 14 Contact 15 Contact 15 Speed dial with Photos 16 Message 18</p>	<p>Easyfone Prime-A1 Pro 4G LTE Flip Phone: Quick Start Guide for Seniors Get started with your Easyfone Prime-A1 Pro 4G LTE flip phone for seniors. This quick start guide provides essential instructions on setup, features like the SOS button and charging dock, and basic operations for an easy mobile experience.</p>
 <p>Table of Contents 1 Congratulations on your purchase 3 2 Get started 4 3 Keys and parts 4 4 Set up and watch on your phone 6 5 Charge your phone 10 6 Make calls 11 7 Receive calls 11 8 Explore your phone 13 9 Change the volume 14 10 Connect with your friends and family 15 11 Set Contacts 15 12 Calls 15 13 Personalize your phone 17 14 Change tones 17 15 Change language 18</p>	<p>Easyfone User Manual: Getting Started and Features Comprehensive user manual for the Easyfone senior mobile phone, covering setup, basic functions, personalization, SOS features, and more. Learn how to use your Easyfone for calls, contacts, and essential features.</p>
 <p>English Quick start guide Contents Congratulations on your purchase 4 Getting started 6 Common function setting paths 9 Shortcuts 10 Get to know your phone 11 Start up your phone 11 Start up word 11 Power on/off 11 Battery 11 Standby Mode 11 Keyboard 11 Adjust volume 12 Call 12 Call settings 12 Making a call 13 Answer a call 13 Call settings 14 Multi-tasking 14 Using the call 14 Contact 15 Contact 15 Speed dial with Photos 16 Message 18</p>	<p>Easyfone Prime-A6 Quick Start Guide A comprehensive quick start guide for the Easyfone Prime-A6, covering setup, basic functions, and troubleshooting.</p>
 <p>English Quick start guide Contents Congratulations on your purchase 4 Getting started 6 Common function setting paths 9 Shortcuts 10 Get to know your phone 11 Start up your phone 11 Start up word 11 Power on/off 11 Battery 11 Standby Mode 11 Keyboard 11 Adjust volume 12 Call 12 Call settings 12 Making a call 13 Answer a call 13 Call settings 14 Multi-tasking 14 Using the call 14 Contact 15 Contact 15 Speed dial with Photos 16 Message 18</p>	<p>Easyfone Senior Cell Phone: Quick Start Guide This guide provides essential instructions for setting up and using your Easyfone senior cell phone, covering basic functions, key features, and getting started with communication.</p>

Quick start guide	
English	
Contents	
Congratulations on your purchase.....	4
Get Started.....	6
Common function setting path.....	9
Shortcut Key.....	9
Insert SIM card/Memory Card/Battery.....	10
Get to know your phone.....	11
Power ON and OFF.....	11
Start-UP wizard.....	11
Standby Mode.....	11
Flashlight.....	12
BLOCK button function.....	12
Keyboard speaker.....	12
Adjust volume.....	12
SOS Button.....	13
EGPS.....	14
Call Logs.....	14
Making a call.....	14
Speaker.....	15
Call settings.....	15
Hang up the call.....	15
Mute the caller.....	16
Contact(PhoneBook).....	16
Add contact.....	16
Quickly search for contacts.....	17
Contact options.....	17
Speed dial with Photos.....	18
Message.....	18

1

[Easyfone Prime-A1 Pro User Manual and Quick Start Guide](#)

Comprehensive guide for the Easyfone Prime-A1 Pro senior flip phone, covering setup, essential features like SOS and GPS, call management, messaging, device settings, and troubleshooting tips.

lang:en score:31 filesize: 667.94 K page_count: 44 document date: 2022-12-09

Quick start guide	
English	
Contents	
Congratulations on your purchase.....	4
Get Started.....	6
Common function setting path.....	9
Shortcut Key.....	9
Insert SIM Card/Memory Card/Battery.....	10
Get to know your phone.....	11
Power ON and OFF.....	11
Start-UP wizard.....	11
Standby Mode.....	11
Flashlight.....	12
BLOCK button function.....	12
Keyboard speaker.....	12
Adjust volume.....	12
SOS Button.....	13
EGPS.....	14
Call Logs.....	14
Making a call.....	14
Speaker.....	15
Call settings.....	15
Hang up the call.....	15
Mute the caller.....	16
Contact(PhoneBook).....	16
Add contact.....	16
Quickly search for contacts.....	17
Contact options.....	17
Speed dial with Photos.....	18
Message.....	18

1

[Easyfone Prime-A1 Pro Quick Start Guide](#)

This document provides a quick start guide for the Easyfone Prime-A1 Pro unlocked senior cell phone, covering setup, basic functions, and features.

lang:en score:21 filesize: 7.54 M page_count: 45 document date: 0000-00-00

Quick start guide	
English	
Contents	
Congratulations on your purchase.....	4
Get Started.....	6
Common function setting path.....	9
Shortcut Key.....	9
Insert SIM Card/Memory Card/Battery.....	10
Get to know your phone.....	11
Power ON and OFF.....	11
Start-UP wizard.....	11
Standby Mode.....	11
Flashlight.....	12
BLOCK button function.....	12
Keyboard speaker.....	12
Adjust volume.....	12
SOS Button.....	13
EGPS.....	14
Call Logs.....	14
Making a call.....	14
Speaker.....	15
Call settings.....	15
Hang up the call.....	15
Mute the caller.....	16
Contact(PhoneBook).....	16
Add contact.....	16
Quickly search for contacts.....	17
Contact options.....	17
Speed dial with Photos.....	18
Message.....	18

1

[Easyfone Prime-A1 Pro 4G LTE Flip Phone: Quick Start Guide for Seniors](#)

Get started with your Easyfone Prime-A1 Pro 4G LTE flip phone for seniors. This quick start guide provides essential instructions on setup, features like the SOS button and charging dock, and basic operations for an easy mobile experience.

lang:en score:19 filesize: 8.01 M page_count: 45 document date: 2022-12-09



[\[pdf\]](#) Test Report

ELECTROMAGNETIC EMISSIONS COMPLIANCE REPORT fly XiTongTianDi Com test report Shen Zhen Yixun Electronic Technology Co Ltd PRIMEA1PRO Mobile Phone 2AQ8SPRIMEA1PRO primea1pro

Report No.: STR210915001002E FCC RADIO TEST REPORT FCC ID: 2AQ8SPRIMEA1PRO Product: Mobile Phone Trade Mark: Easyfone Model No.: Prime-A1 Pro Family Model: N/A Report No.: STR210915001002E Issue Date: Oct 26. 2021 Prepared for Shen Zhen Yixun Electronic Technology Co., Ltd. 14D, HuaqiaoXinyuan, Wanz...

lang:nl **score:16** filesize: 3.53 M page_count: 65 document date: 2021-11-06



[\[pdf\]](#) Test Report

ELECTROMAGNETIC EMISSIONS COMPLIANCE REPORT fly test report Shen Zhen Yixun Electronic Technology Co Ltd PRIMEA1PRO Mobile Phone 2AQ8SPRIMEA1PRO primea1pro

Report No.: STR210915001003E FCC RADIO TEST REPORT FCC ID: 2AQ8SPRIMEA1PRO Product: Mobile Phone Trade Mark: Easyfone Model No.: Prime-A1 Pro Family Model: N/A Report No.: STR210915001003E Issue Date: Oct 26. 2021 Prepared for Shen Zhen Yixun Electronic Technology Co., Ltd. 14D, HuaqiaoXinyuan, Wanz...

lang:nl **score:16** filesize: 816.13 K page_count: 42 document date: 2021-11-09




[\[pdf\]](#) Test Report

ELECTROMAGNETIC EMISSIONS COMPLIANCE REPORT fly test report Shen Zhen Yixun Electronic Technology Co Ltd PRIMEA1PRO Mobile Phone 2AQ8SPRIMEA1PRO primea1pro

Report No.: STR210915001001E RADIO TEST REPORT FCC ID: 2AQ8SPRIMEA1PRO Product: Mobile Phone Trade Mark: Easyfone Model No.: Prime-A1 Pro Family Model: N/A Report No.: STR210915001001E Issue Date: Oct 26. 2021 Prepared for Shen Zhen Yixun Electronic Technology Co., Ltd. 14D, HuaqiaoXinyuan, Wanzhon...

lang:nl **score:16** filesize: 4.93 M page_count: 78 document date: 2021-11-06



[\[pdf\]](#) Test Report

Randy He test report Shen Zhen Yixun Electronic Technology Co Ltd PRIMEA1PRO Mobile Phone 2AQ8SPRIMEA1PRO primea1pro

Report No.: STR210915001004E FCC CFR47 PART 24E, 27 CERTIFICATION TEST REPORT FCC ID: 2AQ8SPRIMEA1PRO Product Mobile Phone Trade Mark Easyfone Model Number Prime-A1 Pro Family Model N/A Report No. STR210915001004E Prepared for Shen Zhen Yixun Electronic Technology Co., Ltd. 14D, HuaqiaoXinyuan, Wanz...

lang:en **score:15** filesize: 1.02 M page_count: 39 document date: 2021-11-12

[\[pdf\]](#) SAR Rating

Measurement Report Kent RF exposure Shen Zhen Yixun Electronic Technology Co Ltd PRIMEA1PRO
Mobile Phone 2AQ8SPRIMEA1PRO primea1pro

Page 1 of 137 Report No.: STR210915001005E FCC SAR EVALUATION REPORT In
accordance with the requirements of FCC 47 CFR Part 2 2.1093 , ANSI/IEEE C95.1-
1992 and IEEE Std 1528-2013 Product Name Mobile Phone Trademark Easyfone
Model Name Prime-A1 Pro Family Model N/A Report No. STR210915001005E FCC
I...

lang:en **score:13** filesize: 4.26 M page_count: 100 document date: 2021-11-12