



Manuals.plus /

› Lovehoney /

› Lovehoney Purple Power Mini Massage Wand Kit Instruction Manual

Lovehoney Power Mini Wand

Lovehoney Purple Power Mini Massage Wand Kit

Instruction Manual

1. PRODUCT OVERVIEW

The Lovehoney Purple Power Mini Massage Wand Kit is a compact, rechargeable personal massager designed for versatile use. It features a mini wand with multiple vibration patterns and intensity levels, accompanied by two interchangeable silicone attachments for targeted stimulation. The kit is splash-proof and includes a convenient travel case.



Image 1.1: The Lovehoney Purple Power Mini Massage Wand, showing the main wand unit and two silicone attachments.

2. WHAT'S INCLUDED

Your Lovehoney Purple Power Mini Massage Wand Kit includes the following items:

- 1 x Purple Power Mini Massage Wand
- 1 x Butterfly Attachment (for external stimulation)
- 1 x G-spot Attachment (for internal stimulation)
- 1 x USB Charging Cable
- 1 x Zip Travel Case



Image 2.1: All components included in the kit: the purple wand, two black silicone attachments, and a USB cable.

3. SETUP AND INITIAL CHARGE

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Charge:** Before first use, fully charge the massage wand.
 - Connect the small end of the provided USB charging cable to the charging port on the wand.
 - Connect the larger end of the USB cable to a standard USB power source (e.g., computer USB port, USB wall adapter).
 - The indicator light on the wand will illuminate during charging and typically change or turn off when fully charged. Refer to the product for specific light behavior.
 - A full charge provides approximately 60 minutes of run time.



Image 3.1: The purple massage wand shown with its USB charging cable connected, illustrating the charging process.

4. OPERATING INSTRUCTIONS

1. **Power On/Off:** Press and hold the power button (usually marked with a circle or a specific symbol) for a few seconds to turn the wand on or off.
2. **Adjust Vibration Patterns:** Once powered on, press the wave button (often marked with a wavy line or 'M') to cycle through the 7 available vibration patterns.
3. **Adjust Intensity Levels:** Use the '+' and '-' buttons to increase or decrease the vibration intensity. There are 10 different intensity levels.
4. **Using Attachments:**
 - To attach, gently push the desired silicone attachment onto the head of the wand until it is securely seated.
 - To remove, gently pull the attachment off the wand head.
 - Always ensure attachments are clean and dry before and after use.

5. **Lubrication:** For optimal comfort and experience, always use a water-based lubricant with the wand and its attachments.



Image 4.1: A hand demonstrating how to hold the massage wand with an attachment, highlighting the control buttons.

5. ATTACHMENTS GUIDE

The kit includes two distinct silicone attachments designed for different types of stimulation:

- **Butterfly Attachment:** This attachment is designed for external stimulation. Its shape allows for broad or precise contact.
- **G-spot Attachment:** This attachment is curved and designed for internal stimulation.

Important Safety Note:

- The main wand unit is for external use only.
- The wand unit itself is not designed for anal use.

- Only the G-spot attachment is suitable for internal use.



Image 5.1: The massage wand fitted with the butterfly attachment for external use.




Image 5.2: The massage wand fitted with the G-spot attachment for internal use.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your massage wand and ensure hygienic use.

1. Cleaning After Each Use:

- Disconnect the wand from any charging cable.
- Clean the wand and attachments thoroughly with warm water and a mild, toy-safe soap or a specialized toy cleaner.
- Rinse thoroughly to remove all soap residue.
- Dry completely with a lint-free cloth or allow to air dry before storing.

2. **Water Resistance:** The wand is splash-proof, meaning it can withstand splashes of water. It is **not** designed to be fully submerged in water. Avoid submerging the wand to prevent damage.

3. **Material Care:** The wand and attachments are made of silicone. Avoid using cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone material.

7. STORAGE

Store your Lovehoney Purple Power Mini Massage Wand Kit in a clean, dry, and cool place, away from direct sunlight and extreme temperatures.

- Use the provided zip travel case for discreet and protected storage.
- Keep the wand and attachments separate from other toys made of different materials to prevent material degradation.



Image 7.1: The black zip travel case provided with the kit, ideal for storage and transport.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Wand does not turn on.	Battery is depleted.	Charge the wand fully using the provided USB cable. Ensure the charging cable is properly connected to both the wand and a power source.
Wand vibrations are weak or inconsistent.	Low battery.	Recharge the wand.
Wand does not charge.	Faulty cable or power source.	Try a different USB cable or a different USB power source. Ensure the charging port on the wand is clean and free of debris.
Attachments do not fit securely.	Incorrect attachment orientation or debris.	Ensure the attachment is aligned correctly with the wand head. Check for any debris preventing a secure fit.

9. SPECIFICATIONS

Model Name:	Power Mini Wand
Brand:	Lovehoney
Material:	Silicone
Color:	Purple, Black
Product Dimensions:	10.63 x 4.72 x 2.36 inches
Weight:	15.2 ounces
Battery:	1 Product Specific battery (included)
Run Time:	Approximately 60 minutes (fully charged)
Vibration Functions:	7 patterns
Intensity Levels:	10 levels
Water Resistance:	Splash-proof

10. SAFETY INFORMATION

Please read and adhere to the following safety guidelines for safe and enjoyable use of your massage wand:

- This product is intended for adult use only.
- The main wand unit is for external use only. Only the G-spot attachment is suitable for internal use.
- Do not use the wand for anal stimulation.
- Always use a water-based lubricant with the wand and its attachments. Oil-based lubricants can damage silicone.
- Discontinue use immediately if you experience any discomfort, pain, or irritation. Consult a healthcare professional if symptoms persist.
- Do not use the product if it appears damaged or defective.
- Keep out of reach of children.
- Do not expose the product to extreme temperatures, direct sunlight, or corrosive liquids.
- The product is splash-proof, not waterproof. Do not submerge in water.

11. WARRANTY AND SUPPORT

Information regarding product warranty and customer support is typically provided by the manufacturer or retailer at the time of purchase. Please refer to the packaging, the Lovehoney official website, or your purchase receipt for details on warranty coverage and how to contact customer support for assistance with your Lovehoney Purple Power Mini Massage Wand Kit.

For further assistance, you may visit the Lovehoney Store on Amazon.

