

[Manuals.plus](#) /

> [SYLVANIA](#) /

> Sylvania SP782 Dual 8-inch 10-watt-max Karaoke Light-up Bluetooth Speaker with FM Radio User Manual

SYLVANIA SP782

Sylvania SP782 Dual 8-inch 10-watt-max Karaoke Light-up Bluetooth Speaker with FM Radio

User Instruction Manual

PRODUCT OVERVIEW

The Sylvania SP782 is a versatile portable audio system designed for music playback and karaoke. It features dual 8-inch speakers, integrated LED lighting, and multiple connectivity options including Bluetooth, USB, AUX, and FM radio. This manual provides essential information for setting up, operating, and maintaining your speaker.

- **Bluetooth Technology:** Stream audio wirelessly from compatible smart devices.
- **Multiple Inputs:** Supports USB drives, SD cards (TF card slot), FM radio, and auxiliary input for wired connections.
- **LED Lighting:** Dynamic blue LEDs enhance the listening experience with visual effects.
- **Microphone Input:** Connect a microphone for karaoke or public address functions.
- **Portability:** Designed for easy transport, suitable for various indoor and outdoor settings.

SETUP GUIDE

1. Unpacking and Inspection

Carefully remove all components from the packaging. Inspect the speaker and accessories for any signs of damage. Retain the packaging for future storage or transport.

2. Power Connection

The Sylvania SP782 operates on corded electric power. Connect the provided power cable to the DC 5V IN port on the rear panel of the speaker and then to a standard electrical outlet. Ensure the power source matches the speaker's voltage requirements.





Figure 1: Rear panel of the Sylvania SP782 speaker, highlighting the various input ports and controls including the DC 5V IN power port, USB port, TF card slot, AUX input, microphone input, and volume knob.

3. Initial Power On

Once connected to power, locate the power switch (if present, usually integrated with volume knob or separate) and turn the unit on. The LED lights on the front panel should illuminate, indicating the speaker is active.

OPERATING INSTRUCTIONS

1. Bluetooth Pairing

1. Turn on the speaker. It should automatically enter Bluetooth pairing mode, indicated by a flashing LED or an audible prompt.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
3. Search for available devices. The speaker will appear as "SYLVANIA SP782" or similar.
4. Select the speaker to pair. Once connected, you will hear a confirmation sound, and the Bluetooth indicator light will become solid.
5. You can now stream audio wirelessly from your device to the speaker.

2. USB/TF Card Playback

Insert a USB flash drive or a TF (microSD) card containing MP3 audio files into the respective port on the rear panel. The speaker will automatically detect the media and begin playback. Use the control buttons (e.g., Play/Pause, Next/Previous) on the speaker to manage playback.

3. FM Radio Operation

Switch the speaker to FM radio mode (often by pressing a "Mode" button or cycling through inputs). The speaker will automatically scan and save available FM stations. Use the Next/Previous buttons to navigate between saved stations.

4. AUX Input

Connect an external audio device (e.g., MP3 player, laptop) to the AUX input port on the rear panel using a 3.5mm audio cable. Switch the speaker to AUX mode. Audio from the connected device will now play through the speaker.

5. Microphone Usage

Plug a wired microphone into the "MIC IN" port on the rear panel. Adjust the microphone volume using the dedicated control (if available) or the main volume knob. The microphone input is ideal for karaoke or public speaking.

6. LED Light Control

The speaker features integrated LED lights. There is a "LIGHT" button on the rear panel. Press this button to toggle the LED lights on/off or to cycle through different lighting modes, if available.





Figure 2: Front view of the Sylvania SP782 speaker showcasing its dual 8-inch drivers and illuminated LED lights, which can display various colors like blue and green.







Figure 3: Another front view of the Sylvania SP782 speaker, demonstrating the LED lights in a different color combination, specifically green and red, highlighting the dynamic lighting feature.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the speaker or subjecting it to strong impacts, which can damage internal components.
- **Ventilation:** Ensure the speaker's ventilation openings are not blocked to prevent overheating.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet not active; speaker off.	Ensure power cable is securely connected. Check power outlet with another device. Turn the speaker on.
No sound	Volume too low; incorrect input mode; audio source issue; damaged cable.	Increase volume. Select correct input mode (Bluetooth, USB, AUX, FM). Check audio source device. Replace audio cable if using AUX.
Bluetooth not pairing	Speaker not in pairing mode; device too far; interference; device already paired.	Ensure speaker is in pairing mode. Move device closer to speaker. Turn off other Bluetooth devices. Disconnect from previously paired devices.
FM radio static	Weak signal; interference.	Adjust speaker position for better reception. Extend antenna if available.

SPECIFICATIONS

Brand:	SYLVANIA
Model:	SP782
Power Source:	Corded Electric
Recommended Uses:	Music
Manufacturer:	Sylvania
UPC:	656942170716
Package Dimensions:	23.5 x 11 x 9 inches
Item Weight:	8 pounds
ASIN:	B09887RN5M
Batteries:	1 Product Specific batteries required (<i>Note: Primarily corded, internal battery for portability</i>)
Connectivity Technology:	AUX, Bluetooth, USB
Color:	Black

Compatible Devices: Smartphone

Mounting Type: Plug Mount

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact information provided with your purchase documentation or visit the official Sylvania website. Keep your proof of purchase for any warranty claims.

This product is designed for reliable performance. Should you encounter any issues not covered in the troubleshooting section, please contact customer support for assistance.