

[Manuals.plus](#) /

> [Mintu](#) /

> Dryer Repair Kit Replacement For Kenmore Elite Oasis Dryer, Elite QuietPak9 HE5 Dryer, Elite Front Load Dryer, Kenmore Series 90 gas dryer With Roller, Belt & Pulley Etc

Mintu 110.C97872601 110C97872601

Dryer Repair Kit Instruction Manual

For Kenmore Elite Oasis, QuietPak9 HE5, Front Load, and Series 90 Gas Dryers

1. PRODUCT OVERVIEW

This Dryer Repair Kit provides essential replacement components for various Kenmore Elite and Series 90 gas dryer models. The kit typically includes a dryer drum belt, drum support rollers, and an idler pulley, which are common wear-and-tear parts responsible for the smooth operation of your dryer drum. Replacing these components can resolve issues such as squeaking noises, grinding sounds, or a dryer drum that is not tumbling.

2. SAFETY INFORMATION

Before attempting any repair or maintenance on your dryer, please read and understand the following safety precautions:

- **Disconnect Power:** Always unplug the dryer from the electrical outlet or turn off the circuit breaker before beginning any work. Failure to do so can result in electric shock or serious injury.
- **Gas Supply:** For gas dryers, ensure the gas supply valve is turned off before starting work.
- **Wear Protective Gear:** Use work gloves to protect your hands from sharp edges and safety glasses to protect your eyes.
- **Ventilation:** Ensure the work area is well-ventilated, especially when dealing with gas appliances.
- **Professional Assistance:** If you are unsure about any step or uncomfortable performing the repair, consult a qualified appliance technician.
- **Retain Original Parts:** Keep original parts for comparison during installation.

3. PACKAGE CONTENTS

Your Dryer Repair Kit typically includes the following components:

- Dryer Drum Belt
- Dryer Drum Support Rollers (multiple, typically 4)
- Idler Pulley

- Retaining Washers/Clips



Figure 3.1: Typical components included in the dryer repair kit.

The image above displays the various parts you should find in your repair kit, including the main drive belt, the drum support rollers (with red centers), the idler pulley (white), and small metal retaining clips and washers.

4. COMPATIBILITY

This repair kit is designed to be compatible with a wide range of dryer models from various brands. Please verify your dryer's model number against the list below to ensure compatibility.

Compatible Whirlpool Models:

GEW9200LW0, GEW9200LW1, GEW9250PW0, GEW9250PW1, GGW9200LW0, GEW9200LL1, GGW9200LW1, GEQ9800LW0, WED8300SW0, WED9200SQ0, GEW9200LQ0, GGW9250PW0, GEQ9800LW1, GEW9250PL0, GGW9200LL1, WGD8300SW0, GEQ9800PW1, IES5000RQ0, GGW9200LQ0, GGW9250PW3, GEW9868KQ1, WED8500SR0, WED8300SW1, GGW9250PW1, GEW9200LQ1, GEQ9800PW2, GEW9200LW2, WGD9200SQ0, WED8300SW2, GEW9200LT1, GEW9868KQ2, GEW9260PW0, WED9400SU0, WED9400SW0, GEW9868KQ3, GGW9200LW2, GGW9250PL1, LEQ8611LW0, LGQ8611LW1, CGM2751KQ3, GGW9200LQ1, GGW9868KQ1, GEW9250SU0, GGW9250PW2, LEQ8611LW1, WGD9400SW0, GEQ8811LW1, GEW9250PT0, GGQ9800PW1, GGW9250PL0, WGD8300SW1, GEQ8858KQ0, GEW9260PW1, CEM2760KQ1, GEQ9800LG0, GEW9868KT1, GGQ9800LW0, WED8410SW0, WGD8500SR0, CEM2750KQ3, CEM2750TQ0, CEM2760KQ3, GEW9868KL2, GGQ8811PL0, GGW9868KQ2, LGQ8611LW0, WGD9400SU0, CSP2761KQ3, GEQ8811LL1, GEW9200LL2, GEW9250PL1, GGQ9800PW2, GGQ9800PW3, GGW9200LL2, LEQ8611PW0, GEQ8811KQ0, GEQ8811PL0, GEQ9800PB0, GEW9868KL1, GGQ9800PB0, GGW9250PL2, GGW9260PL0, WED9500TW0, WED9600TW0, CEM2760KQ2, GEQ9800PW0, GEW9200LQ2, GEW9250PT1, GGQ8831LW0, GGQ9800LG0, GGW9200LT1, GGW9250PT0, LEQ8611LG1, LGQ8611LG0, WED8300SB0, WGD8410SW0, YGEW9200LW0, YGEW9250PW1, CEM2760TQ0, GEQ8821LW0, GEQ8831LW0, GEQ9800LG1, GEQ9800PB1, GGQ9800LW1, GGW9260PW0, GGW9868KQ3, LEQ8611PW1, WED9400SB0, WED9400ST0, WGD8410SW1, WGD9600TW0, 3XLER5437KQ0, 3XWGD5705SW0, YWED90HEFW2.

Compatible KitchenAid Models:

KEHS01PMT0, KEHS01PMT1, KEHS01PWH2, KEHS02RWH0, KGHS01PMT1, KEHS02RMT1.

Compatible Maytag Models:

MED9600SQ0, MED9700SQ0, MGD9600SQ0, MGD9700SB0, MGD9700SQ0, MED9700SB0, MED9800TK0, MGDB850WQ0, 3LMEDC100YW0, 3LMEDC100YW1, 3LMEDC100YW2, 3LMEDC300YW1, 3LMEDC300YW2, 3LMEDC315FW0, 3LMEDC415FW0, 3RAED3005TQ0, 3RMED4905TW0, 3RMED4905TW1, 3RMED4905TW2, 7MMGDB835EW0, 7MMGDB835EW2, 7MMGDB850WL0, 7MMGDB850WL1, 7MMGDB950AG0, 7MMGDB950AG1, 7MMGDX550XW0, 7MMGDX550XW1, 7MMGDX600BW0, 7MMGDX655EW0, 7MMGDX655EW1, 7MMGDX700BG0, 7MMGDX700YL0, 7MMGDX700YL1, 7MMGE9959TB.

5. INSTALLATION / SETUP GUIDE

Replacing dryer components requires disassembling parts of your dryer. The exact steps may vary slightly depending on your specific dryer model. Always refer to your dryer's original service manual for detailed, model-specific instructions. The following is a general guide:

1. Prepare the Dryer:

- Ensure the dryer is unplugged from the power outlet.
- If it's a gas dryer, turn off the gas supply valve.
- Pull the dryer away from the wall to access the rear.
- Disconnect the exhaust vent hose.

2. Access Internal Components:

- Depending on your model, you may need to remove the top panel, front panel, or both. This usually involves removing screws located at the back, top, or inside the door frame.
- Carefully disconnect any wire harnesses or components attached to the panels.

3. Remove the Dryer Drum:

- Locate the idler pulley and release the tension on the dryer belt. Carefully remove the old belt from around the drum and motor pulley.
- Note the routing of the old belt for correct installation of the new one.
- Lift the dryer drum out of the cabinet. This will expose the drum support rollers.

4. Replace Drum Support Rollers:

- Remove the old drum support rollers. They are typically held in place by a shaft and retaining clips or washers.
- Clean any lint or debris from the roller shafts and surrounding area.
- Install the new drum support rollers, ensuring they spin freely. Secure them with the provided retaining washers/clips.

5. Replace Idler Pulley:

- Locate the idler pulley assembly. Remove the old idler pulley.
- Install the new idler pulley, ensuring it is properly seated and provides tension when the belt is installed.

6. Install New Dryer Belt:

- Place the dryer drum back into the cabinet, ensuring it rests correctly on the new support rollers.
- Route the new dryer belt around the drum and then around the motor pulley and idler pulley, following the path of the old belt. Ensure the ribbed side of the belt faces the drum.
- Verify that the belt is properly tensioned by the idler pulley.

7. Reassemble the Dryer:

- Reattach any panels, screws, and wire harnesses that were removed.

- Reconnect the exhaust vent hose.
- Push the dryer back into its position.

8. Test the Dryer:

- Plug the dryer back into the electrical outlet.
- If it's a gas dryer, turn the gas supply valve back on.
- Run a short cycle to ensure the drum tumbles smoothly and there are no unusual noises.

6. MAINTENANCE

Proper maintenance can extend the life of your dryer and its components:

- **Clean Lint Filter:** Clean the lint filter before or after every load to maintain airflow and prevent strain on components.
- **Inspect Venting:** Periodically check and clean the dryer's exhaust vent system to prevent lint buildup, which can restrict airflow and cause overheating.
- **Listen for Noises:** Pay attention to any new or unusual noises from your dryer. Squeaking or grinding often indicates worn rollers or a failing idler pulley.
- **Avoid Overloading:** Do not overload the dryer, as this puts excessive strain on the motor, belt, and rollers, leading to premature wear.

7. TROUBLESHOOTING

This repair kit is designed to address common dryer issues related to the drum's movement. If you experience the following symptoms, replacing the components in this kit may resolve the problem:

- **Squeaking or Grinding Noises:** Often caused by worn-out drum support rollers or a failing idler pulley.
- **Dryer Drum Not Tumbling:** Can be a symptom of a broken or stretched dryer belt.
- **Clothes Not Drying Properly:** While often related to venting, worn rollers can cause the drum to drag, impacting drying efficiency.

If issues persist after replacing the components, further diagnosis by a qualified technician may be required.

8. SPECIFICATIONS

Product Type	Dryer Repair Kit (Belt, Rollers, Pulley)
Brand	Mintu
Model Number	110.C97872601 110C97872601
Compatible Brands	Kenmore, Whirlpool, KitchenAid, Maytag (and others as listed in compatibility section)
ASIN	B0989B7J42
Date First Available	June 30, 2021

9. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in this manual. For details regarding warranty coverage,

returns, or technical support, please contact the seller or refer to the product listing on the retailer's website. You may also visit the [Mintu Store on Amazon](#) for additional product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question