

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Remington](#) /

› [Remington Supercare Pro 2200 AC Hairdryer AC7200 Instruction Manual](#)

## Remington AC7200

# Remington Supercare Pro 2200 AC Hairdryer - Instruction Manual

Model: AC7200

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using your Remington Supercare Pro 2200 AC Hairdryer. Keep this manual for future reference.

- **Water and Moisture:** Avoid using this appliance near water or in wet areas, such as bathrooms or near sinks. Do not immerse the appliance in water or any other liquid.
- **High Temperatures:** Do not use high temperatures for extended periods, as this may cause damage to hair or the appliance.
- **Filter Maintenance:** Regularly clean the rear filter to prevent overheating and maintain optimal performance.
- **Children:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Power Cord:** Always inspect the power cord for damage before use. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
- **Storage:** Always allow the appliance to cool down before storing. Do not wrap the cord around the appliance.

## 2. PRODUCT OVERVIEW

The Remington Supercare Pro 2200 AC Hairdryer is designed for efficient and powerful hair drying and styling. It features a durable AC motor and multiple settings to suit various hair types and styling needs.



This image displays the Remington Supercare Pro 2200 AC Hairdryer along with its included styling accessories: two concentrator nozzles for precise airflow and a diffuser for enhancing natural curls and waves.



A detailed view of the hairdryer, highlighting its ergonomic design, power cord loop, and the control buttons for heat and speed settings located on the handle.

### Key Features:

- **Powerful 2200W AC Motor:** For fast and efficient drying.
- **3 Heat Settings:** Cold, regulated, and hot for versatile styling.
- **2 Speed Settings:** Low and high airflow control.
- **Cool Shot Function:** To set your style.
- **Included Accessories:** Two concentrator nozzles and a diffuser.

### 3. SETUP

1. **Unpacking:** Carefully remove the hairdryer and all accessories from the packaging. Retain the packaging for storage or future transport.

2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Attach Accessories:**
  - **Concentrators:** For precise drying and styling, attach one of the concentrator nozzles to the front of the hairdryer by pushing it firmly into place.
  - **Diffuser:** For enhancing natural curls and adding volume, attach the diffuser by aligning it with the front of the hairdryer and twisting gently until it locks.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet. Ensure your mains voltage matches the voltage specified on the appliance.

## 4. OPERATING INSTRUCTIONS

Familiarize yourself with the controls on the handle of your hairdryer before use.

1. **Power On/Off:** Use the main power switch to turn the hairdryer on or off.
2. **Speed Settings:** The hairdryer has two speed settings. Select the desired airflow speed using the speed control switch:
  - **Low Speed:** For gentle drying or styling.
  - **High Speed:** For fast drying.
3. **Heat Settings:** The hairdryer offers three heat settings. Adjust the temperature using the heat control switch:
  - **Cold:** For a cool airflow, ideal for setting styles.
  - **Regulated (Warm):** For normal drying and styling.
  - **Hot:** For fast drying and more intense styling.
4. **Cool Shot Function:** Press and hold the 'Cool Shot' button to instantly deliver a burst of cool air. This helps to set your style and add shine. Release the button to return to the previously selected heat setting.
5. **Drying and Styling:** Direct the airflow towards your hair, maintaining a safe distance to avoid overheating. Use the concentrator for targeted drying or the diffuser for gentle drying of curls.
6. **Finishing:** Once styling is complete, switch off the hairdryer and unplug it from the power outlet.

## 5. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your hairdryer.

1. **Unplug Before Cleaning:** Always ensure the hairdryer is switched off and unplugged from the mains before cleaning.
2. **Clean the Rear Filter:** The rear filter prevents hair and dust from entering the motor. It should be cleaned regularly (e.g., weekly or bi-weekly depending on usage).
  - Grip the rear filter cover and twist or pull it off (refer to product diagram if unsure).
  - Use a soft brush or a dry cloth to remove any accumulated dust or hair from the filter mesh.
  - Replace the filter cover by aligning it and twisting or pushing it back into place until secure.
3. **Clean the Appliance Body:** Wipe the exterior of the hairdryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. **Storage:** Allow the hairdryer to cool completely before storing. Store it in a dry place, away from moisture. Do not wrap the power cord tightly around the appliance, as this can damage the cord. Use the hanging loop for convenient storage.

## 6. TROUBLESHOOTING

If you encounter any issues with your Remington Supercare Pro 2200 AC Hairdryer, please refer to the following common problems and solutions:

- **Hairdryer does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the power switch is in the 'ON' position.
  - Verify that the electrical outlet is functional by testing it with another appliance.
- **Low airflow or overheating:**
  - The most common cause is a blocked rear filter. Refer to the 'Maintenance and Cleaning' section to clean the filter.
  - Ensure there are no obstructions in the air intake or outlet.
  - The hairdryer may have an automatic overheat protection feature. If it shuts off, unplug it, allow it to cool down for a few minutes, and clean the filter before restarting.
- **Unusual noise or smell:**
  - Immediately turn off and unplug the hairdryer.
  - Check the rear filter for any foreign objects.
  - If the issue persists, discontinue use and contact customer support.

If the problem is not resolved by the above steps, please contact Remington customer support for further assistance.

## 7. SPECIFICATIONS

Feature	Specification
Model Number	AC7200
Power	2200 Watts
Motor Type	AC Motor
Number of Speeds	2
Number of Heat Settings	3 (Cold, Regulated, Hot)
Special Feature	Cool Shot Function
Material	Plastic, Rubber
Dimensions (L x W x H)	10 x 5 x 1.27 cm (approximate body dimensions)
Weight	1.1 kilograms
Included Components	Hairdryer, 2 Concentrators, 1 Diffuser

# 199.5mm



# 287.5mm

This image illustrates the physical dimensions of the hairdryer, showing a length of 199.5mm and a height of 287.5mm, providing an understanding of its size.

## 8. WARRANTY AND SUPPORT INFORMATION

Your Remington Supercare Pro 2200 AC Hairdryer comes with a **5-year warranty** from the date of purchase, covering manufacturing defects under normal use.

For warranty claims, technical support, or any other inquiries, please contact Remington customer service. You can usually find contact details on the official Remington website or on your product packaging.

Please retain your proof of purchase for warranty validation.