

[manuals.plus](#) /› [TFA](#) /› **TFA Dostmann Time & Light 60.2029.10 Alarm Clock and Night Light User Manual****TFA 60.2029.10**

TFA Dostmann Time & Light 60.2029.10 Alarm Clock and Night Light User Manual

Model: 60.2029.10

INTRODUCTION

Thank you for choosing the TFA Dostmann Time & Light 60.2029.10 Alarm Clock and Night Light. This device combines a digital alarm clock with a versatile night light, designed for convenience and ease of use. Please read this manual carefully to ensure proper operation and to fully utilize all features of your new device.



Image: The TFA Dostmann Time & Light 60.2029.10 Alarm Clock and Night Light. This grey cylindrical device features a slanted top surface that illuminates, functioning as both a clock and a night light.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Keep the device away from water and other liquids.
- Use only the provided or a certified micro USB cable for charging.

PACKAGE CONTENTS

Please check that all items are present in your package:

- TFA Dostmann Time & Light 60.2029.10 Alarm Clock and Night Light
- Micro USB Charging Cable
- User Manual

PRODUCT OVERVIEW

The device features a clear digital display and intuitive controls on its top surface.



Image: Close-up view of the TFA Dostmann Time & Light 60.2029.10 alarm clock display and control buttons. This image shows the top surface of the alarm clock with its digital display indicating time and alarm icons. Surrounding the display are control buttons for time setting, alarm setting, brightness adjustment, and volume.

Key Features:

- **Digital Alarm Clock:** Compact and practical with manual time setting, suitable for travel or as a digital table clock.
- **Night Light Function:** Simply flip the device to activate the night light with 7 adjustable brightness levels.
- **Dual Alarms:** Features two distinct alarm settings.
- **Snooze Function:** Shake the alarm clock to activate a 5-minute snooze.
- **Display Illumination:** 3 brightness levels for the display, with an automatic night timer.
- **Rechargeable Battery:** Powered by a built-in rechargeable lithium-ion battery via micro USB, eliminating the need for disposable batteries.



Image: An illustrative image highlighting the key features of the alarm clock, including its dual alarm capability, precise quartz timekeeping, integrated night light function, and convenient USB rechargeable power source.

SETUP

1. Charging the Device

Before first use, fully charge the alarm clock. Connect the micro USB cable to the charging port on the device and the other end to a USB power adapter (not included) or a computer USB port. The charging indicator will show the charging status.

2. Setting the Time

1. Press and hold the **TIME SET** button (usually marked with a clock icon) until the hour digits begin to flash.
2. Use the + and - buttons to adjust the hour.
3. Press **TIME SET** again to switch to minute adjustment. Use + and - to set the minutes.
4. Press **TIME SET** once more to confirm and exit time setting mode.

OPERATING INSTRUCTIONS

1. Setting Alarms (Alarm 1 and Alarm 2)

The device supports two independent alarms.

1. Press and hold the **ALARM 1** button (often marked with a bell icon and '1') until the alarm hour digits flash.
2. Use the + and - buttons to set the desired alarm hour.
3. Press **ALARM 1** again to switch to minute adjustment. Use + and - to set the alarm minutes.
4. Press **ALARM 1** once more to confirm and activate Alarm 1. An alarm icon will appear on the display.
5. Repeat the process for **ALARM 2** using the corresponding button.

2. Activating/Deactivating Alarms

Briefly press the **ALARM 1** or **ALARM 2** button to toggle the respective alarm on or off. The alarm icon on the display indicates if it is active.

3. Snooze Function

When an alarm sounds, gently shake the device to activate the snooze function. The alarm will pause for approximately 5 minutes and then sound again. This can be repeated multiple times.

4. Using the Night Light

To activate the night light, simply flip the alarm clock over. The top surface will illuminate. You can adjust the brightness:

1. While the night light is active, press the **LIGHT** button (often marked with a sun icon) to cycle through 7 brightness levels.
2. Flip the device back to its original position to turn off the night light.

5. Adjusting Display Brightness

The main time display has 3 brightness levels and an automatic night timer.

1. Press the **BRIGHTNESS** button (often marked with a sun icon) to cycle through the 3 display brightness levels.
2. The automatic night timer will dim the display during nighttime hours for comfortable viewing.

MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the charging port is free of dust and debris.
- Store the device in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device using the micro USB cable.
Alarm does not sound.	Alarm is not activated.	Ensure the alarm icon is visible on the display. Activate the alarm by briefly pressing its button.
Night light does not work.	Device not flipped correctly.	Ensure the device is completely flipped over to activate the night light function.
Display is too dim/bright.	Brightness setting needs adjustment.	Press the BRIGHTNESS button to cycle through the 3 display brightness levels.

SPECIFICATIONS

Feature	Detail
Brand	TFA
Model Number	60.2029.10
Color	Grey
Dimensions (L x W x H)	11.5 x 3.81 x 9.3 cm
Weight	159 grams
Material	Plastic
Display Type	Digital
Power Source	Battery Powered (Rechargeable Lithium-ion)
Special Features	Alarm, Night Light Combination, Illuminated Display, Adjustable Brightness, Snooze Function, USB Rechargeable
Country of Origin	China

WARRANTY AND SUPPORT

This product comes with a 1-year availability of spare parts. For warranty claims or technical support, please refer to your purchase documentation or contact the retailer where the product was purchased. Keep your proof of purchase for warranty purposes.