

IKEA BAGGEBO Shelf Unit Instruction Manual

Model: 604.838.73

INTRODUCTION

This manual provides essential instructions for the assembly, safe use, and maintenance of your IKEA BAGGEBO Shelf Unit, model 604.838.73. Please read these instructions carefully before assembly and retain them for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: To prevent tipping, it is crucial to secure the shelf unit to the wall using the included wall-fixing devices. Failure to do so can result in serious injury.

Always ensure the unit is placed on a flat, stable surface. Do not overload shelves beyond the maximum weight capacity.

SETUP AND ASSEMBLY

The IKEA BAGGEBO Shelf Unit requires assembly. Please follow the steps below and refer to the included assembly diagram for visual guidance.

- Unpack Components:** Carefully unpack all parts and hardware from the packaging. Verify that all components are present according to the parts list (usually found in the separate assembly guide).
- Assemble Frame:** Connect the metal tubes to form the main frame structure. Ensure all connections are secure.
- Install Shelves:** Place the mesh shelves onto the designated supports within the frame.
- Wall Fixing:** Once assembled, position the shelf unit in its desired location. Using the provided wall-fixing hardware, securely attach the unit to a suitable wall. This step is mandatory for stability and safety.




Figure 1: Dimensional diagram of the IKEA BAGGEBO Shelf Unit, showing overall dimensions (60 cm width, 116 cm height, 25 cm depth) and internal shelf spacing. This diagram aids in understanding the unit's structure and space requirements.






Figure 2: Fully assembled IKEA BAGGEBO Shelf Unit in white, showcasing its metal frame and mesh shelves. This image provides a visual reference of the completed product.

USAGE AND OPERATION

The BAGGEBO Shelf Unit is designed for indoor storage of various items such as books, decorations, and small household goods. Distribute weight evenly across the shelves to maintain stability. Avoid placing heavy items on the top shelf if possible.

- **Weight Distribution:** Ensure items are distributed evenly to prevent imbalance.
- **Maximum Load:** Do not exceed the maximum load of 12 kg per shelf.
- **Placement:** Ideal for living rooms, bedrooms, or offices. Not recommended for outdoor use or in excessively humid environments.

CARE AND MAINTENANCE

Proper care will extend the life of your shelf unit.

- Cleaning:** Wipe the unit clean with a soft cloth dampened with a mild detergent. Avoid abrasive cleaners or harsh chemicals.
- Drying:** Dry thoroughly with a clean, dry cloth immediately after cleaning.
- Inspection:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit feels unstable or wobbly.	Not properly secured to the wall; loose fittings; uneven floor.	Ensure wall-fixing devices are correctly installed and tightened. Check all screws and retighten. Place on a level surface.
Difficulty during assembly.	Incorrect part orientation; missing steps.	Refer to the detailed assembly instructions provided with the product. Ensure parts are oriented correctly before tightening.
Missing parts.	Packaging error.	Contact IKEA customer support with your proof of purchase and model number.

PRODUCT SPECIFICATIONS

Brand: Ikea

Model Number: 604.838.73

Color: White

Product Dimensions (W x D x H): 60 cm x 25 cm x 116 cm (23.6 x 9.8 x 45.7 inches)

Maximum Load per Shelf: 12 kg (26.5 lbs)

Material: Steel (epoxy/polyester powder coating), Polypropylene plastic

Item Weight: Approximately 12 kg (26.5 lbs)

Assembly Required: Yes

Room Type: Kitchen (also suitable for living room, bedroom, office)

Mounting Type: Floor Mount (with mandatory wall-fixing)

WARRANTY INFORMATION

For detailed warranty information, please refer to the documentation provided at the time of purchase or visit the official IKEA website. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact IKEA customer service. You can find contact details on the official IKEA website or on your purchase receipt.

Online Resources: www.ikea.com

