

- Manuals.plus /
- › Hansgrohe /
- › Hansgrohe Vernis Blend M35 Kitchen Tap 210 User Manual

Hansgrohe 71870670

Hansgrohe Vernis Blend M35 Kitchen Tap 210 Instruction Manual

Model: 71870670 | Brand: Hansgrohe

INTRODUCTION

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of your Hansgrohe Vernis Blend M35 Kitchen Tap 210. This single-lever kitchen tap features a tall swivel spout and a matt black finish, designed for both functionality and aesthetic appeal in modern kitchen environments. Please read these instructions carefully before installation and use to ensure proper function and longevity of your product.



Figure 1: Overview of key features including AirPower, ComfortZone, Swivel Spout, Ceramic Cartridge, and Easy Installation.

SETUP AND INSTALLATION

The Hansgrohe Vernis Blend M35 Kitchen Tap is designed for straightforward installation. Ensure you have the necessary tools and follow local plumbing codes.

- **Minimum Tap Hole:** A minimum tap hole diameter of 35 mm is required for installation.
- **Connection Hoses:** The tap connects to standard angle valves using flexible G $\frac{3}{4}$ (DN15) connection hoses, which are certified for use with drinking water.
- **Swivel Area Adjustment:** The swivel area of the kitchen tap can be defined during installation to 110°, 150°, or 360° to best suit your sink configuration.



AirPower

Full volume. Less splashing

Figure 2: Illustration of the easy installation process for the kitchen tap.




Figure 3: Dimensional drawing for precise installation planning.

OPERATING INSTRUCTIONS

Your Hansgrohe Vernis Blend M35 Kitchen Tap is designed for user-friendly operation and enhanced comfort.

- **Water Flow and Temperature Control:** The ergonomically shaped single lever handle allows for precise adjustment of both water quantity and temperature. Move the handle up or down to control flow, and left or right to adjust temperature.
- **Swivel Spout:** The tall spout offers a generous ComfortZone 260, providing ample space between the spout and the sink basin for filling large containers. The spout can swivel up to 360°, offering maximum flexibility for various kitchen tasks.
- **AirPower Technology:** The tap incorporates Hansgrohe's AirPower technology, which enriches the water with air. This creates a fuller, softer water jet with significantly less splash, enhancing comfort and reducing water waste.



Easy Installation

Quick and easy to fit

Figure 4: The ComfortZone feature provides increased flexibility and space at the kitchen sink.



ComfortZone

More flexibility makes kitchen work easier

Figure 5: AirPower technology delivers a full water volume with reduced splashing.



Figure 6: The swivel spout offers enhanced flexibility for various tasks.

MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your Hansgrohe kitchen tap. The matt black surface finish is designed for easy care.

- **Cleaning:** Use only mild soap and water with a soft cloth for cleaning. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the matt black finish and internal components.
- **Ceramic Cartridge:** The tap features a high-quality, smooth-running ceramic mixer system designed for durability. No specific user maintenance is required for the cartridge itself.
- **Aerator Cleaning:** Periodically unscrew and clean the aerator at the tip of the spout to remove any mineral deposits that may affect water flow.
- **Finish Protection:** Regularly wipe the tap dry after use to prevent water spots and maintain the integrity of the matt black finish.

TROUBLESHOOTING

If you encounter issues with your kitchen tap, refer to the following common solutions:

Problem	Possible Cause	Solution
Low water flow	Clogged aerator or supply lines	Clean or replace the aerator. Check supply line filters for blockages.
Leaking from spout	Worn ceramic cartridge or seals	Contact Hansgrohe customer support for replacement parts or professional assistance.
Difficulty adjusting temperature	Issue with ceramic cartridge or water heater settings	Ensure water heater is functioning correctly. If problem persists, contact support.

For issues not listed here or if solutions do not resolve the problem, please contact Hansgrohe customer support.

SPECIFICATIONS

Brand	Hansgrohe
Model Number	71870670
Recommended Use	Kitchen
Mounting Type	Deck Mount
Hole Count	1
Finish Type	Matte
Colour	Matt Black
Material	Plastic (Handle Material: Plastic)
Handle Type	Lever
Spout Design	Swivel (110°, 150°, or 360° adjustable)
Spout Height	14.5 Centimeters
Spout Reach	24 Centimeters
Item Weight	1.46 Kilograms
Suitable for Continuous Flow Heaters	Yes

WARRANTY AND SUPPORT

Hansgrohe products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official Hansgrohe website.

Spare Parts Availability: Hansgrohe guarantees the availability of spare parts for up to 15 years after the discontinuation of a product range, ensuring long-term support for your tap.

For technical assistance, spare parts, or warranty claims, please contact Hansgrohe customer support through their

official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B098JHV8CS>

More documents and user manuals: <https://manuals.plus/>