**YEELIGHT YLYD01YL**

# YEELIGHT Rechargeable Motion Sensor Night Light

Model: YLYD01YL

## Introduction

Thank you for choosing the YEELIGHT Rechargeable Motion Sensor Night Light. This versatile lighting solution is designed to provide convenient and energy-efficient illumination in various indoor spaces. Featuring both motion and dusk-to-dawn sensors, it automatically lights your path when needed, ensuring safety and comfort. Its rechargeable battery and multiple installation options make it a flexible addition to any home.



Image: Four YEELIGHT Rechargeable Motion Sensor Night Lights, showcasing their compact, circular design with a central sensor and warm white glow.

## Key Features

- **Dual Sensor Technology:** Equipped with both a motion sensor and a dusk-to-dawn sensor, ensuring the light only activates when motion is detected in low-light conditions.
- **360° Soft Light:** Built-in 6 LED lights provide a wide, comfortable illumination angle, reducing harsh shadows.
- **Rechargeable Battery:** Features a built-in 750mAh battery, offering long standby time (up to 120 days) and convenient USB charging.
- **Multiple Installation Methods:** Easily installable via magnetic adsorption, 3M strong adhesive, or a hook-up option, allowing placement in various locations.
- **Sensitive Motion Detection:** Detects movement within 22 feet and a 120° angle, providing reliable activation.
- **Two Operating Modes:** Auto Mode (motion and light sensing) and Always On Mode for continuous illumination.




Image: A comparison showing the wide, 360-degree soft light distribution of the YEELIGHT product versus a narrower, 180-degree dim light from other products.





Image: Illustrations demonstrating three installation methods: magnetic attachment to a metal surface, adhesive mounting with 3M tape, and hanging with a hook.





Image: A split image showing the light sensing feature (only turns on in the dark) and motion-activated feature (no switch, hands-free operation).




Image: A diagram illustrating the motion sensor's detection range of up to 22 feet and a 120-degree sensing angle.





Image: A visual highlighting the rechargeable nature of the light, featuring a built-in 750mAh battery and a long standby time of 120 days.

## Package Contents

Please check the package contents carefully upon opening:

- YEELIGHT Rechargeable Motion Sensor Night Light (4 units)
- USB Charging Cable (4 units)
- 3M Adhesive Pads (4 units)
- User Manual

## Setup and Installation

The YEELIGHT Motion Sensor Night Light offers flexible installation options to suit various locations.

### Initial Charging

1. Before first use, fully charge the night light using the provided USB charging cable. Connect the cable to the light's charging port and a standard USB power adapter (not included).
2. The charging indicator light will show the charging status (e.g., red for charging, green for fully charged).

### Installation Methods

1. **Magnetic Adsorption:** The light has a built-in magnet. Simply attach it to any metallic surface, such as a refrigerator, metal cabinet, or magnetic strip.
2. **3M Strong Adhesive:** For non-metallic surfaces, peel off the protective film from one side of the 3M adhesive pad and stick it to the back of the night light. Then, peel off the other side and firmly press the light onto the desired clean, dry, and smooth surface (e.g., wall, wooden cabinet).
3. **Hook-up:** The light features a small loop or integrated hook. You can hang it on a hook, clothes hanger, or any suitable protrusion.




Image: A visual guide demonstrating the magnetic, 3M adhesive, and hook installation options for the night light.

## Operating Instructions

The YEELIGHT night light offers two primary operating modes:

- **Auto Mode (Motion & Light Sensing):** This is the default and most energy-efficient mode. The light will only turn on when motion is detected in a dark environment. If the ambient light is sufficient, the light will not activate, even if motion is present. The light will automatically turn off after approximately 15 seconds of no motion detection.
- **Always On Mode:** In this mode, the light remains continuously on, regardless of motion or ambient light conditions. This mode is suitable for situations where constant illumination is desired.

To switch between modes, locate the small switch or button on the side or back of the night light. Refer to the specific markings on your device for "Auto" and "On" positions.





Image: A visual representation of the two operating modes: Auto Mode (light activates with motion in darkness) and Always On Mode (light stays on continuously).

## Charging the Device

The YEELIGHT Motion Sensor Night Light is equipped with a rechargeable battery for long-term use. When the light output appears dim or the light stops activating, it's time to recharge.

1. Locate the micro-USB charging port on the side of the night light.
2. Connect the provided USB charging cable to the light and plug the other end into a USB power source (e.g., computer USB port, wall adapter, power bank).
3. A charging indicator light will illuminate (typically red) to show that the device is charging.

4. Once fully charged, the indicator light will change color (typically green or turn off). Disconnect the charging cable.

A full charge typically provides up to 120 days of standby time in Auto Mode, depending on usage frequency.




Image: A comparison highlighting the convenience of USB charging for the YEELIGHT light versus traditional battery replacement in other devices.

## Maintenance

To ensure the longevity and optimal performance of your YEELIGHT Motion Sensor Night Light, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface of the light with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or internal components.
- **Water Exposure:** This product is designed for indoor use and is not waterproof. Avoid exposing it to water, high humidity, or direct rain.
- **Storage:** If storing the light for an extended period, ensure it is fully charged and store it in a cool, dry place away from direct sunlight. Recharge it periodically (e.g., every 3-6 months) to maintain battery health.
- **Sensor Care:** Keep the motion sensor lens clean and unobstructed to ensure accurate detection.

## Troubleshooting

If you encounter any issues with your YEELIGHT Motion Sensor Night Light, please refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
| --- | --- | --- |
| Light does not turn on. | ◦ Battery is depleted.<br>◦ Insufficient darkness (in Auto Mode).<br>◦ No motion detected (in Auto Mode).<br>◦ Sensor obstructed.<br>◦ Light is in "Off" position. | ◦ Charge the light fully.<br>◦ Ensure the environment is dark enough for the light sensor to activate.<br>◦ Move closer to the light or ensure motion is within detection range.<br>◦ Clear any obstructions from the sensor lens.<br>◦ Check the mode switch and set it to "Auto" or "On". |

| Problem | Possible Cause | Solution |
| --- | --- | --- |
| Light stays on continuously (in Auto Mode). | ◦ Light is in "Always On" mode.<br>◦ Constant motion detected.<br>◦ Sensor malfunction. | ◦ Switch the light to "Auto" mode.<br>◦ Ensure there is no continuous motion near the sensor.<br>◦ Contact customer support if the issue persists after checking modes and environment. |
| Motion sensor is not sensitive. | ◦ Sensor obstructed or dirty.<br>◦ Light placed too high or far from detection area. | ◦ Clean the sensor lens.<br>◦ Reposition the light to a lower height or closer to the desired detection path. |
| Battery life is shorter than expected. | ◦ Frequent activation.<br>◦ Operating in "Always On" mode.<br>◦ Battery degradation over time. | ◦ Reduce unnecessary activations by optimizing placement.<br>◦ Use "Auto Mode" for energy saving.<br>◦ Ensure full charges. If significantly degraded, consider replacement. |

## SPECIFICATIONS

| | |
| --- | --- |
| **Brand** | YEELIGHT |
| **Model Number** | YLYD01YL |
| **Color** | Warm White (4pc) |
| **Base Material** | Metal |
| **Shade Color** | White |
| **Special Feature** | Rechargeable, Motion Sensor, Dusk to Dawn Sensor |
| **Room Type** | Kitchen, Bathroom, Basement, Bedroom, Drawer, Stairs, Hallway |
| **Number of Light Sources** | 6 (LED) |
| **Connectivity Technology** | USB |
| **Mounting Type** | Tabletop, Magnetic, Adhesive, Hook |
| **Control Method** | Touch (for mode switch) |
| **Indoor/Outdoor Usage** | Indoor |
| **Water Resistance Level** | Not Water Resistant |
| **Voltage** | 12 Volts |
| **Item Weight** | 3.87 ounces |
| **Product Dimensions** | 10 x 2 x 2.7 inches |

| | |
|---|---|
| **Battery Capacity** | 750mAh (Built-in) |
| **Motion Detection Range** | Up to 22 feet (120° angle) |

## Warranty and Support

YEELIGHT products are manufactured to high-quality standards. For warranty information, technical support, or any inquiries regarding your product, please refer to the contact information provided on the product packaging or visit the official YEELIGHT website. Please retain your proof of purchase for warranty claims.
For further assistance, you may also contact the seller directly through the platform where the product was purchased.

© 2024 YEELIGHT. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question