

[Manuals.plus](#) /

› [Coucur](#) /

› Coucur BE1033 Wireless Earbuds User Manual

Coucur BE1033

Coucur BE1033 Wireless Earbuds User Manual

Model: BE1033 | Brand: Coucur

1. INTRODUCTION

Thank you for choosing the Coucur BE1033 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.1 connectivity, immersive sound, noise-cancelling microphone, and IP7 waterproof rating. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

Please check the package to ensure all items are present:

- Coucur BE1033 Wireless Earbuds (Left and Right)
- Portable Charging Case
- USB-C Charging Cable
- Silicone Ear Tips (S, M, L sizes)
- User Manual




Image: Contents of the Coucur BE1033 Wireless Earbuds package, including the earbuds, charging case, USB-C cable, and various sizes of ear tips.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Coucur BE1033 Wireless Earbuds.

3.1 Earbuds

- **Multi-function Button:** Controls playback, calls, and voice assistant.
- **LED Indicator:** Shows pairing status, charging status, and power.
- **Microphone:** For calls and voice commands.
- **Charging Contacts:** For charging in the case.
- **Detachable Earhooks:** Provide a secure and comfortable fit, especially during sports.

3.2 Charging Case

- **Earbud Charging Slots:** Securely holds and charges the earbuds.
- **Battery Indicator Lights:** Shows the charging case's battery level.
- **USB-C Charging Port:** For charging the case.



Image: The Coucur BE1033 Wireless Earbuds resting inside their open charging case, showcasing their design and the case's interior.



Image: A close-up view of the Coucur BE1033 Wireless Earbuds, highlighting their ergonomic design and detachable earhooks.

4. SETUP

4.1 Charging the Earbuds and Case

For first-time use, fully charge the earbuds and the charging case. The earbuds provide up to 6-7 hours of listening time, and the portable charging case extends this to 25 hours. The case takes approximately 1 hour to fully charge via USB-C.

1. Place the earbuds into the charging case. Ensure the charging contacts align.
2. Connect the USB-C cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer).
3. The indicator lights on the charging case will illuminate to show charging progress. Once fully charged, the lights will remain solid or turn off depending on the model.



Image: An illustration showing the USB-C fast charging port on the earbud case with indicator lights displaying charging levels (25%, 50%, 70%, 100%).

IP7 Waterproof



Image: A visual representation indicating the Coucur earbuds and their charging case provide up to 25 hours of total playtime, emphasizing long-lasting power.

4.2 Pairing with Your Device (One-Step Pairing)

The earbuds feature one-step pairing for quick and easy connection.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "BE1033" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear a confirmation tone, and the earbuds' LED indicators will turn off or flash slowly.
5. The earbuds will automatically reconnect to the last paired device when taken out of the case.



Image: A visual demonstrating the Bluetooth 5.1 pairing process, showing the earbuds in their case next to a smartphone with the Bluetooth settings open and 'BE1033' connected.



Image: An illustration depicting the fast pairing feature of the earbuds, showing them connecting seamlessly to a smartphone with musical notes and instruments in the background.

4.3 Wearing the Earbuds

For optimal sound quality and comfort, choose the correct size ear tips and adjust the earhooks.

1. Select the ear tips that provide a snug fit in your ear canal. (S, M, L sizes are included).
2. Place the earbud into your ear, ensuring the ear tip is comfortably sealed.
3. Gently adjust the detachable earhook over the top of your ear until it feels secure and comfortable. The earhooks are designed to keep the earbuds firmly in place during activities.

Power Last All Day



Image: A person wearing the Coucur BE1033 Wireless Earbuds, demonstrating their secure fit during an outdoor activity and for general use.




Image: A diagram illustrating how the earhooks provide a comfortable and firm fit for the earbuds, showing the earbud placement and the earhook's position behind the ear.

5. OPERATING THE EARBUDS

5.1 Touch Controls

The earbuds feature intuitive touch controls for various functions:

Function	Action
Play/Pause	Press either earbud once
Next Track	Double press the right earbud
Previous Track	Double press the left earbud
Volume Up	Press and hold the left earbud
Volume Down	Press and hold the right earbud
Answer/End Call	Press either earbud once
Reject Call	Press either earbud once
Voice Assistant (Siri/Google Assistant)	Triple press either earbud



Image: A comprehensive diagram illustrating all the one-button control functions of the earbuds, including play/pause, track navigation, volume adjustment, call management, and voice assistant activation.



Image: A user activating the voice assistant (Hey Siri or Google Assistant) on the earbud with a simple tap, demonstrating the ease of access to smart features.

5.2 Sound Quality and Noise Cancellation

The Coucur BE1033 earbuds deliver Hi-Fi stereo deep bass thanks to a powerful 6mm driver unit. Equipped with CVC8.0 noise-cancelling technology, they effectively filter out environmental noise, ensuring crystal clear calls and an immersive music experience.

Video: An official product video showcasing the features of the Coucur BE1033 Wireless Earbuds, including their design, sound quality, and one-step pairing functionality.

6. MAINTENANCE

6.1 Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- Use a dry cotton swab to carefully clean the charging contacts on both the earbuds and the case.

6.2 IP7 Waterproof Rating

The earbuds are IP7 waterproof, meaning they can withstand sweat and splashes, making them suitable for strenuous workouts and various weather conditions. However, they are not designed for swimming or prolonged submersion.




Image: The Coucur BE1033 Wireless Earbuds being splashed with water, illustrating their IP7 waterproof capability, suitable for workouts and outdoor use.

6.3 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your earbuds, try the following solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not pairing	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "BE1033" from your device's Bluetooth list and re-pair. ◦ Place earbuds back in case, close, then open again to reset.
Only one earbud working	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the case, close the lid, wait a few seconds, then open the lid and take them out together. ◦ If the issue persists, try resetting the earbuds (refer to specific reset instructions if available in a separate quick start guide).
No sound or low volume	◦ Adjust volume on both your device and the earbuds. ◦ Ensure earbuds are properly seated in your ears. ◦ Check if the earbuds are connected to the correct device. ◦ Clean any debris from the earbud mesh.
Charging case not charging	◦ Ensure the USB-C cable is securely connected. ◦ Try a different USB-C cable or power adapter. ◦ Clean the charging port on the case.

8. SPECIFICATIONS

Feature	Detail
Model Number	BE1033
Brand	Coucur
Connectivity Technology	Wireless, Bluetooth 5.1
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.1
Bluetooth Range	10 Meters
Battery Life (Earbuds)	6-7 Hours
Total Playtime (with Case)	Up to 25 Hours
Charging Case Charging Time	1 Hour
Water Resistance Level	IP7 Waterproof

Feature	Detail
Noise Control	Active Noise Cancellation (CVC8.0)
Audio Driver Size	6 Millimeters
Control Method	Touch, Voice
Material	Silicone
Product Dimensions	1.87 x 1.55 x 1 inches
Item Weight	4.2 ounces

9. WARRANTY AND SUPPORT

Coucur is committed to providing high-quality products. For any product-related inquiries, technical support, or warranty claims, please contact Coucur customer service through the retailer where you purchased the product or visit the official Coucur website. Please retain your proof of purchase for warranty purposes.

Date First Available: July 25, 2021

© 2024 Coucur. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B098JPS73M>

More documents and user manuals: **<https://manuals.plus/>**