

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CofeLife](#) /

› [CofeLife K300 Podcast Equipment Bundle User Manual](#)

CofeLife SK300 Mic

CofeLife K300 Podcast Equipment Bundle User Manual

Model: SK300 Mic

1. INTRODUCTION

This manual provides detailed instructions for the CofeLife K300 Podcast Equipment Bundle. This professional studio equipment is designed for podcasting, streaming, music recording, and video creation. It includes a condenser microphone and a sound card with various features to enhance your audio experience.




Image 1.1: The CofeLife K300 Podcast Equipment Bundle, featuring the sound card and condenser microphone.

2. PACKAGE CONTENTS

Verify that all components are present in your package:

- K300 Sound Card
- Condenser Microphone
- Microphone Stand
- XLR Cable for Microphone
- Audio Cables (various types for connection)
- USB Charging/Data Cable
- User Manual (this document)

3. SETUP INSTRUCTIONS

Follow these steps to set up your CofeLife K300 Podcast Equipment Bundle:

1. **Charge the Sound Card:** Connect the K300 sound card to a power source using the provided USB cable. Ensure it is fully charged before initial use.
2. **Connect the Microphone:** Attach the condenser microphone to its stand. Connect the microphone to the sound card using the XLR cable. The microphone connects to the 'MIC' input on the sound card.
3. **Connect to Device:**
 - **For PC/Laptop:** Connect the sound card to your computer via the USB data cable. Your computer should recognize it as an audio device.
 - **For Smartphones/Tablets:** Use the appropriate audio cables (e.g., 3.5mm TRRS cables) to connect your phone to the 'Live 1', 'Live 2', or 'Live 3' ports on the sound card.
 - **For Accompaniment:** Connect an external audio source (e.g., another phone, tablet) to the 'Accompaniment' input on the sound card using a 3.5mm audio cable.
4. **Connect Headphones/Speakers:** Plug your headphones into the 'Headset' or 'Earphone' jack for real-time monitoring. Connect external speakers to the 'Speaker' output if desired.




Image 3.1: Detailed wiring diagram illustrating connections for microphones, phones, and other devices to the K300 sound card.

The K300 bundle is compatible with most mainstream operating systems including Windows, Mac OS, Android, and iOS. It supports various live streaming platforms and recording software.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the functions of the K300 sound card for optimal performance:

4.1 Power On/Off

Press and hold the power button (usually located on the main control panel) to turn the device on or off. The LED lights will illuminate upon power-on.

4.2 Audio Adjustments

- Microphone Volume:** Use the 'MIC VOL' knob to adjust the microphone input level.
- Monitor Volume:** Adjust the 'Monitor VOL' knob to control the volume of your headphones.

- **Accompaniment Volume:** Use the 'Accompaniment' slider to control the volume of background music or external audio input.
- **Treble/Bass:** Utilize the 'MIC HIGH' and 'MIC LOW' knobs to fine-tune the microphone's treble and bass frequencies.

4.3 Sound Effects and Modes

The K300 sound card features 12 modes, 20 sound effects, and 4 voice changer options:

- **Reverberation Modes:** Select from 'KTV', 'Concert', or 'Studio' modes for different vocal reverberation effects.
- **Voice Changer:** Transform your voice into 'Male', 'Female', 'Child', or 'Monster' using the dedicated buttons.
- **Sound Effects:** Trigger various pre-loaded sound effects such as 'Applause', 'Laughter', 'Kiss', 'Face slap', and more, using the sound effects selection buttons.
- **Electronic Tone Adjustment:** The 'Electronic Adjust' section allows for 12 groups of electronic tone adjustments.
- **One-Button Avoidance (Dodge):** This function automatically lowers background music volume when you speak into the microphone.
- **Original Sound Elimination:** Press the 'Purge Original' button to remove vocals from an accompaniment track, allowing you to sing over the instrumental.



Image 4.1: A close-up view of the K300 sound card's control panel, highlighting the sound effect and voice changer buttons.

4.4 Real-time Monitoring

Connect headphones to the 'Headset' or 'Earphone' jack to monitor your audio in real-time, ensuring optimal sound quality during recording or streaming.

5. MAINTENANCE

To ensure the longevity and optimal performance of your K300 Podcast Equipment Bundle, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the sound card and microphone. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the equipment in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Handle cables gently. Avoid sharp bends or kinks that can damage internal wires.
- **Battery Care:** For the built-in lithium polymer battery, avoid fully discharging it frequently. Charge it regularly, even if not in use for extended periods, to maintain battery health.

6. TROUBLESHOOTING

If you encounter issues with your K300 Podcast Equipment Bundle, refer to the following common problems and solutions:

- **No Sound Output:**

- Check all cable connections to ensure they are secure.
- Verify that the sound card is powered on and charged.
- Adjust the 'Monitor VOL' knob and your device's volume settings.
- Ensure the correct audio input/output device is selected in your computer's or phone's sound settings.

- **Microphone Not Working:**

- Confirm the microphone is correctly plugged into the 'MIC' port.
- Increase the 'MIC VOL' knob on the sound card.
- Test the microphone with another device if possible to rule out a faulty microphone.

- **Sound Effects or Voice Changer Not Activating:**

- Ensure the sound card is powered on.
- Press the effect buttons firmly.
- Some effects may require a microphone input to be active.

- **Distorted Audio:**

- Reduce the 'MIC VOL' to prevent clipping.
- Check for loose cable connections.
- Ensure no other audio processing software is interfering.

- **Device Not Recognized by Computer:**

- Try a different USB port on your computer.
- Restart your computer and the sound card.
- Ensure your operating system is up to date.

If problems persist, please refer to the Warranty and Support section for contact information.

7. SPECIFICATIONS

Feature	Specification

Feature	Specification
Model Number	SK300 Mic
Item Weight	3.14 pounds (1.43 Kilograms)
Package Dimensions	11.3 x 7.44 x 5.98 inches
Batteries	1 Lithium Polymer battery required (included)
Compatible Devices	Laptop, Personal Computer, Smartphone
Connector Type	XLR Connector
Operating System Compatibility	Windows, Mac OS, Android, iOS
Power Source	Corded Electric
Voltage	1 Volts
Number of Channels	2
Sound Card Features	12 modes, 20 sound effects, 7 LED lights, 5-level noise reduction, 4 voice changers, 12 electronic tone adjustments
Microphone Type	Condenser Microphone (Cardioid)
Sampling Rate	120kHz/24 bit



Image 7.1: Visual representation of the K300 sound card's key features and specifications.

8. WARRANTY AND SUPPORT

CofeLife provides the following support for your K300 Podcast Equipment Bundle:

- **Warranty:** A 12-month warranty is provided from the date of purchase.
- **Returns:** A 40-day no-reason return policy is available.
- **Product Issues:** If you encounter any product or usage problems, please contact our customer support team. We aim to resolve any issues within 8-12 hours.
- **Replacements:** Defective or damaged products will be replaced free of charge.

For assistance, please refer to the contact information provided with your purchase or visit the official CofeLife support website.

© 2025 CofeLife. All rights reserved.