Masko 1

MASKO High-Pressure Cleaner Instruction Manual

Model: 1 | Brand: Masko

Introduction

Thank you for choosing the MASKO High-Pressure Cleaner. This manual provides essential information for the safe and efficient operation, assembly, maintenance, and troubleshooting of your new high-pressure cleaner. Please read these instructions carefully before using the appliance and keep them for future reference.



Image: The MASKO High-Pressure Cleaner unit with key specifications displayed. Max. Pressure: 165 Bar, Max. Flow Rate: 450 L/H, Power: 2200 Watt, Water Temperature: 5-50°C, High-Pressure Hose: 10 Meter, Cable Length: 5 Meter, Weight: 10.7 KG, IPX5 rating for water jet protection, and Child Safety Lock. Gloves are also shown as included.

Safety Instructions

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Read all instructions:** Familiarize yourself with the controls and proper use of the appliance.
- **Electrical Safety:** Ensure the power supply matches the voltage specified on the appliance. Do not operate the appliance with a damaged cord or plug.
- **Water Connection:** Connect the appliance to a water supply that is clean and free of impurities.
- **Personal Protective Equipment:** Wear appropriate eye and hearing protection during operation.
- **Child Safety Lock:** The appliance is equipped with a child safety lock to prevent accidental activation. Always engage the child safety lock when the appliance is unattended or not in use.

- **Avoid Direct Spray:** Never direct the water jet at people, animals, electrical equipment, or the appliance itself.
- **Stable Surface:** Operate the high-pressure cleaner on a stable, level surface to prevent tipping.



Image: Close-up views illustrating the child safety lock mechanism on the spray gun and the different spray patterns (Maximum, Medium, Minimum, Point) achievable with the adjustable nozzle. The image also shows an integrated accessory compartment on the main unit.

Package Contents

Before assembly, ensure all items listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- MASKO High-Pressure Cleaner Unit
- High-Pressure Gun with Quick-Release
- 10-meter High-Pressure Hose with Reel
- 5-meter Power Cable
- Adjustable Spray Nozzles (various types)

- Foam Dispenser Bottle with Nozzle
- Car Wash Brush
- Drain Cleaning Hose
- Floor Brush
- 360° Swivel Angle Nozzle
- Gloves



Image: A comprehensive layout of the MASKO high-pressure cleaner accessories, including the pressure gun with quick-release, wash brush, soap dispenser, various nozzles, drain cleaning hose, car wash brush, and child safety lock.



Image: A closer look at the floor brush and additional nozzles for the MASKO high-pressure cleaner, highlighting their design and connection points.



Image: The 10-meter high-pressure hose coiled on its reel, alongside a pair of yellow protective gloves, emphasizing the extended reach and safety features.

Assembly and Setup

1. **Attach Wheels and Handle:** Securely attach the wheels and handle to the main unit as indicated in the assembly diagrams.
2. **Connect High-Pressure Hose:** Connect one end of the 10-meter high-pressure hose to the outlet on the main unit and the other end to the high-pressure gun. Ensure connections are tight. The integrated hose reel helps manage the hose.
3. **Connect Water Supply:** Connect a garden hose (not included) to the water inlet of the high-pressure cleaner. Ensure the water supply is turned on before starting the unit.
4. **Attach Power Cable:** Plug the 5-meter power cable into a suitable grounded electrical outlet.
5. **Select and Attach Nozzle/Accessory:** Choose the desired nozzle or accessory (e.g., foam dispenser, floor brush) and attach it to the high-pressure gun using the quick-click coupling system.

The total reach of the high-pressure cleaner, including the hose and power cable, is approximately 30 meters, providing ample flexibility for various cleaning tasks.



Image: A visual representation of the MASKO high-pressure cleaner's impressive 30-meter operating range, combining the length of the high-pressure hose and the power cable.

Operating Instructions

1. **Preparation:** Ensure the unit is properly assembled, connected to water and power, and the water supply is open.
2. **Starting the Unit:** Turn on the power switch. Squeeze the trigger on the high-pressure gun to release air from the system and allow water to flow steadily.
3. **Adjusting Spray Pattern:** The high-pressure nozzles allow for optimal adjustment of spray power. Rotate the nozzle to select between different spray patterns: **Maximum** (narrow, powerful jet), **Medium**, **Minimum**, and **Point** (focused, high-impact jet).
4. **Using the Foam Dispenser:** Fill the foam dispenser bottle with appropriate cleaning solution. Attach it to the high-pressure gun. The unit will mix the solution with water to create foam for effective cleaning of surfaces like cars or

furniture.

5. **Versatile Applications:** Use the various attachments to precisely remove dirt from terraces, barbecues, pipes, and diverse surfaces such as tiles, metal, stone, wood, furniture, and cars. The drain cleaning hose can resolve clogged drains without harmful chemicals. The 360° swivel angle nozzle assists in reaching difficult areas.
6. **Stopping the Unit:** Release the trigger on the gun. Turn off the power switch on the unit. Turn off the water supply. Squeeze the trigger again to release any remaining pressure in the system.



Image: A collage demonstrating the versatile applications of the MASKO high-pressure cleaner, including cleaning a metal fence, a brick wall, a patio, and an RV with the foam nozzle.



Image: A person using the MASKO high-pressure cleaner to clean a large garage door, showcasing its effectiveness on vertical surfaces.



Image: A person washing a car with the MASKO high-pressure cleaner, demonstrating its use for vehicle cleaning.

Maintenance

- **Cleaning:** After each use, rinse the high-pressure cleaner and accessories with clean water.
- **Accessory Storage:** Utilize the integrated accessory compartment to keep all nozzles and attachments organized

and readily accessible.

- **Hose Reel:** Wind the high-pressure hose neatly onto the reel after use to prevent kinks and damage.
- **Winter Storage:** If storing the unit in an area where temperatures may drop below freezing, ensure all water is drained from the pump and hoses to prevent damage. Consider using a pump protector.
- **Filter Cleaning:** Regularly check and clean the water inlet filter to prevent blockages and maintain optimal performance.

Troubleshooting

Problem	Possible Cause	Solution
No water pressure / Low pressure	Water supply off or restricted; Air in pump; Clogged nozzle; Kinked hose.	Ensure water supply is fully open; Bleed air by running unit with gun open; Clean nozzle; Straighten hose.
Motor does not start	Power cable not connected; Faulty outlet; Thermal overload activated.	Check power connection; Test outlet with another device; Allow unit to cool down.
Unit cycles on and off	Air in pump; Leak in system; Nozzle partially blocked.	Bleed air; Check all connections for leaks; Clean nozzle.
Water leaks from connections	Loose connections; Worn O-rings.	Tighten all connections; Replace worn O-rings.

Specifications

Feature	Specification
Model	1
Power	2200 Watts
Max Pressure	165 Bar
Max Water Flow Rate	450 Liters per hour
Water Temperature Range	5 - 50°C
High-Pressure Hose Length	10 Meters
Power Cable Length	5 Meters
Total Operating Reach	30 Meters
Weight	14.5 kg (Product dimensions: 1 x 1 x 1 cm; 14,5 kilogrammes)
Dimensions (L x W x H)	10L x 10l x 10H millimeters (as per product specifications, actual unit dimensions are 43.5 cm W x 37 cm D x 132 cm H from image)

Feature	Specification
Color	Blue
Protection Class	IPX5 (Protected against water jets from any angle)



Image: The MASKO high-pressure cleaner with its main dimensions indicated: Height 132 cm, Width 43.5 cm, Depth 37 cm. Key specifications like hose length, pressure, power, and wattage are also listed.

Warranty and Support

The MASKO High-Pressure Cleaner is designed for durability and performance. For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support, spare parts, or service inquiries, please reach out to MASKO customer service through their official channels.
Please note that availability of spare parts is currently listed as 'Information unavailable'.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question