



Manuals.plus /

› Hbada /

› Hbada W203 Gaming Chair Instruction Manual

Hbada W203

Hbada W203 Gaming Chair Instruction Manual

Model: W203

1. INTRODUCTION AND OVERVIEW

The Hbada W203 Gaming Chair is designed to provide ergonomic support and comfort for extended periods of sitting, whether for gaming or office work. It features a robust construction, adjustable components, and a design focused on user well-being.



Image 1.1: The Hbada W203 Gaming Chair in a typical gaming environment, showcasing its design and presence.

2. SAFETY INFORMATION

- Do not exceed the maximum weight capacity of 150 kg (330.7 lbs).
- Ensure all bolts and screws are securely tightened before use and periodically check for looseness.
- Avoid standing on the chair or using it as a step stool.
- Keep hands and fingers clear of moving parts during adjustment.
- Use the chair on a flat, stable surface to prevent tipping.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer service.

- Backrest
- Seat Cushion

- Armrests (2)
- Star Base
- Casters (5)
- Gas Lift Cylinder
- Gas Lift Cover
- Mechanism Plate
- Headrest Pillow
- Lumbar Support Pillow
- Hardware Pack (screws, washers, Allen wrench)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people due to the weight of some components. Follow these steps carefully.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the star base until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the star base. Cover it with the gas lift cover.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the screw holes on the underside of the seat cushion. Secure it with the provided screws and Allen wrench. Ensure the front of the mechanism faces the front of the seat.
4. **Attach Armrests to Seat:** Secure the armrests to the sides of the seat cushion using the designated screws. Do not overtighten initially to allow for minor adjustments.
5. **Attach Backrest to Seat:** Align the backrest with the mounting brackets on the seat cushion. Secure it with screws.
6. **Connect Seat Assembly to Base:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered. Apply downward pressure to secure it.
7. **Attach Headrest and Lumbar Support:** Position the headrest pillow and lumbar support pillow as desired. They are typically secured with straps.
8. **Final Tightening:** Once fully assembled, go back and tighten all screws firmly.



Image 4.1: Overview of chair features, including lift function, height-adjustable armrests, 155-degree recline, silent casters, 360-degree rotation, and durable base.

5. OPERATING INSTRUCTIONS

5.1. Chair Height Adjustment

To adjust the chair height, locate the lever on the right side, beneath the seat. While seated, pull the lever up to lower the chair. To raise the chair, stand up slightly and pull the lever up. Release the lever at the desired height.

5.2. Reclining Function

The chair offers a recline angle of up to 155 degrees with a 17-degree locking feature. To recline, pull the recline lever (typically on the left side) upwards and lean back. Release the lever to lock the backrest in position. To return to an upright position, pull the lever and lean forward.



Image 5.1: The chair's backrest can recline up to 155 degrees, allowing for various comfortable positions.

5.3. Armrest Adjustment

The armrests can be lifted to adjust their height. Locate the button or lever on the side of each armrest. Press or lift it and move the armrest up or down to your preferred height. Release the button/lever to lock it.

5.4. Lumbar Support and Headrest

The chair includes removable and adjustable headrest and lumbar support pillows. Adjust their position by sliding them along the backrest straps to provide optimal support for your head, neck, and lower back.



Image 5.2: Detailed view of the adjustable headrest, lifting armrests, and removable lumbar support.

5.5. Swivel Function

The chair features a 360-degree swivel function, allowing for easy rotation without moving the base.

6. MAINTENANCE

- **Cleaning:** The chair's synthetic leather (PU) material can be wiped clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary to maintain stability and prevent squeaking.
- **Casters:** Keep the casters free of hair and debris to ensure smooth movement.

7. TROUBLESHOOTING

- **Chair Squeaks:** Check and tighten all assembly screws. Applying a small amount of lubricant to moving metal parts (like the mechanism plate) may help.

- **Height Adjustment Not Working:** Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement. Contact customer service.
- **Chair Feels Unstable:** Verify that the star base is correctly assembled and all casters are fully inserted. Ensure all screws are tightened.
- **Casters Not Rolling Smoothly:** Clean any debris (hair, dust) from the caster wheels.

For issues not listed here or persistent problems, please contact Hbada customer service.

8. SPECIFICATIONS



Image 8.1: Key dimensions of the Hbada W203 Gaming Chair.

Feature	Detail
Model Name	Hbada W203
Product Dimensions (D x W x H)	70 x 70 x 128 cm (27.6 x 27.6 x 50.4 inches)
Adjustable Seat Height	40 - 48 cm (15.7 - 18.9 inches)
Item Weight	22.5 kg (49.6 lbs)
Maximum Load Capacity	150 kg (330.7 lbs)
Material	Synthetic leather (PU upholstery), Metal (frame), Reinforced Nylon Resin (base), High-density Urethane Foam (cushion), Silent PU Nylon Casters
Recline Angle	Up to 155 degrees with 17-degree locking
Armrest Adjustment	Lifting (approx. 7 cm range)
Special Features	Adjustable Lumbar Support, Ergonomic Design



Image 8.2: Internal construction details, showing high-density foam and a robust metal frame.

9. WARRANTY AND SUPPORT

The Hbada W203 Gaming Chair comes with a **1-year warranty service**. This warranty covers initial defects and manufacturing faults.

If you encounter any initial defects, malfunctions, or have any concerns regarding your product, please contact our customer service center. Our support team aims to respond within 24 hours and will assist with free exchanges or repairs as applicable. For customer service inquiries, please refer to the contact information provided on your purchase receipt or the official Hbada website.