

Kismile LE

Kismile Portable Evaporative Air Cooler Model LE User Manual

Model: LE

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance and retain for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug from the outlet when not in use, before cleaning, or when moving the appliance.
- Keep the appliance out of reach of children and pets.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Place the appliance on a stable, level surface to prevent water leakage.
- Do not block air inlets or outlets.
- Use only clean water in the water tank. Do not add any chemicals or additives.
- This appliance is for indoor, residential use only.

2. PRODUCT OVERVIEW

The Kismile Portable Evaporative Air Cooler is designed to provide personal cooling through evaporation. It features multiple operating modes, adjustable wind speeds, and a convenient timer function.



Figure 2.1: Kismile Portable Evaporative Air Cooler with remote control.

Package Contents:

- Kismile Portable Evaporative Air Cooler
- Remote Control
- Ice Boxes (x2)
- User Manual

3. SETUP

3.1 Unpacking and Placement

1. Carefully remove the air cooler from its packaging.
2. Place the unit on a firm, level surface, ensuring there is at least 20 cm (8 inches) of clear space around the unit for proper airflow.
3. Ensure the power cord is not pinched or damaged.

3.2 Filling the Water Tank

The unit features a 7-liter water tank. For optimal cooling, use cold water and the provided ice boxes.

1. Pull out the water tank from the bottom rear of the unit.
2. Fill the tank with clean, cold water up to the 'MAX' level indicator. Do not overfill.
3. For enhanced cooling, place the two ice boxes (after freezing them) into the water tank.
4. Carefully slide the water tank back into the unit until it is securely in place.



Figure 3.1: Water tank capacity and location.



Figure 3.2: Included ice boxes for enhanced cooling.

4. OPERATION

The air cooler can be operated using the control panel on top of the unit or the included remote control.

4.1 Control Panel and Remote Control

REMOTE CONTROL INCLUDED

Setting temperature and modes anywhere



SPEED



COOL



WINDTYPE



SWING



TIMER



ANION



Figure 4.1: Air Cooler with Remote Control.



Figure 4.2: Remote Control for the Kismile Air Cooler.

4.2 Functions

- **Power (On/Off):** Press to turn the unit on or off.
- **Mode:** Cycle through Normal, Natural, and Sleep modes.
- **Speed:** Adjust wind speed (Low, Mid, High).
- **Swing:** Activate or deactivate the 40° automatic oscillation feature.
- **Timer:** Set the operating timer from 1 to 12 hours.
- **Purify:** Activates the air purification function.
- **Cool:** Activates the evaporative cooling function.



Figure 4.3: Three Operating Modes.

40°WIDE OSCILLATION

Rotate cooling air fast around your room



Figure 4.4: 40-degree Wide Oscillation.




Figure 4.5: Built-in 12-hour Timer.

5. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your air cooler.

5.1 Cleaning the Exterior

- Always unplug the unit before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the control panel or other electrical components.

5.2 Cleaning the Water Tank

- Remove the water tank from the unit.
- Empty any remaining water.
- Clean the tank with a mild detergent and rinse thoroughly with clean water.
- Allow the tank to air dry completely before reinserting.

5.3 Cleaning the Air Filter

- The air filter is located at the back of the unit. Gently pull it out.
- Rinse the filter under running water to remove dust and debris. For heavier buildup, use a soft brush and mild detergent.
- Allow the filter to dry completely before placing it back into the unit.

5.4 Storage

- If storing the unit for an extended period, ensure the water tank is empty and clean, and the air filter is dry.
- Store the appliance in a cool, dry place, away from direct sunlight.

6. TROUBLESHOOTING

Before contacting customer support, please refer to the following troubleshooting guide.

Problem	Possible Cause	Solution
Unit does not turn on	No power supply Power button not pressed	Check if the unit is plugged in and the outlet is working. Press the Power button on the control panel or remote.
Weak or no airflow	Air filter is dirty Air inlets/outlets blocked	Clean the air filter. Ensure nothing is obstructing the air inlets or outlets.
No cooling effect	Water tank is empty Cooling function not activated Ice boxes not used	Fill the water tank. Press the 'Cool' button. Ensure ice boxes are frozen and placed in the water tank.
Water leakage	Water tank not properly seated Unit is on an uneven surface Overfilled water tank	Ensure the water tank is securely pushed in. Place the unit on a flat, stable surface. Do not fill water above the 'MAX' line.

7. SPECIFICATIONS

Feature	Specification
Brand	Kismile
Model Name	Kismile Portable Air Cooler (Model LE)
Mounting Type	Freestanding
Color	White
Controls Type	Remote, Touch Panel




Feature	Specification
Reservoir Capacity	7 Liters
Product Dimensions	12.99"D x 12.99"W x 28.74"H
Item Weight	14.97 pounds
Voltage	120 Volts
Power Source	Corded Electric
Special Features	Portable, Remote control, 3 Wind Speeds, 3 Modes (Normal/Natural/Sleeping), 40° Oscillation, 12-hour Timer, Purify Function




8. WARRANTY AND SUPPORT

Kismile products are manufactured to high-quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Kismile website.

Please have your model number (LE) and purchase date available when contacting support.

Related Documents - LE

<p>WINE & BEVERAGE COOLER</p> <p>USER MANUAL</p>  <p>Model: JC-85B</p> <p><small>Please read the operating instructions carefully before using the product. Please read the instruction booklet before using the product. Please read the instruction booklet before using the product. Please read the instruction booklet before using the product.</small></p>	<p>JC-85B Wine & Beverage Cooler User Manual</p> <p>User manual for the JC-85B Wine & Beverage Cooler by Kismile, providing detailed instructions on product features, safety, operation, cleaning, installation, maintenance, and troubleshooting.</p>
<p><i>care & use</i></p> <p>ICE MAKER WITH WATER DISPENSERS MODEL NO.: HZB-15YLR</p>  <p><small>Important Safety Information 1 Safety Instructions 2 Getting to Know Your Unit 3 Before The First Use 4 Using Your Unit 5 Troubleshooting Guide 6</small></p>	<p>Kismile HZB-15YLR Ice Maker with Water Dispenser: Care and Use Guide</p> <p>Comprehensive guide for the HZB-15YLR Ice Maker with Water Dispenser, covering important safety information, setup, operation, and troubleshooting. Learn how to use and maintain your appliance for optimal performance.</p>
 <p><small>IMPORTANT INSTRUCTIONS AND OPERATING MANUAL</small></p> <p><small>AIR FRYER (AIR OVEN)</small></p> <p><small>Model: HIC-AF-8083D</small></p>	<p>Kismile Air Fryer (Air Oven) HIC-AF-8083D: Important Instructions and Operating Manual</p> <p>Comprehensive operating manual for the Kismile HIC-AF-8083D Air Fryer (Air Oven), covering safety, parts, usage, digital control panel, cooking presets, cleaning, storage, troubleshooting, and FAQs. Learn how to use your air fryer for various cooking methods.</p>

 <p>147x210mm 2020.6.13</p> <p>KIS-MILE</p> <p>Model No. PTC-902A</p> <p>Serial No. 000000</p> <p>Ceramic Fan Heater</p> <p>Features:</p> <ul style="list-style-type: none">• Automatic Thermostat• Three Settings: 1100W / 1500W / 2000W (All Fan On)• Over-heat Safety• Safety Locking Switch• Safety Tip-over Protection• 220VAC, 50Hz, 1500W at 230°C, 1500W at 210°C <p>Start Please Instructions</p>	<p>KISMILE Ceramic Fan Heater PTC-902A User Manual and Safety Guide</p> <p>Comprehensive user manual and safety guide for the KISMILE Ceramic Fan Heater, Model PTC-902A. Learn about features, safe operation, cleaning, and troubleshooting.</p>
 <p>INSTRUCTION MANUAL</p> <p>Ice Maker</p> <p>MODEL NO.: CB24C</p> <p>ITEM NO.: ZH424-WHITE ZH424-BLACK</p>	<p>CB24C Ice Maker Instruction Manual</p> <p>Comprehensive instruction manual for the Kismile CB24C Ice Maker, covering safety precautions, product introduction, control panel operation, usage, cleaning, maintenance, troubleshooting, and specifications.</p>
	<p>KISMILE KIS-H1000 Infrared Heater: Operating Manual and Safety Guide</p> <p>Comprehensive operating manual and safety instructions for the KISMILE KIS-H1000 infrared heater. Learn about installation, safe operation, remote control functions, troubleshooting, and warranty.</p>