

ICE COOREL 6 Fans Blue

ICE COOREL Laptop Cooling Pad User Manual

Model: 6 Fans Blue

1. INTRODUCTION

Thank you for purchasing the ICE COOREL Laptop Cooling Pad. This device is designed to enhance your laptop's performance and longevity by providing efficient cooling and an ergonomic viewing angle. Please read this manual thoroughly to ensure proper setup and operation.

2. KEY FEATURES

- **Powerful Cooling System:** Equipped with six 70mm cooling fans, operating at an adjustable speed of 2400-2600 RPM, to effectively dissipate heat.
- **Ergonomic Design:** Features five adjustable height settings, allowing you to position your laptop for optimal comfort and reduced strain.
- **Dual USB Ports:** Includes two USB 2.0 ports for convenient data transmission or connecting additional peripherals.
- **Ultra-Quiet Operation:** Designed to provide a noise-free cooling experience.
- **Durable Construction:** Made with a high-quality metal mesh surface for wear resistance and improved heat dissipation.
- **Universal Compatibility:** Suitable for most laptops ranging from 13 to 17 inches.
- **Non-slip Baffles:** Two integrated baffles prevent your laptop from sliding off the stand.



Figure 2.1: The ICE COOREL Laptop Cooling Pad featuring six illuminated fans.

ICE COOREL Laptop Cooling Pad

6 Height Stand Agajustbla
Foldable Non-slip Baffle
Two USB Ports&One USB Cable
6 Quiet Cooling Fans


>>>



Figure 2.2: Overview of the cooling pad's key attributes.

3. SPECIFICATIONS

Attribute	Value
Product Dimensions	16.5 x 11 x 1.1 inches (420mm x 285mm x 28mm)
Item Weight	2.27 pounds (1.03 kg)
Material	Metal Mesh, Plastic
Fan Quantity	6 Fans
Fan Speed	2400-2600 RPM (Adjustable)
USB Ports	2 x USB 2.0
Compatibility	Laptops up to 17 inches



Support to laptop 12"-17"




Figure 3.1: Product dimensions and laptop compatibility.

4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the cooling pad from its packaging.
2. **Position:** Place the cooling pad on a stable, flat surface.
3. **Adjust Height (Optional):**

The cooling pad features an adjustable stand with five height settings. Gently lift the rear of the pad and extend the support rods to your desired angle. Ensure both support rods are securely locked into place for stability.




Figure 4.1: Ergonomic height adjustment options.

4. **Place Laptop:** Carefully place your laptop on the cooling pad. Ensure the two non-slip baffles at the front are extended to prevent the laptop from sliding.
5. **Connect USB:** Connect the provided USB cable from one of the cooling pad's USB ports to an available USB 2.0 port on your laptop. The fans will begin to operate, and the blue LED lights will illuminate.

Ergonomic Laptop Cooling Stand

6 Height Adjustable

Free to adjust a comfortable angle which you feel



Non-slip Baffles



14.5cm/5.7in

Figure 4.2: Laptop placed on the ergonomic stand with non-slip baffles.



Dual USB Ports
*To connect more USB devices
Come with free one USB cable*

Figure 4.3: Connecting the cooling pad via USB to a laptop.

5. OPERATING INSTRUCTIONS

The ICE COOREL Laptop Cooling Pad is designed for simple plug-and-play operation.

- **Power On/Off:** The cooling pad powers on automatically when connected to a powered USB port on your laptop. Disconnect the USB cable to turn it off.
- **Adjust Fan Speed:** Locate the fan speed control dial, typically on the side of the cooling pad. Rotate the dial to increase or decrease the fan speed according to your cooling needs.
- **Using USB Ports:** The two additional USB 2.0 ports on the cooling pad can be used to connect other USB devices such as a mouse, keyboard, or external hard drive, effectively expanding your laptop's connectivity.




Figure 5.1: Control panel with USB ports and fan speed dial.



Figure 5.2: Illustration of effective heat dissipation.

6. MAINTENANCE

To ensure optimal performance and longevity of your cooling pad, follow these simple maintenance guidelines:

- **Cleaning:** Regularly wipe the metal mesh surface and plastic frame with a soft, dry cloth to remove dust. For stubborn dirt, a slightly damp cloth can be used, but ensure the pad is completely dry before reconnecting it to power.
- **Dust Removal:** Periodically use compressed air to clear dust from the fan blades and vents to maintain efficient airflow.
- **Storage:** When not in use for extended periods, store the cooling pad in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the cooling pad to liquids. In case of accidental spills, immediately disconnect power and allow it to dry completely.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fans are not spinning / No LED lights	Not properly connected to USB port. USB port on laptop is not providing power. Faulty USB cable.	Ensure the USB cable is securely plugged into both the cooling pad and a working USB port on your laptop. Try a different USB port on your laptop. Test with another USB cable if available.
Fans are spinning slowly / Low airflow	Fan speed dial set too low. Dust accumulation on fans.	Rotate the fan speed dial to increase fan speed. Clean the fan blades and vents as described in the Maintenance section.
Laptop still overheating	Improper placement of laptop. Laptop's internal cooling issues. Extreme ambient temperature.	Ensure the laptop is centered on the cooling pad and the baffles are extended. Ensure your laptop's own vents are not blocked. Consider professional laptop maintenance if internal issues are suspected. Use in a well-ventilated area.
USB ports on cooling pad not working	Cooling pad not receiving sufficient power. Device connected requires more power than available.	Ensure the cooling pad is connected to a fully functional USB port on your laptop. Try connecting lower-power devices.

8. WARRANTY INFORMATION

Please refer to the product packaging or the retailer's website for specific warranty terms and conditions. Typically, ICE COOREL products come with a limited manufacturer's warranty covering defects in materials and workmanship.

9. CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact ICE COOREL customer service through the following channels:

- **Website:** Visit the official ICE COOREL website (if available, link would be here).
- **Email:** Refer to your product packaging for customer support email.
- **Retailer:** Contact the retailer from whom you purchased the product.

When contacting support, please have your product model (6 Fans Blue) and purchase date ready.

© 2022 ICE COOREL. All rights reserved.

Product Model: 6 Fans Blue

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question