

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TECH8 USA](#) /

› [TECH8 USA 2-in-1 Mouse Mover and Jiggler Instruction Manual](#)

TECH8 USA mm-bl-all

TECH8 USA 2-in-1 Mouse Mover and Jiggler Instruction Manual

Model: mm-bl-all

INTRODUCTION

The TECH8 USA 2-in-1 Mouse Mover and Jiggler is designed to keep your computer active by automatically moving the cursor. This prevents your PC from entering sleep mode or showing an 'away' status in communication applications like Skype, Microsoft Teams, or Lync. It features a compact design, dual operating modes, and a timer function, all without requiring any software installation.

SETUP

The TECH8 USA Mouse Mover is a plug-and-play device that requires no software or driver installation. Simply connect it to an available USB port on your computer.



The TECH8 USA 2-in-1 Mouse Mover and Jiggler features a compact design with a USB-A connector and an inline control panel. The control panel includes buttons for power, mode selection (Jiggle/Move), and timer settings (2H, 4H, Non-Stop), each with indicator lights.

We took the brains of
a standard mouse...

... and planted it
in our Mouse Mover.



This image demonstrates the device's undetectable nature. It functions as a standard mouse, requiring no special software or drivers, making it indistinguishable from a regular mouse to computer systems.



The device is shown connected to a laptop, emphasizing its core functionalities: it is undetectable by IT systems, remembers previous settings, requires no software installation, has a power on/off button, offers two operational modes (Jiggle and Move), and includes a timer function. It is also noted as an American company product.

OPERATING INSTRUCTIONS

Power On/Off

Press the power button on the control panel to turn the device on or off. This allows you to activate or deactivate the mouse moving function without needing to unplug the device from the USB port.

Mode Selection: Jiggle and Move

The device offers two distinct modes to suit your preference:

- **Jiggle Mode:** In this mode, the cursor moves invisibly or with very subtle movements. This is ideal for maintaining an active status without noticeable on-screen cursor activity.
- **Move Mode:** This mode causes the cursor to move visibly across the screen. Select this mode if you prefer to see the cursor movement.

Press the 'MODE' button on the control panel to switch between Jiggle and Move modes. The

corresponding indicator light will illuminate to show the active mode.

Timer Function

The integrated timer allows you to set the duration for which the device operates:

- **2H (2 Hours):** The device will operate for 2 hours and then automatically turn off.
- **4H (4 Hours):** The device will operate for 4 hours and then automatically turn off.
- **Non-Stop:** The device will operate continuously until manually turned off.

Press the 'TIME' button on the control panel to cycle through the timer options. The indicator light will show the selected duration. The device features smart memory, retaining your last selected timer and mode settings.

Your browser does not support the video tag.

This video demonstrates the functionality of the TECH8 USA 2-in-1 Mouse Mover and Jiggler, showcasing its plug-and-play setup, dual Jiggle and Move modes, and the integrated timer function to maintain PC activity.

MAINTENANCE

The TECH8 USA Mouse Mover and Jiggler requires minimal maintenance. Keep the device clean and free from dust. Avoid exposing it to extreme temperatures or moisture. Do not attempt to disassemble the device, as this may void any implied support.

TROUBLESHOOTING

- **Device Not Responding:** Ensure the device is securely plugged into a functioning USB port. Try a different USB port if necessary.
- **Cursor Movement Not Visible in Jiggle Mode:** Jiggle mode is designed for subtle or invisible cursor movements to maintain active status without distraction. If you require visible movement, switch to Move Mode.
- **Device Stops Working After Unplugging/Replugging:** If the device does not resume operation immediately after being unplugged and reconnected, ensure the power button is pressed to turn it on again.
- **Incorrect Timer or Mode Setting:** The device has a smart memory function. If settings are incorrect, simply adjust them using the 'MODE' and 'TIME' buttons.

SPECIFICATIONS

Feature	Detail
Product Dimensions	5 x 2 x 0.04 inches
Item Weight	2.8 ounces
Model Number	mm-bl-all
Connectivity Technology	USB
Movement Detection Technology	Optical

Special Feature	Portable
-----------------	----------

WARRANTY AND SUPPORT

TECH8 USA products are designed and assembled in the USA, reflecting a commitment to quality and innovation. While specific warranty details are not provided in this manual, TECH8 USA offers 24/7 US-based client service for any inquiries or support needs.

For further assistance, please refer to the official TECH8 USA brand store or contact customer support directly.