

[Manuals.plus](#) /

› [Michael Kors](#) /

› Michael Kors Dylan Chronograph Watch MK8303 User Manual

Michael Kors MK8303

Michael Kors Dylan Chronograph Watch MK8303 User Manual

Model: MK8303

INTRODUCTION

Thank you for choosing the Michael Kors Dylan Chronograph Watch MK8303. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

The Michael Kors Dylan Chronograph Watch MK8303 features a durable stainless steel case, a comfortable silicone strap, and a striking blue dial. It is powered by a precise quartz movement and includes a chronograph function and date display. With a water resistance of up to 100 meters, it is suitable for various activities.



Image: Michael Kors Dylan Chronograph Watch MK8303. This image displays the watch with its blue dial, three subdials, and a blue

SETUP

Setting the Time

1. Pull the crown (the knob on the side of the watch) out to the second click position.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time. Ensure you differentiate between AM and PM if your watch has a 24-hour indicator or date change mechanism.
3. Push the crown back in to the normal position to start the watch.

Setting the Date

1. Pull the crown out to the first click position.
2. Turn the crown clockwise or counter-clockwise (depending on the movement) until the correct date appears in the date window. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism.
3. Push the crown back in to the normal position.

OPERATING INSTRUCTIONS

Using the Chronograph (Stopwatch)

Your Michael Kors Dylan Chronograph Watch MK8303 is equipped with a stopwatch function for measuring elapsed time.

1. **Start:** Press the upper pusher (button) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the upper pusher again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** Press the lower pusher to reset the chronograph hands to their zero position.
4. **Split Time (if applicable):** Some chronographs allow for split time measurement. Consult the detailed movement guide if your specific model supports this.

Water Resistance

This watch is water resistant up to 100 meters (10 ATM). This means it is suitable for swimming and snorkeling, but not for diving. Do not operate the crown or pushers while the watch is wet or submerged, as this can compromise the water resistance.

MAINTENANCE

Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and strap regularly with a soft, dry cloth. For the silicone strap, you may use a slightly damp cloth with mild soap and water, then rinse and dry thoroughly. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

The watch is powered by a quartz movement, which requires a battery. When the battery runs low, the second hand may start to skip or stop. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields.

TROUBLESHOOTING

- **Watch Not Running:** Check if the crown is pushed in completely. If it is, the battery may need replacement.
- **Date Not Changing:** Ensure the time is set correctly, especially distinguishing between AM and PM. If the date changes at noon, the watch is set 12 hours off. Adjust the time by 12 hours.
- **Water Inside Watch:** If you notice condensation or water inside the watch, immediately take it to a professional watch repair service. Do not attempt to open the watch yourself.

SPECIFICATIONS

Feature	Detail
Brand Name	Michael Kors
Model Number	MK8303
Case Material Type	Stainless Steel
Case Thickness	12 millimeters
Item Shape	Round
Dial Color	Blue
Display Type	Analog
Movement	Quartz
Special Features	Chronograph, Water Resistant
Band Material Type	Silicone
Strap Color	Blue
Clasp Type	Tang Buckle
Water Resistance Depth	100 meters
Item Weight	11 grams
Age Range Description	Adult

WARRANTY AND SUPPORT

Your Michael Kors watch is covered by a limited manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage duration and what is not covered. For warranty claims or technical support, please contact Michael Kors customer service or an authorized service center. Keep your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B098RGHWV4>

More documents and user manuals: <https://manuals.plus/>