VssoPlor S001

Vssoplor Wireless Mouse User Manual

Model: S001

INTRODUCTION

Thank you for choosing the Vssoplor Wireless Mouse. This manual provides essential information for setting up, operating, and maintaining your new wireless mouse. Please read it carefully before use and retain it for future reference.

Image: The Vssoplor Wireless Mouse in black and gold, showcasing its sleek design.

PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- 1 x Vssoplor Wireless Mouse
- 1 x USB Nano Receiver (stored inside the mouse)
- 1 x User Manual (this document)
- **Note:** 1 AA battery is required and not included in the package.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Vssoplor Wireless Mouse.

Image: Diagram showing the bottom of the mouse, highlighting the Anti-slip Pad, Switch Button, Battery Slot, and USB Receiver storage.

- **Left/Right Click Buttons:** Standard mouse functionality.
- **Scroll Wheel:** For vertical scrolling.
- **USB Nano Receiver:** Connects the mouse wirelessly to your computer. Stored in a compartment on the bottom of the mouse.
- **Battery Slot:** Holds one AA battery.
- **Power Switch:** ON/OFF switch to conserve battery life.
- **Optical Sensor:** Located on the bottom for tracking movement.

SETUP

1. Install Battery

1. Open the battery compartment cover on the bottom of the mouse.
2. Insert one AA battery, ensuring correct polarity (+/-).
3. Close the battery compartment cover.

2. Connect USB Nano Receiver

1. Locate the USB Nano Receiver stored in the compartment next to the battery slot on the bottom of the mouse.
2. Gently pull out the receiver.
3. Plug the USB Nano Receiver into an available USB port on your computer (desktop, laptop, PC).

Image: The USB Nano Receiver inserted into a laptop's USB port, ready for use.

3. Power On the Mouse

- Flip the power switch on the bottom of the mouse to the "ON" position.
- Your computer should automatically detect and install the necessary drivers. No additional software is required.

Image: A visual representation of the mouse and its receiver connected to a laptop, illustrating the "Plug and Play" functionality.

OPERATING INSTRUCTIONS

Basic Usage

- Move the mouse on a flat surface to control the cursor on your screen.
- Use the left button for primary clicks (selecting, opening).
- Use the right button for secondary clicks (context menus).
- Scroll the wheel to navigate vertically through documents and web pages.

Image: A hand operating the Vssoplor Wireless Mouse on a wooden desk, emphasizing its quiet click feature for focused work.

Power Saving Features

- **Intelligent Sleep Mode:** The mouse will automatically enter sleep mode after 5 minutes of inactivity to conserve battery power. To wake it up, simply click any button.
- **Power Switch:** For extended periods of non-use, turn off the mouse using the ON/OFF switch on the bottom to maximize battery life.

Image: An illustration depicting the quiet click functionality of the mouse, with a sleeping child in the background, symbolizing undisturbed environments.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** When the mouse performance degrades or stops responding, replace the AA battery. Ensure proper polarity.
- **Receiver Storage:** When traveling or not using the mouse, store the USB Nano Receiver in its dedicated slot on the bottom of the mouse to prevent loss.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mouse not responding	- Low or dead battery - Receiver not properly connected - Mouse is off - Interference	- Replace the AA battery. - Ensure the USB receiver is securely plugged into a working USB port. - Turn the mouse ON using the switch on the bottom. - Move the mouse closer to the receiver or away from other wireless devices.
Cursor movement is erratic or jumpy	- Dirty optical sensor - Unsuitable surface - Low battery	- Clean the optical sensor on the bottom of the mouse with a soft cloth. - Use the mouse on a clean, non-reflective, opaque surface or a mouse pad. - Replace the AA battery.
Wireless connection issues	- Out of range - USB port issue	- Ensure the mouse is within 10 meters (33 feet) of the receiver. - Try plugging the receiver into a different USB port on your computer.

SPECIFICATIONS

- **Model:** S001
- **Connectivity:** 2.4G Wireless
- **Operating Distance:** Up to 10 meters (33 feet)
- **Movement Detection:** Optical
- **Power Source:** 1 x AA Battery (not included)
- **Dimensions:** 4.7 x 2.6 x 0.04 inches (approx. 11.9 x 6.6 x 0.1 cm)
- **Weight:** 2.4 ounces (approx. 68 grams)
- **Compatibility:** Windows 7/8/10/XP, Vista, Mac OS X 10.4 and later. (Note: Does not work with USB-C ports directly without an adapter).
- **Special Features:** Ergonomic Design, Lightweight, Portable, Silent Click, Auto-Sleep Mode.


Image: A diagram illustrating the dimensions of the Vssoplor Wireless Mouse, highlighting its slim and portable nature.

WARRANTY AND SUPPORT

VssoPlor products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official VssoPlor website.

For further assistance, you may contact VssoPlor customer service through their official channels. Please have your product model (S001) and purchase details ready.

You can find more information and products from VssoPlor at their [Amazon Store](#).

For further assistance, you may contact VssoPlor customer service through their official channels. Please have your product model (S001) and purchase details ready.

You can find more information and products from VssoPlor at their [Amazon Store](#).