

[Manuals.plus](#) /

› [Vinmo oog](#) /

› Vinmo oog 3-in-1 Selfie Stick Tripod with Bluetooth Remote Control User Manual

Vinmo oog Selfie Stick Tripod

Vinmo oog 3-in-1 Selfie Stick Tripod with Bluetooth Remote Control User Manual

Model: Selfie Stick Tripod

1. INTRODUCTION

Thank you for choosing the Vinmo oog 3-in-1 Selfie Stick Tripod. This versatile device combines a selfie stick, a tripod, and a detachable Bluetooth remote control, designed to enhance your photography and videography experience. Its compact and lightweight design makes it ideal for travel, group photos, and various creative shots. Please read this manual carefully to ensure proper use and to maximize the product's features.

Key Features:

- 3-in-1 Design: Selfie stick, tripod, and Bluetooth remote shutter.
- 360-Degree Rotatable Phone Holder and 203-Degree Adjustable Head.
- Extendable Telescopic Rod (18 cm to 68 cm total length).
- Durable ABS, PC, and Aluminum Alloy Construction.
- Wide Compatibility with 4-6.5 inch Smartphones.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Vinmo oog Selfie Stick Tripod Holder
- 1 x Detachable Bluetooth Remote Shutter
- 1 x User Manual

3. SETUP

3.1 Unfolding the Selfie Stick Tripod

1. Gently pull the phone holder upwards to extend the telescopic rod.

2. To use as a tripod, spread the three legs at the base until they are stable on a flat surface.
3. To use as a selfie stick, keep the legs folded and use the handle.

Easy Life, Start Here



Long press to turn on and connect "Selfie"



Open the rubber cell phone clamp



Mount your phone in different angles



Take photos or videos freely

Figure 1: Product features including durable material, detachable remote, and stable tripod base.

3.2 Mounting Your Smartphone

1. Open the rubber cell phone clamp by pulling the top part upwards.
2. Carefully insert your smartphone into the clamp, ensuring it is securely held. The clamp is compatible with phones approximately 4-6.5 inches in size.

3. Adjust the phone holder's angle as needed. It can rotate 360 degrees and the head can be adjusted 203 degrees for optimal viewing.



Figure 2: Step-by-step guide for connecting Bluetooth and mounting the phone.

3.3 Bluetooth Remote Control Pairing

1. Locate the detachable Bluetooth remote control, usually integrated into the handle.
2. Long press the button on the remote control to turn it on. An indicator light will flash, indicating it is in pairing mode.
3. On your smartphone, go to Bluetooth settings and search for available devices.
4. Select the device named "Selfie" (or similar) from the list to pair. The indicator light on the remote will stop flashing once successfully paired.
5. The remote control has a range of up to 10 meters.



Figure 3: Wireless Bluetooth remote control for shooting up to 10m.

4. OPERATING INSTRUCTIONS

4.1 Taking Photos and Videos

- Once your phone is securely mounted and the Bluetooth remote is paired, open your phone's camera application.
- Position the selfie stick or tripod to achieve your desired angle and distance. The telescopic rod extends from 18 cm (folded) to 68 cm (fully extended).
- Press the button on the Bluetooth remote control to capture a photo or start/stop video recording.

4.2 Adjusting Angles and Orientation

- The phone holder allows for 360-degree rotation, enabling you to switch between landscape and portrait modes easily.
- The rotating head can be adjusted up to 203 degrees, providing flexibility to find the perfect shooting angle for any situation.



Figure 4: Examples of diverse uses for the selfie stick tripod.

5. MAINTENANCE

- **Cleaning:** Wipe the selfie stick tripod with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Fold the selfie stick tripod to its compact size (18 cm) and store it in a dry place away from direct sunlight and extreme temperatures.

- **Battery:** The Bluetooth remote control uses a replaceable button cell battery. If the remote stops responding, replace the battery.
- **Water Resistance:** This product is **not water resistant**. Avoid exposure to water or high humidity.

SMALL AND EXQUISITE EASY TO CARRY

Folds into one for easy fit in bag pockets

185mm
100g



Figure 5: The compact design allows for easy portability.

6. TROUBLESHOOTING

- **Remote Control Not Pairing:**
 1. Ensure the remote control is charged or has a fresh battery.
 2. Make sure Bluetooth is enabled on your smartphone.
 3. Turn off and on both the remote and your phone's Bluetooth, then try pairing again.
 4. Ensure no other Bluetooth devices are interfering with the connection.
- **Remote Control Not Taking Photos/Videos:**
 1. Verify that the remote is successfully paired with your phone.
 2. Ensure your phone's camera app is open and active.

3. Some phone models may require specific camera settings or a third-party camera app for full remote functionality.
- **Selfie Stick/Tripod Instability:**
 1. Ensure all sections of the telescopic rod are fully extended and locked into place (if applicable).
 2. When using as a tripod, ensure the legs are fully spread on a flat, stable surface.
 3. Avoid placing excessively heavy phones or accessories that exceed the product's weight capacity.
 - **Phone Not Fitting in Clamp:**
 1. The clamp is designed for smartphones approximately 4-6.5 inches. Ensure your phone falls within this range.
 2. Remove any bulky phone cases that might prevent a secure fit.

7. SPECIFICATIONS

Feature	Detail
Brand	Vinmo oog
Model Name	Selfie Stick Tripod
Color	Black
Compatible Devices	Smartphone (4-6.5 inches)
Materials	Acrylonitrile Butadiene Styrene (ABS), Polycarbonate (PC), Aluminum Alloy
Minimum Height (Folded)	18 cm (7.1 inches)
Maximum Height (Extended)	68 cm (26.8 inches)
Shaft Diameter	2.5 cm (1 inch)
Number of Leg Sections	3
Tripod Head Type	Fixed Head (360-degree rotation, 203-degree adjustable)
Remote Control Range	Up to 10 meters (33 feet)
Water Resistance Level	Not Water Resistant
Weight	140 grams (approx.)

8. WARRANTY AND SUPPORT

Vinmo oog is committed to providing high-quality products and customer satisfaction. This product comes with a customer satisfaction guarantee. If you encounter any issues with your Vinmo oog Selfie Stick Tripod, please do not hesitate to contact our customer service team.

Customer Service:

- For support, questions, or concerns, please contact us via email. Our team is available 24 hours to assist you.
- We offer a 100% return guarantee for product issues.

Please refer to your purchase documentation for specific warranty terms and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question