Kodahome PG-G01

Kodahome Universal Series Pet Groom Tool Kit Instruction Manual

Model: PG-G01

1. Introduction

Thank you for choosing the Kodahome Universal Series Pet Groom Tool Kit. This manual provides essential information for the safe and effective use of your new pet grooming attachment. Please read these instructions carefully before use and retain them for future reference.
This tool is designed to assist in shedding and grooming pets, effectively collecting loose hair directly into a vacuum cleaner, reducing mess in your home.

2. Safety Information

For pet use only (e.g., dogs, cats). This product is not a toy. Keep out of reach of children.

- Ensure your vacuum cleaner is in good working condition before attaching the grooming tool.
- Do not use the tool on pets with skin conditions, open wounds, or severe matting without consulting a veterinarian.
- Always monitor your pet during grooming to ensure their comfort and safety.
- If your pet shows signs of distress, stop grooming immediately.
- Do not force the tool through tangled fur. Gently detangle before grooming.

3. Package Contents

Verify that all components are present in your package:

- Grooming Tool (Pet Brush)
- 3.3ft Reinforced Extension Hose with Adapter (Adapter A)
- Universal Adapter (Adapter B)
- Instruction Book (This manual)



Figure 1: Components of the Kodahome Pet Groom Tool Kit. Includes the main pet brush, an extension hose, Adapter A, Adapter B, and the instruction manual.

4. Product Features



Figure 2: Detailed view of the grooming tool highlighting its key features.

- **Stainless Steel Combs:** Designed for effective undercoat removal without harming the pet's skin.
- **Upgraded Scraper Mechanism:** Ensures more fur is collected into the vacuum and less remains on the comb plate.
- **Push Button:** Activates the scraper to move collected hair into the vacuum.
- **Release Slider:** Locks or unlocks the comb plate for use or storage.
- **Ergonomic Handle:** Provides comfortable grip during grooming.
- **Upholstery Tool Function:** Can be used independently or with a vacuum for hair removal from furniture.

5. Vacuum Compatibility

This tool is designed for wide compatibility with most vacuum cleaners, including Upright, Canister, Stick, and Wet/Dry types from various brands (e.g., Miele, Shark, Bissell, Hoover, Shop-Vac, Kirby, Rainbow).

The vacuum hose handle must have a circular shape. Refer to the following diameter ranges for compatibility:

- **Inner Diameter Range:** 1 1/4" - 1 3/4" (32mm - 44mm)
- **Outer Diameter Range:** 1" - 1 5/8" (26mm - 42mm)

Important Note: This tool is generally not compatible with vacuum cleaners that have an outer diameter over 1 5/8" (45mm) or an inner diameter over 1 3/4". It is also not compatible with vacuum intake channels that are triangular or non-circular.



Figure 3: Examples of vacuum types that are generally not compatible with the grooming tool.

6. Setup and Assembly

6.1 Connecting the Extension Hose to Your Vacuum

Choose the appropriate connection method based on your vacuum cleaner's handle type.

Method A: For Vacuum Handles with an Outer Circular Diameter (1" - 1 5/8")

1. Take Adapter A (the end of the extension hose with the rubber seal).
2. Insert Adapter A onto your vacuum's handle.
3. Twist Adapter A until it is completely sealed and secure. The internal rubber seal will ensure a tight fit.



Figure 4: Connection method for vacuum handles with an outer circular diameter.

Your browser does not support the video tag.

Video 1: Demonstration of connecting the extension hose using Adapter A for outer circular vacuum handles. This video shows the twisting and sealing process for a secure connection.

Method B: For Vacuum Handles with an Inner Circular Diameter (1 1/4" - 1 3/4")

1. First, connect Adapter B to Adapter A. Ensure the plastic end of Adapter B is flush with Adapter A.
2. Insert the combined Adapter A and B into your vacuum's handle.
3. Twist the adapters until they are completely sealed and secure within the vacuum handle.




Figure 5: Connection method for vacuum handles with an inner circular diameter.

Your browser does not support the video tag.

Video 2: Demonstration of connecting the extension hose using Adapter B for inner circular vacuum handles. This video shows the steps for combining adapters and securing them to the vacuum.

7. Operating Instructions

1. **Prepare Your Pet:**

   It is recommended to introduce the grooming tool and vacuum to your pet gradually. Start by letting them get familiar with the tool and the sound of the vacuum (if used) without direct contact. Use treats to create a positive association.

   If your pet is initially scared of the vacuum noise, try grooming them with the vacuum turned OFF first.

2. **Adjust Suction (Optional):**

   If your vacuum has adjustable suction, you may reduce it to minimize noise and make the experience more comfortable for your pet.

3. **Begin Grooming:**

Gently brush your pet's fur with the grooming tool. The stainless steel combs will collect loose hair.



Figure 6: Grooming a dog with the Kodahome Pet Groom Tool.

4. **Remove Collected Hair:**

   Once the tool has collected a sufficient amount of fur, turn ON the vacuum cleaner (if not already on). Push the red button on the grooming tool forward. This activates the scraper, retracting the comb plate and allowing the collected pet hair to be sucked into the vacuum automatically.



Figure 7: Activating the hair removal mechanism by pressing the button.

Your browser does not support the video tag.

Video 3: Demonstration of the grooming tool's hair removal function. Shows how pressing the button retracts the comb and allows the vacuum to collect the fur.

5. **Repeat:**

   Continue brushing and removing hair until your pet is thoroughly groomed.

6. **Dyson V-Series Specific Instruction:**

   If using with a Dyson V6, V7, V8, V10, V11, V15, or Outsize series vacuum cleaner, use the provided self-adhesive tape to lock the vacuum switch in the ON position for one-handed operation.

7.1 Upholstery Tool Function

The grooming tool can also be used as an upholstery tool to remove pet hair from furniture, with or without a vacuum cleaner connection.



Figure 8: Using the grooming tool as an upholstery cleaner.

8. Maintenance and Care

- After each use, ensure all collected hair is removed from the grooming tool and vacuum canister.
- Wipe the grooming tool with a damp cloth to clean any residue. Do not immerse the tool in water.
- Store the tool and accessories in a clean, dry place.

9. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Tool does not fit vacuum.	Incorrect adapter used or vacuum is incompatible.	Review Section 5 (Compatibility) and Section 6 (Setup and Assembly) to ensure correct adapter usage and vacuum compatibility. Check vacuum handle dimensions.
Hair is not being sucked into the vacuum.	Vacuum suction is too low, button not fully pressed, or vacuum canister is full.	Increase vacuum suction. Ensure the red button is fully pressed to retract the comb. Empty the vacuum canister. Check for blockages in the hose or tool.
Pet is scared of the tool/vacuum.	Lack of acclimatization.	Introduce the tool and vacuum gradually. Start with the vacuum off. Use treats and positive reinforcement. Refer to Section 7 (Operating Instructions).
Hair remains on the comb after pressing the button.	Insufficient vacuum suction or partial button press.	Ensure vacuum suction is adequate. Press the red button firmly and completely. Check for any obstructions in the scraper mechanism.

10. Specifications

Model Number: PG-G01

Product Dimensions: 22 x 9 x 4.5 cm

Item Weight: 453.59 g (1 Pound)

Material: Plastic

Color: Grey

Special Features: Adjustable, Flexible, Self Cleaning

Product Benefits: Undercoat Removal

Manufacturer: Kodahome

11. Warranty and Support

For warranty information or technical support, please contact Kodahome customer service through the retailer where the product was purchased or visit the official Kodahome website.
Online Support: Kodahome Store on Amazon

© 2024 Kodahome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question