

[Manuals.plus](#) /

› [Satisfyer](#) /

› Satisfyer Pro 2 Violet User Manual

Satisfyer E33183

Satisfyer Pro 2 Violet User Manual

Model: E33183

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Satisfyer Pro 2 Violet. Please read it thoroughly before first use and retain it for future reference. The Satisfyer Pro 2 utilizes Airpulse technology to deliver pressure wave stimulation.



Image 1.1: Satisfyer Pro 2 Violet device and its retail packaging.

2. SAFETY INFORMATION

- For adult use only.
- Do not use if the device or charging cable is damaged.
- Discontinue use immediately if you experience any discomfort or pain.
- Consult a healthcare professional if you have any pre-existing medical conditions or concerns.
- Use only water-based lubricants with this device. Oil-based lubricants can damage the silicone material.
- Keep out of reach of children.

3. SETUP

3.1 Initial Charge

Before first use, fully charge your Satisfyer Pro 2. Connect the included USB magnetic charging cable to the charging contacts on the device and a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator will illuminate during charging and turn off when fully charged. A full charge typically takes

approximately 2-3 hours.

3.2 First Use Preparation

Clean the device thoroughly before its initial use. Refer to the 'Maintenance' section for cleaning instructions. Apply a small amount of water-based lubricant to the stimulation head for enhanced comfort and experience.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To turn the device on, press and hold the power button () for 2 seconds. To turn the device off, press and hold the power button () for 2 seconds again.

4.2 Adjusting Intensity

The Satisfyer Pro 2 features 11 pressure wave intensity levels. Once the device is on, press the '+' button to increase the intensity and the '-' button to decrease the intensity. Experiment to find your preferred level.



Image 4.1: Control buttons for power and intensity adjustment.

4.3 Airpulse Technology

The device uses patented Airpulse technology to create non-contact pressure waves for stimulation. Position the stimulation head over the desired area without direct contact to experience the air pulse sensations.



Image 4.2: Visual representation of the Airpulse Technology in operation.

4.4 Waterproof Use

The Satisfyer Pro 2 is waterproof to IPX7 rating, meaning it can be submerged in water up to 1 meter for 30 minutes. This allows for use in the shower or bath. Ensure the charging port is dry before connecting the charging cable.

5. MAINTENANCE

5.1 Cleaning

Clean the device thoroughly after each use. Wash the device with warm water and a mild, toy-friendly soap or a

specialized toy cleaner. Rinse thoroughly and pat dry with a lint-free cloth. Do not use alcohol, petroleum-based cleaners, or harsh chemicals, as these can damage the silicone.

5.2 Storage

Store the Satisfyer Pro 2 in a clean, dry place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent material degradation.



Image 5.1: Key features of the Satisfyer Pro 2, including easy cleaning and waterproof design.

6. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Press and hold the power button for 2 seconds.
- **Device not charging:** Check if the USB magnetic charging cable is properly connected to both the device and the power source. Try a different USB port or adapter.
- **Weak or inconsistent sensation:** Ensure the stimulation head is positioned correctly without direct contact. The battery might be low; try recharging.
- **Unusual noise:** While the device has a whisper mode, some motor sound is normal. If the noise is

excessively loud or unusual, discontinue use and contact support.

If you encounter issues not listed here or if troubleshooting steps do not resolve the problem, please contact Satisfyer customer support.

7. SPECIFICATIONS

Feature	Specification
Model Name	Satisfyer Pro 2 Violet
Model Number	E33183
Dimensions	11.6 x 7.5 x 19 cm
Weight	0.39 g
Material	Body-friendly Silicone
Waterproof Rating	IPX7
Intensity Levels	11 Pressure Wave Intensities
Battery Type	Lithium Ion (included)
Charging	USB Magnetic Charging Cable

8. WARRANTY AND SUPPORT

Satisfyer offers a 15-year guarantee on this product. For warranty claims or technical support, please retain your proof of purchase.

For further assistance, you may contact the manufacturer directly:

Manufacturer: Triple A Import GmbH

Address: Am Lenkwark 3, 33609 Bielefeld, Germany

Website: www.satisfyer.com

Email: info@satisfyer.com



15-year guarantee • 15 Jahre Garantie • Garantie de 15 ans • 15 años de garantía comercial • 15 anos de garantia • Garanzia 15 anni • 15 lat gwarancji • 15 років гарантії • 15 лет гарантии • 15年保証 • 15 年质保
www.satisfyer.com/guarantee



Pressure wave and touch-free clitoral stimulation • Druckwellenstimulation und berührungslose Klitorisstimulation • Onde de pression et stimulation clitoridienne sans contact • Onda de presión y estimulación del clitoris sin contacto • Ondas de pressão e estimulação do clitoris sem contacto • Stimolazione ad onde di compressione e stimolazione clitoridea senza contatto • Stymulacja falami i bezdotykowa stymulacja techlaczk • Бездотикова вакуумно-хвильова стимуляція клітора • Бесконтактная вакуумно-волновая стимуляция клитора • 圧力の波とタッチフリーな陰核への刺激 • 压力波 刺激、无接触阴蒂刺激



Body-friendly silicone • Körperfreundliches Silikon • Silicone biocompatible • Silicona agradable al cuerpo • Silicone antialérgico • Silicone dermocompatibile • Miły w dotyku silikon • Лазідний до шкіри силікон • Нежный для кожи силикон • 体に優しいシリコン • 亲肤性硅胶



Waterproof (IPX7) • Wasserdicht (IPX7) • Étanche à l'eau (IPX7) • Impermeable (IPX7) • Impermeável à água (IPX7) • Impermeabile (IPX7) • Wodoszczelny (IPX7) • водонепроницаемая поверхность (IPX7) • водонепроницаемый (IPX7) • 防水 (IPX7) • 防水 (IPX7)



11 programs • 11 Programme • 11 programmes • 11 programas • 11 Programas • 11 programmi • 11 programów • 11 програм • 11 программ • 11プログラム • 11种程序



Whisper mode • Flüster Modus • Mode silencieux • Modo de susurro • Modo Silêncio • Modalità sussurro • Cicha praca • Безшумний режим • Бесшумный режим • ささやきモード • 静音模式



Rechargeable Li-ion battery • Lithium-Ionen-Akku • Batterie lithium-ion rechargeable • Bateria de iones de litio • Pilha de íons de lítio • Batteria agli ioni di litio • Akumulator litowo-jonowy • Підзаряджаємий, Літій-іонний акумулятор • Перезаряджаемый, Литий-ионный аккумулятор • リチウムイオン充電電池 • 锂离子电池



Easy to clean • Leicht zu reinigen • Nettoyage facile • Fácil de limpiar • Limpeza fácil • Facile da pulire • Łatwy w czyszczeniu • Легко чистить • Лёгкая очистка • 清浄も簡単 • 易于清洗



Magnetic USB charging cable included • USB-Magnetladekabel inklusive • Câble de recharge magnétique USB inclus • Cable de carga magnético por USB incluido • Cabo de carregamento magnético USB incluído • Cavo di ricarica magnetico USB incluso • W zestawie magnetyczny kabel ładujący USB • Магнітний зарядний кабель USB в комплекті • В комплект входит магнитный кабель для зарядки USB • USB磁気充電ケーブル付き • 附带USB磁性充电线

Material: silicone, ABS • Material: Silikon, ABS • Matériau : silicone, ABS • Material: silicona, ABS • Material: silicone, ABS • Materiale: silicone, ABS • Materiały: silicone, ABS • Матеріал: силікон, АБС • Материал: силикон, АБС • 素材 : シリコン、ABS 樹脂 • 材质 : 硅胶、ABS

PATENT GRANTED (EP 3 228 297 B1, EP 3 563 822 B1, CA 2 943 097 C, AU 2018200317 B2, RU 2 695 307 C1, MX 363260 B, ZA 201700224 B, JP 6893105 B2, BR 102016023617-7)

PATENT PENDING (US 2017/0281457 A1, CN 107280939 A, JP 2021-90821 A)

Image 8.1: Product packaging displaying warranty and manufacturer contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question