

Lenovo ZA5T0380US

Lenovo Tab M10 FHD Plus (2nd Gen) User Manual

1. INTRODUCTION

1.1 Overview

The Lenovo Tab M10 FHD Plus (2nd Gen) is a versatile tablet designed for various uses, from entertainment to productivity. It features a 10.3-inch Full HD display, an Octa-Core processor, and runs on the Android operating system. This device includes features such as Kid's Mode for child-friendly content and parental controls, dual speakers with Dolby Atmos for enhanced audio, and integrated front and rear cameras.

1.2 What's in the Box

Verify that all items are present in the packaging:

- Lenovo Tab M10 FHD Plus (2nd Gen) Tablet
- 5V/2A Power Adapter
- USB Type-C™ 2.0 Cable
- Quick Start Guide & User Guide (this document)

2. SETUP

2.1 Device Layout

Familiarize yourself with the physical components of your tablet.



Image: Rear camera and side buttons (power, volume) on the Lenovo Tab M10 FHD Plus (2nd Gen).

2.2 Powering On and Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the Lenovo logo appears.
- **To Power Off:** Press and hold the Power button until the power options menu appears, then select 'Power off'.
- **To Restart:** Press and hold the Power button until the power options menu appears, then select 'Restart'.

2.3 Charging the Battery

Before first use, fully charge the tablet's battery. Connect the USB Type-C cable to the tablet's charging port and the other end to the provided power adapter. Plug the adapter into a power outlet.

2.4 Initial Configuration

Upon first power-on, follow the on-screen prompts to set up your tablet:

- Select your preferred language.
- Connect to a Wi-Fi network.
- Sign in with your Google Account or create a new one.
- Review and accept the terms and conditions.



Image: Tablet lock screen during initial setup.

3. OPERATING THE TABLET

3.1 Basic Navigation

The tablet uses touch gestures for navigation:

- **Tap:** Select an item.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on content.
- **Long Press:** Access contextual menus or move icons.



Image: Tablet home screen displaying various application icons.

3.2 Kid's Mode

Kid's Mode provides a safe and controlled environment for children. It includes dedicated content, parental controls for screen time limits, and specialized eye protection features.

- To activate Kid's Mode, locate the Kid's Mode icon on the home screen or in the app drawer.
- Follow the on-screen instructions to set up profiles and parental controls.
- The tablet also features bumpy environment and posture alerts to encourage correct usage.



Image: Tablet displaying the Kid's Mode interface.

3.3 Camera Usage

The tablet is equipped with an 8 MP rear camera and a 5 MP front camera. Open the Camera application to capture photos and videos.

- Tap the camera icon to launch the application.
- Switch between front and rear cameras using the camera toggle icon.
- Tap the shutter button to take a photo or start/stop video recording.

3.4 Audio and Entertainment

The tablet features dual speakers tuned with Dolby Atmos for an enhanced audio experience. Use the tablet for watching videos, listening to music, or playing games.



Image: Tablet displaying a racing game.




Image: Tablet displaying a video player with a music visualizer.

3.5 Connectivity

The tablet supports Wi-Fi and Bluetooth for wireless connectivity.

- **Wi-Fi:** Connect to wireless networks (802.11 a/b/g/n/ac, 2.4 GHz & 5 GHz Dual Band) via the Settings menu to access the internet.
- **Bluetooth:** Pair with Bluetooth-enabled devices (Bluetooth 5.0) such as headphones or speakers via the Settings menu.

4. MAINTENANCE

4.1 Cleaning the Device

To clean your tablet, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics. Avoid using harsh chemicals or abrasive materials.

4.2 Software Updates

Regularly check for and install software updates to ensure optimal performance and security. Navigate to **Settings > System > System update** to check for available updates.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your tablet.

Issue	Possible Solution
Tablet does not power on	Ensure the battery is charged. Connect the tablet to the charger for at least 30 minutes, then try powering on again. If it still doesn't turn on, perform a force restart by holding the power button for 10-15 seconds.

Issue	Possible Solution
Screen is unresponsive	Restart the tablet. If the issue persists, ensure the screen is clean and free of debris.
Wi-Fi connection issues	Restart your Wi-Fi router and the tablet. Forget the network in tablet settings and reconnect. Ensure you are within range of the Wi-Fi signal.
Apps are crashing or freezing	Close and reopen the app. Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). Ensure the app and tablet software are up to date.
Battery drains quickly	Reduce screen brightness, close unused apps, disable Wi-Fi/Bluetooth when not in use. Check battery usage in Settings to identify power-consuming apps.

6. SPECIFICATIONS

Detailed technical specifications for the Lenovo Tab M10 FHD Plus (2nd Gen).

Feature	Detail
Model Number	ZA5T0380US
Display Size	10.3 Inches
Screen Resolution	1920 x 1200 pixels (FHD)
Processor	Octa-Core, up to 2.3 GHz (MediaTek)
RAM	2 GB DDR4 SDRAM
Storage	32 GB Flash Memory
Operating System	Android 10 (or later)
Graphics Coprocessor	PowerVR GE8300
Rear Camera	8 MP
Front Camera	5 MP
Wireless Connectivity	Wi-Fi 802.11 a/b/g/n/ac (2.4 GHz & 5 GHz Dual Band), Bluetooth 5.0
Ports	1x USB 2.0 Type-C
Battery Life	Up to 10 Hours (average)
Item Weight	1.01 pounds
Product Dimensions	9.6 x 6.04 x 0.33 inches

Feature	Detail
Color	Gray

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the official Lenovo support website for detailed terms and conditions regarding warranty coverage and duration.

7.2 Customer Support

For further assistance, technical support, or service inquiries, please visit the official Lenovo support website or contact their customer service. You can find contact information and support resources at support.lenovo.com.