Redragon K535

Redragon K535 Mechanical Gaming Keyboard User Manual

Model: K535-KR

1. Introduction

Thank you for choosing the Redragon K535 Mechanical Gaming Keyboard. This manual provides essential information for the proper setup, operation, and maintenance of your keyboard. Please read it thoroughly to ensure optimal performance and longevity of your device.

2. Package Contents

- Redragon K535 Mechanical Gaming Keyboard
- Detachable USB Type-C Cable
- User Manual (this document)

3. Product Overview

The Redragon K535 is a low-profile mechanical gaming keyboard featuring Red Switches, designed for a responsive and comfortable typing experience. It includes a detachable USB Type-C cable for easy portability and connectivity.



Figure 3.1: Top-down view of the Redragon K535 keyboard, showcasing its full layout and RGB backlighting.



Figure 3.2: Close-up view of the Redragon K535 keyboard, highlighting the low-profile Red Switches and keycap design.



Figure 3.3: Side profile view of the Redragon K535 keyboard, illustrating its ultra-slim design and adjustable feet.

4. Setup Instructions

1. **Connect the Cable:** Insert the USB Type-C end of the provided cable into the port on the back of the Redragon K535 keyboard.
2. **Connect to Computer:** Plug the standard USB-A end of the cable into an available USB port on your PC or laptop.
3. **Driver Installation:** The keyboard is plug-and-play. Your operating system (e.g., Windows 10) should automatically detect and install the necessary drivers. No additional software installation is typically required for basic functionality.

4. **Verify Functionality:** Once connected, the keyboard's backlighting should illuminate. Test key presses in a text editor to confirm proper operation.

5. Operating Instructions

5.1 Basic Keyboard Functions

The Redragon K535 functions as a standard QWERTY keyboard. All alphanumeric keys, symbols, and modifier keys (Shift, Ctrl, Alt) operate as expected.

5.2 Function Key Combinations (Fn Key)

The **Fn** key, located near the right Alt key, can be combined with other keys to access multimedia controls and system functions.

- **Fn + F1-F8:** Multimedia controls (e.g., Play/Pause, Stop, Previous Track, Next Track, Mute, Volume Down, Volume Up).
- **Fn + F9-F12:** System shortcuts (e.g., Email, Web Browser, Calculator, Search).

5.3 Backlighting Control

The K535 features customizable RGB backlighting. Use the following key combinations to adjust lighting effects:

- **Fn + Ins/Home/PgUp/Del/End/PgDn:** Cycle through various lighting modes and effects.
- **Fn + Arrow Keys (Up/Down):** Adjust backlight brightness.
- **Fn + Arrow Keys (Left/Right):** Adjust lighting effect speed or direction.

6. Maintenance

To ensure the longevity and optimal performance of your Redragon K535 keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. For deeper cleaning, use compressed air to remove dust and debris from between the keycaps. Avoid using harsh chemicals or abrasive materials.
- **Spills:** In case of liquid spills, immediately disconnect the keyboard from your computer. Turn it upside down to drain any liquid and allow it to dry completely before reconnecting. Do not attempt to use the keyboard while wet.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Handle the detachable USB Type-C cable with care. Avoid sharp bends or excessive pulling to prevent damage.

7. Troubleshooting

If you encounter issues with your Redragon K535 keyboard, refer to the following common solutions:

Problem	Possible Solution
Keyboard not responding	• Ensure the USB cable is securely connected to both the keyboard and the computer. • Try connecting the keyboard to a different USB port on your computer. • Test the keyboard on another computer to rule out a system-specific issue. • Restart your computer.

Problem	Possible Solution
Backlighting not working or incorrect	• Ensure the keyboard is properly connected and powered. • Use the Fn + lighting control keys (e.g., Fn + Ins/Home/PgUp/Del/End/PgDn, Fn + Arrow Up/Down) to adjust modes and brightness. • If applicable, check for any software settings that might override keyboard lighting controls.
Specific keys not working	• Clean the affected key area to remove any debris that might be obstructing the switch. • If the issue persists, it may indicate a hardware fault.

8. Specifications

Feature	Detail
Brand	Redragon
Model Number	K535-KR
Keyboard Type	Mechanical Gaming Keyboard
Switch Type	Low Profile Red Switches
Connectivity	Wired, Detachable USB Type-C Cable
Compatible Operating Systems	Windows 10 (and compatible with PC & Laptop)
Color	Black
Item Weight	500 g
Package Dimensions	47.7 x 17.4 x 4.1 cm
Power Source	USB power

9. Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Redragon website. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, you may contact Redragon customer support through their official channels.

© 2023 Redragon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question