

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AULA](#) /

› [AULA F2066-II USB Wired Keyboard User Manual](#)

AULA F2066-II

AULA F2066-II USB Wired Keyboard User Manual

Model: F2066-II | Brand: AULA

INTRODUCTION

Thank you for choosing the AULA F2066-II USB Wired Keyboard. This manual provides essential information for setting up, operating, and maintaining your keyboard. Please read it carefully to ensure optimal performance and longevity of your device.

SETUP INSTRUCTIONS

- Unpack the Keyboard:** Carefully remove the AULA F2066-II keyboard from its packaging. Ensure all components are present.
- Connect to Computer:** Locate an available USB port on your computer or laptop. Insert the USB connector of the keyboard firmly into the USB port.
- Driver Installation:** The keyboard is plug-and-play. Your operating system (Windows, macOS, Linux) should automatically detect and install the necessary drivers. No additional software installation is typically required.
- Test Functionality:** Open a text editor or any application that accepts text input and test typing to ensure all keys are functioning correctly.



Image: The AULA F2066-II USB Wired Keyboard, showcasing its full layout and RGB backlighting. This image illustrates the keyboard's design and key arrangement.

OPERATING INSTRUCTIONS

The AULA F2066-II keyboard features a standard layout with additional multimedia functions. It supports both English and Arabic languages.

Basic Usage:

- **Typing:** Use the alphanumeric keys for standard text input.
- **Function Keys (F1-F12):** These keys perform their standard functions.
- **Numeric Keypad:** The dedicated numeric keypad on the right provides quick entry for numbers and calculations.

Multimedia Key Combinations:

This keyboard includes various multimedia functions accessible via the **FN** key combined with other keys. Refer to the table below for specific combinations.



Multimedia key combination

FN+F1	My computer	FN+F2	Search	FN+F3	Calculator
FN+F4	CD player	FN+F5	Previous song	FN+F6	Next song
FN+F7	Play / pause	FN+F8	Stop	FN+F9	Mute
FN+F10	Volume reduction	FN+F11	Volume increase	FN+F12	Lock / unlock full keyboard
WIN-L	lock WIN+APP	→	speed +	←	speed-
FN+PRTSE	6 Keys Anti-Ghosting		FN+SCRLK	N Keys Anti-Ghosting	

Image: A detailed table illustrating the multimedia key combinations available on the AULA F2066-II keyboard. This includes functions like volume control, media playback, and application shortcuts activated by pressing the FN key with specific function keys.

Multimedia Key Functions

Combination	Function
FN + F1	My Computer
FN + F2	Search
FN + F3	Calculator
FN + F4	CD Player
FN + F5	Previous Song
FN + F6	Next Song
FN + F7	Play / Pause
FN + F8	Stop

Combination	Function
FN + F9	Mute
FN + F10	Volume Reduction
FN + F11	Volume Increase
FN + F12	Lock / Unlock Full Keyboard
WIN + L	Lock WIN + APP
FN + PRT SC	6 Keys Anti-Ghosting
FN + SCRLK	N Keys Anti-Ghosting

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your AULA F2066-II keyboard.

- **Cleaning:** Regularly clean the keyboard with a soft, dry cloth. For deeper cleaning, use compressed air to remove dust and debris from between the keys. Avoid using harsh chemicals or abrasive materials.
- **Spills:** In case of liquid spills, immediately disconnect the keyboard from your computer. Turn it upside down to drain any liquid and allow it to dry completely before reconnecting. Do not attempt to use the keyboard while it is wet.
- **Storage:** When not in use for extended periods, store the keyboard in a clean, dry environment away from direct sunlight and extreme temperatures.



Image: A top-down view of the AULA F2066-II keyboard, highlighting the keycaps and their spacing. This perspective is useful for understanding how to clean between the keys.

TROUBLESHOOTING

If you encounter issues with your AULA F2066-II keyboard, refer to the following common solutions:

Problem	Solution
Keyboard not responding.	<ul style="list-style-type: none"> • Ensure the USB cable is securely connected to both the keyboard and the computer. • Try connecting the keyboard to a different USB port. • Restart your computer. • Test the keyboard on another computer to rule out a computer-specific issue.
Certain keys are not working.	<ul style="list-style-type: none"> • Check for any physical obstructions or debris under the keycaps. • Gently remove the keycap (if applicable and designed for removal) and clean the switch area. • Ensure the keyboard is not in a locked mode (e.g., FN + F12).
Backlighting is not working.	<ul style="list-style-type: none"> • Check if the backlighting feature is enabled (refer to keyboard specific lighting controls, usually FN + arrow keys or dedicated light key). • Ensure the keyboard is receiving sufficient power from the USB port.

SPECIFICATIONS

Feature	Detail
Brand	AULA
Model Number	F2066-II-Black-Panel
Connectivity Technology	USB Wired
Keyboard Language	English & Arabic
Compatible Devices	PC, Laptop
Color	Black
Backlight Color	Single Color (RGB effects are typically pre-set patterns, not customizable per key color)
Material	Plastic
Dimensions (L x W x H)	49.7 x 40.7 x 5.3 cm
Weight	960 grams



Image: The AULA F2066-II keyboard displayed alongside its retail packaging. This image provides a visual reference for the product and its box.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official AULA website. Keep your proof of purchase for warranty claims.

Online Resources:

- AULA Official Website: www.aulagaming.com (*Note: This is a generic placeholder URL as no specific support link was provided in the product data. Please verify the correct URL.*)
- Product Support Page: Check the AULA website for a dedicated support page for model F2066-II.