Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Rastar 74940

Rastar Mercedes-Benz Actros Trailer Radio Control Toy

Model: 74940

Product Overview

The Rastar Mercedes-Benz Actros Trailer Radio Control Toy, Model 74940, is designed to provide an engaging play experience. This detailed replica features both a truck and a car, offering realistic play with its intricate interior and exterior design. It is equipped with light and sound functions for enhanced realism and rubber tires for smooth operation. The toy is easy to control, allowing for forward, backward, left, and right steering.
This toy is crafted from durable plastic and metal components. It is designed to enhance mental skills, hand-eye coordination, and motor skills in children. The trailer is built to a 1:26 scale, and the accompanying car is at a 1:24 scale.

Key Features:

- Detailed interior and exterior design.
- Functional lights and sounds.
- Durable rubber tires.
- Easy-to-use radio control with full directional movement (forward, backward, left, right).
- Constructed from high-quality plastic and metal.



Image 1: The Rastar Mercedes-Benz Actros Trailer Radio Control Toy, showing the yellow truck, the black trailer, the red sports car, and the remote control unit.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not suitable for children under 3 years.
This toy should be used under parental or adult supervision. Keep the toy away from flame sources, direct sunlight, and any external impacts that could cause damage. Ensure all small parts are securely attached before play. Dispose of batteries responsibly.

Setup

1. Unboxing

Carefully remove all components from the packaging. Verify that all parts, including the truck, trailer, car, and remote control, are present and undamaged.

2. Battery Installation

The truck and remote control require batteries for operation. Refer to the battery compartments on both the truck and the remote control for specific battery type and quantity requirements (typically AA or AAA batteries). Ensure batteries are inserted with correct polarity (+/-). Close the battery compartment covers securely.

3. Initial Pairing

Turn on both the truck and the remote control. The devices should automatically pair. If pairing does not occur, turn both devices off and then on again. Ensure there are no other strong radio signals nearby that could interfere with the connection.



Image 2: A detailed front view of the yellow Rastar Mercedes-Benz Actros RC truck, highlighting its grille and headlights.

Operating Instructions

1. Basic Movement

- **Forward:** Push the left joystick on the remote control forward.
- **Backward:** Pull the left joystick on the remote control backward.
- **Turn Left:** While moving forward or backward, push the right joystick to the left.
- **Turn Right:** While moving forward or backward, push the right joystick to the right.

2. Light and Sound Functions

Specific buttons on the remote control activate the truck's lights and sounds. Refer to the remote control's markings for these functions. Typically, one button controls headlights and taillights, while another activates engine sounds or horn.

3. Attaching/Detaching Trailer and Car

The trailer can be manually attached to and detached from the truck. The red car can be placed onto the trailer's ramp for transport. Ensure the car is securely positioned on the trailer before moving the truck.



Image 3: A side view of the Rastar Mercedes-Benz Actros RC truck with its trailer, showing the red sports car positioned on the trailer's ramp.

Maintenance

1. Cleaning

To clean the toy, gently wipe surfaces with a soft, damp cloth. Do not immerse the toy or remote control in water. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish and electronic components.

2. Storage

When not in use, store the toy in a cool, dry place, away from direct sunlight and extreme temperatures. Remove batteries from both the truck and the remote control if the toy will not be used for an extended period to prevent battery leakage and corrosion.

3. Battery Care

Always use fresh batteries of the recommended type. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.



Image 4: A rear view of the Rastar Mercedes-Benz Actros RC truck, showing the connection point for the trailer.

Troubleshooting

1. Toy Does Not Respond

- Check if batteries are correctly installed in both the truck and the remote control.
- Replace old or depleted batteries with fresh ones.
- Ensure both the truck and remote control are turned ON.
- Re-pair the remote control and truck by turning both off and then on again.
- Ensure you are within the effective operating range of the remote control.

2. Poor Control Range or Interference

- Avoid operating the toy near other radio-controlled devices or strong electromagnetic interference sources.
- Ensure the remote control's antenna (if applicable) is fully extended.

3. Lights or Sounds Not Working

- Check battery levels.
- Ensure the specific light/sound buttons on the remote control are being pressed correctly.

Specifications

Feature	Detail

Feature	Detail
Brand	Rastar
Model Number	74940
Shipping Dimensions	35.2 x 26.4 x 4.8 cm
Item Weight	320 grams
Manufacturer Recommended Age	6 years and up
Educational Objective(s)	Motor skills, Hand-eye coordination
Trailer Scale	1:26
Car Scale	1:24
Batteries Required?	Yes
Material Type(s)	Plastic, Metal, Rubber
Toy Vehicle Model	Car, Truck, Trailer
Special Features	Portable
Size	Small
Date First Available	July 8, 2021

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official Rastar website. Keep your purchase receipt as proof of purchase for any warranty claims.
No official product videos from the seller were available for embedding in this manual.

© 2024 Rastar. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B098W3M3V3

More documents and user manuals: **https://manuals.plus/**