

[Manuals.plus](#) /

› [Owigift](#) /

› Owigift Washer Water Drain Pump Motor Instruction Manual for Maytag Bravos XL Washers

Owigift MVWB850YW0

Owigift Washer Water Drain Pump Motor Instruction Manual

For Maytag Bravos XL and Compatible Washer Models

1. INTRODUCTION

This instruction manual provides essential information for the safe and effective installation, operation, and maintenance of your Owigift Washer Water Drain Pump Motor. This replacement part is designed for specific Maytag Bravos XL washer models. Please read this manual thoroughly before attempting any installation or repair to ensure proper function and safety.

2. SAFETY INFORMATION

- **Disconnect Power:** Always disconnect the washing machine from its power source before attempting any service or repair. Failure to do so can result in electric shock or serious injury.
- **Wear Protective Gear:** Wear appropriate personal protective equipment, such as gloves and safety glasses, to prevent injury during installation.
- **Professional Assistance:** If you are unsure about any step of the installation process, it is recommended to seek assistance from a qualified appliance repair technician.
- **Water Drainage:** Ensure all water is drained from the washer before beginning the pump replacement to prevent spills and potential electrical hazards.
- **Sharp Edges:** Be aware of sharp edges on internal components of the washing machine.

3. PRODUCT OVERVIEW

The Owigift Washer Water Drain Pump Motor is a critical component responsible for removing water from your washing machine's tub during the drain cycle. This replacement part ensures efficient water expulsion, preventing issues such as standing water and error codes like "LD" or "F32". It is constructed from durable materials, including stainless steel and acrylonitrile butadiene styrene (ABS), designed for reliable performance.



Image 1: Front view of the Owigift Washer Water Drain Pump Motor, showing the main housing and hose connections.



Image 2: Angled view of the Owigift Washer Water Drain Pump Motor, highlighting the motor assembly and mounting brackets.

4. COMPATIBILITY

This Owigift Washer Water Drain Pump Motor is compatible with various Maytag, Kenmore, and Whirlpool washing machine models. Please verify your washer's model number against the list below to ensure compatibility.

Compatible Maytag Models:

- MVWB700BW0
- MVWB725BG0
- MVWB725BW0
- MVWB750YW0
- MVWB850YG0
- MVWB850YW0
- MVWB880BW0
- MVWB950YG0
- MVWB950YW0
- MVWB980BG0
- MVWB980BW0

Compatible Whirlpool Models:

- WTW7800XW1
- WTW6700TW0
- WTW6200SW1
- WTW6200SW2
- WTW6200VW1
- WTW6300SW0
- WTW6300SW1
- WTW6300SW2
- WTW6300WW0

Compatible Kenmore Models:

- 11027086600
- 11028081700
- 11028062800
- 11027032602
- 11027042603
- 11028032701
- 11027062600
- 11028087700
- 11027062601
- 11027062602

Note: If your model number is not listed or you are unsure about compatibility, please contact the seller for assistance.

5. SPECIFICATIONS

Problem/Error Code	Possible Cause	Solution
Part Number	W10536347 (Replaces AP5650269, W10217134, W10281682, PS5136124)	
Material	Stainless Steel, Acrylonitrile Butadiene Styrene (ABS)	
Power Source	DC	
Voltage	120 Volts	
Color	Black	
Package Dimensions	8.32in x 6.15in (approximate)	
Included Components	1 x W10536347 Washer Drain Pump Assembly, 3 x Mounting Screws	

6. SETUP AND INSTALLATION

Replacing a washer drain pump motor requires careful attention to safety and proper procedure. The following steps provide a general guide. Always refer to your specific washing machine's service manual for detailed instructions.

1. **Prepare for Installation:**
 - Disconnect the washer from the electrical outlet.

- Turn off the water supply to the washer.
- Move the washer away from the wall to access the rear.
- Drain any remaining water from the washer tub and hoses.

2. Access the Drain Pump:

- Depending on your washer model, you may need to remove the front panel, rear panel, or tilt the washer back to access the drain pump.
- Locate the drain pump, typically at the bottom of the washer.

3. Disconnect Old Pump:

- Carefully disconnect the electrical wiring harness from the old pump.
- Remove the hoses connected to the pump. Be prepared for residual water.
- Unscrew or unclip the old pump from its mounting brackets.

4. Install New Pump:

- Position the new Owigift drain pump motor in place and secure it with the provided mounting screws or clips.
- Reconnect the hoses to the new pump, ensuring they are securely fastened to prevent leaks.
- Reconnect the electrical wiring harness to the new pump.

5. Test and Reassemble:

- Before reassembling the washer panels, restore the water supply and power.
- Run a short drain cycle or a small wash cycle to check for leaks and proper pump operation.
- Once confirmed, reattach any removed panels and push the washer back into its position.

Your browser does not support the video tag.

Video 1: A general guide demonstrating the unboxing and overview of a W10536347 Washer Drain Pump Assembly, similar to the Owigift product. This video provides visual context for the component.

7. OPERATING INSTRUCTIONS

The drain pump motor operates automatically as part of your washing machine's cycle. Its primary function is to remove water from the wash tub after the wash and rinse cycles, preparing the clothes for the spin cycle. No direct user interaction is required for the pump's operation once correctly installed.

- Ensure the washer is properly loaded and the correct wash cycle is selected.
- The pump will activate during the drain phases of the cycle.
- Listen for unusual noises during the drain cycle, which could indicate an issue (refer to Troubleshooting).

8. MAINTENANCE

Regular maintenance of your washing machine can help prolong the life of the drain pump motor and prevent common issues.

- **Clean the Drain Filter:** Many washing machines have a drain pump filter that can become clogged with lint, coins, or small items. Consult your washer's user manual for instructions on how to locate and clean this filter regularly.
- **Inspect Hoses:** Periodically check the drain hoses for kinks, blockages, or damage. Ensure they are properly connected and not leaking.
- **Avoid Overloading:** Overloading the washing machine can put undue stress on the pump and other components.
- **Use Proper Detergent:** Use only high-efficiency (HE) detergent in HE washers to prevent excessive suds that can hinder drainage.

9. TROUBLESHOOTING

If your washing machine is experiencing drainage issues after installing the new pump, consider the following common problems and solutions:

Problem/Error Code	Possible Cause	Solution
Washer not draining / Error Code "LD" or "F32"	◦ Clogged drain pump filter. ◦ Kinked or blocked drain hose. ◦ Improper installation of the new pump. ◦ Faulty water level sensor (less common after pump replacement).	◦ Clean the drain pump filter (refer to your washer's manual). ◦ Check and straighten the drain hose; clear any blockages. ◦ Re-check all connections and mounting of the new pump. Ensure no debris is in the pump impeller. ◦ If issues persist, consult a professional technician.
Unusual noise during drain cycle	◦ Debris in the pump impeller. ◦ Loose mounting of the pump. ◦ Pump motor malfunction.	◦ Disconnect power, access the pump, and check for foreign objects in the impeller. ◦ Ensure the pump is securely mounted. ◦ If noise continues after checking for debris and secure mounting, the pump may be faulty.
Water leaking from pump area	◦ Loose hose connections. ◦ Damaged hoses or seals. ◦ Cracked pump housing.	◦ Tighten all hose clamps and connections. ◦ Inspect hoses and seals for damage and replace if necessary. ◦ If the pump housing is cracked, the pump needs replacement.

10. WARRANTY AND SUPPORT

This Owigift product is designed for quality and reliability. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For any questions regarding compatibility, installation, or troubleshooting that are not covered in this manual, please contact the seller directly. The seller aims to respond to inquiries within 24 hours to assist you with your product.

Contact Information: Refer to your purchase documentation or the online retailer's platform for seller contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B098XVY2CB>

More documents and user manuals: <https://manuals.plus/>