

[Manuals.plus](#) /

› [HASBRO](#) /

› HASBRO FurReal Dazzlin' Dimples My Playful Dolphin Interactive Electronic Pet F2401 Instruction Manual

HASBRO F2401

HASBRO FurReal Dazzlin' Dimples My Playful Dolphin Interactive Electronic Pet F2401 Instruction Manual

Brand: HASBRO | Model: F2401

INTRODUCTION

Welcome to the world of FurReal Dazzlin' Dimples My Playful Dolphin! This interactive electronic pet offers over 80 sounds and movements, providing a lifelike and engaging play experience. Your dolphin friend responds to your actions with various sounds and motions, making playtime dynamic and fun.

Interact with your dolphin by feeding it its fish snack, grooming its soft body with the included brush, or gently stroking its tail. It will respond with happy sounds and movements. You can also roll the included ball towards its flipper, and it will try to hit it back. Give your dolphin a gentle kiss on its nose, and it will kiss you back, showing its affection with a soft glow on its cheeks.

The Dazzlin' Dimples Dolphin also features a special Night Mode, where it plays soothing ocean sounds to help you relax and fall asleep together. This product is designed for ages 4 and up.



Image: The FurReal Dazzlin' Dimples My Playful Dolphin, a blue interactive plush toy with star patterns.

SAFETY INFORMATION

WARNING: This product contains small parts and a ball. Choking hazard. Not suitable for children under 3 years of age.
Do not immerse in water. Doing so may cause malfunction or damage to the product.

WHAT'S INCLUDED

- 1 x FurReal Dazzlin' Dimples My Playful Dolphin interactive plush toy
- 1 x Fish snack accessory
- 1 x Grooming brush accessory
- 1 x Play ball accessory
- 4 x AAA alkaline batteries (for demo purposes)



Image: The product packaging showing the dolphin toy and its accessories.

SETUP

Battery Installation

1. Locate the battery compartment on the underside of the dolphin.
2. Using a Phillips head screwdriver, open the battery compartment cover.
3. Insert 4 new AAA alkaline batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.
5. The dolphin includes demo batteries. For optimal performance, replace them with fresh alkaline batteries.

Power On/Off

To turn on your Dazzlin' Dimples Dolphin, locate the power switch, usually near the battery compartment. Flip the switch to the "ON" position. To turn off, flip the switch to the "OFF" position.

OPERATING INSTRUCTIONS

Your FurReal Dazzlin' Dimples Dolphin is designed to be highly interactive. Explore its various reactions by engaging with it in different ways.

Interactive Play Modes

- **Feeding:** Offer the fish snack to your dolphin's mouth. It will make eating sounds and movements.



Image: A child feeding the dolphin with its fish accessory.

- **Grooming:** Gently brush your dolphin's soft body with the included brush. It will respond with happy sounds and movements.
- **Tail Interaction:** Gently stroke or pat your dolphin's tail. It will wag its tail and make playful sounds.
- **Belly Tickle:** Gently tickle your dolphin's belly. It will react with cute sounds and movements.
- **Ball Play:** Roll the included ball towards your dolphin's flipper. It will attempt to hit the ball back with its flipper, mimicking a dolphin show.



Image: A child playing with the dolphin and its ball accessory.

- **Nose Kiss:** Gently press your nose against your dolphin's nose. It will respond with a kiss sound and its cheeks will glow pink, showing affection.



Image: A child gently touching noses with the dolphin, which responds with a glowing cheek.

Night Mode

To activate Night Mode, gently hug your dolphin. It will play soothing ocean sounds, helping you relax and drift off to sleep.



Image: A child hugging the dolphin, which is in Night Mode, playing calming sounds.

Demonstration Videos

Watch this video for a demonstration of how to interact with a similar FurReal dolphin toy, showcasing various playful responses.

Your browser does not support the video tag.

Video: A child interacting with a FurReal unicorn dolphin, demonstrating feeding and petting actions.

This video provides a general overview of FurReal interactive pets, highlighting their engaging movements and sounds.

Your browser does not support the video tag.

Video: A general promotional video for FurReal pets, showing various animals dancing and interacting.

MAINTENANCE

Cleaning

To clean your Dazzlin' Dimples Dolphin, gently wipe the surface with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the toy is completely dry before storing or playing with it again.

As mentioned in the safety warnings, do not immerse the toy in water.

Storage

When not in use for extended periods, turn off the toy and remove the batteries to prevent leakage and damage. Store the toy in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **No Power/No Response:**
 - Ensure the power switch is in the "ON" position.
 - Check if the batteries are correctly installed with the proper polarity.
 - Replace old batteries with fresh AAA alkaline batteries.
- **Limited Responses:**
 - Ensure you are interacting with the correct sensor areas (mouth for feeding, tail for wagging, nose for kissing).
 - Try turning the toy off and then on again to reset its functions.
 - Replace batteries if they are low.
- **Unusual Sounds or Movements:**
 - Turn the toy off and on again.
 - Replace batteries.
 - If the issue persists, contact customer support.

SPECIFICATIONS

Brand	HASBRO
Model Number	F2401
Product Type	Interactive Electronic Plush Toy
Character	Dolphin
Recommended Age	4 years and up
Power Source	4 x AAA Alkaline Batteries (demo batteries included)
Dimensions (L x W x H)	55.9 cm x 35.6 cm x 20.3 cm (22 x 14 x 8 inches)
Weight	1.8 kg (3.97 lbs)
Material Type	Plastic
Indoor/Outdoor Use	Indoor




Image: Diagram showing the length, width, and height of the dolphin toy.

WARRANTY

This product is covered by a limited warranty against manufacturing defects. Please refer to the warranty information provided with your purchase or visit the official HASBRO website for details. Keep your proof of purchase for warranty claims.

SUPPORT

For further assistance, troubleshooting, or product inquiries, please visit the official HASBRO customer support website or contact their customer service department. Contact information can typically be found on the product packaging or the HASBRO official website.

You can also visit the [Hasbro Japan Store on Amazon](#) for more information and products.