

[Manuals.plus](#) /

› [TIMMKOO](#) /

› TIMMKOO Q5 WiFi MP3 Player User Manual

TIMMKOO Q5

TIMMKOO Q5 WiFi MP3 Player

User Instruction Manual

1. PRODUCT OVERVIEW

The TIMMKOO Q5 is a versatile digital music and media player designed for an enhanced audio-visual experience. Featuring a 4.0-inch full touch screen, it supports high-resolution video playback and HiFi lossless music. The device offers extensive connectivity options including Wi-Fi and Bluetooth, alongside expandable storage for your media library. It also includes built-in functionalities such as FM radio, a voice recorder, an ebook reader, and a web browser.





Figure 1.1: Front view of the TIMMKOO Q5 MP3 Player, showcasing its 4.0-inch full touch screen interface with various application icons.

2. WHAT'S IN THE BOX

Upon unboxing your TIMMKOO Q5 MP3 Player, please ensure all the following components are present:

- TIMMKOO Q5 Bluetooth MP3 Player x 1
- USB-C Cable x 1
- Wired headphones x 1
- User Manual x 1 (This document)

3. DEVICE LAYOUT AND FEATURES

Familiarize yourself with the physical layout and key features of your TIMMKOO Q5 MP3 Player:

- **4.0-inch Full Touch Screen:** High-definition display for intuitive navigation and media consumption.
- **Power Button:** Located on the side, used for turning the device on/off and screen lock/unlock.
- **Volume Buttons:** Located on the side, for adjusting audio output levels.
- **USB-C Port:** Located at the bottom, for charging and data transfer.
- **3.5mm Headphone Jack:** Located at the bottom, for wired audio output.
- **Micro SD/TF Card Slot:** Located on the side, for expanding storage up to 512GB.
- **Built-in Speaker:** For direct audio playback without headphones.

Duplex Bluetooth 4.2

perfectly compatible with Bluetooth headphones, speakers, car stereo



Figure 3.1: The TIMMKOO Q5 MP3 Player highlighting its Duplex Bluetooth 4.2 capability, connecting seamlessly with various audio devices.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the device using the provided USB-C cable and a compatible power adapter (not included). The battery indicator on the screen will show charging status.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button on the side until the TIMMKOO logo appears.
- **To Power Off:** Press and hold the Power button until a power-off menu appears, then select 'Power off'.
- **Screen Lock/Unlock:** Briefly press the Power button to lock or unlock the screen.

Long Battery Life

Low-power solutions ensure your continuous music and movie enjoyment



 **1800**^{mAh} Capacity

 **50** Hrs Music

 **8** Hrs Video

Figure 4.1: The TIMMKOO Q5 MP3 Player features a built-in 1800mAh lithium battery, providing up to 50 hours of music playback or 8 hours of video playback on a single charge.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

The TIMMKOO Q5 features a full touch screen for intuitive control. Swipe left/right or up/down to navigate through menus and applications. Tap icons to open them. Use the navigation buttons at the bottom of the screen for Home, Back, and Recent Apps.

1080p & Full Touchscreen

Play high-definition video smoothly, Easy-to-operate interface



Figure 5.1: The 4-inch high-definition screen supports 720p and 1080p video playback, offering an excellent audio-visual experience.

5.2 Music Playback

The device supports various audio formats including MP3, WAV, FLAC, APE, OGG, M4A, AAC, WMA, and MP2.

- **Uploading Music:** Connect the device to your computer using the USB-C cable. Drag and drop music files into the designated folders on the device's internal storage or inserted Micro SD card.
- **Sorting and Playlists:** The powerful Music App allows you to sort songs by title, folder, albums, artists, genre, or album+artist. You can also create and manage playlists in batches.
- **Playback Modes:** Choose from shuffle all, sequential play, loop single, or list loop.
- **EQ Styles:** Preset 8 EQ styles for customized sound.

Perfect Song Classification

Provides a variety of song organization type including Title, Album, Artist, Genre, Album+Artist




Figure 5.2: The music application provides comprehensive song classification and organization features.

5.3 Video Playback

The Q5 supports 720p and 1080p high-resolution video playback. Upload videos by connecting the device to a computer via USB-C and dragging files to the video folder.

5.4 Bluetooth Connectivity

The device is equipped with full-featured duplex Bluetooth 4.2, ensuring stable compatibility with Bluetooth headphones, speakers, and car stereos.

- **Pairing:** Go to 'Settings' > 'Bluetooth', turn Bluetooth on, and select your desired device from the 'Available Devices' list to pair.

5.5 Wi-Fi Connectivity

The Wi-Fi functionality on the TIMMKOO Q5 is limited to specific uses:

- **Network Time Synchronization:** For accurate time and date settings.

- **File Transfer:** Use the provided File Transfer App to easily transfer files between your smartphone (especially Android devices) and the player.
- **Website Browsing:** The built-in browser allows for basic internet access.

Note: Wi-Fi is NOT for downloading music or apps online. The device does not support installing additional apps.



Figure 5.3: High-speed wireless transmission allows for quick transfer of music, videos, and pictures via the file transfer app.

5.6 FM Radio

The device includes an FM radio function. Navigate to the FM Radio app to scan for and listen to local stations.



Figure 5.4: The FM Radio interface allows for easy tuning and station management.

5.7 Recorder

Use the built-in recorder app to capture audio. This is useful for voice notes, lectures, or other audio recordings.




Figure 5.5: The Sound Recorder app provides a simple interface for audio capture.

5.8 Ebook Reader

The Q5 supports ebook reading. Transfer ebook files to the device and open them using the Ebook app for a portable reading experience.



Figure 5.6: The Ebook app allows you to read digital books directly on the device's screen.

5.9 Browser

Access the internet for basic web browsing through the pre-installed browser application. Remember, this is for browsing

only, not for downloading content.



Figure 5.7: The built-in browser provides access to the internet for general browsing.

5.10 Disabling/Uninstalling Apps

The TIMMKOO Q5 allows you to disable or uninstall certain pre-installed applications like FM Radio, Videos, Ebook, Browser, and Recorder to customize your device. This helps manage storage and personalize your experience.




Figure 5.8: You can disable or uninstall pre-installed apps to suit your specific needs.

5.11 Storage Management

The device comes with 8GB of internal storage and supports expandable storage up to 512GB via a Micro SD/TF card slot. This allows for a vast media library.



Figure 5.9: The built-in Micro SD/TF slot allows for significant expansion of device storage.

6. MAINTENANCE

To ensure the longevity and optimal performance of your TIMMKOO Q5 MP3 Player, follow these maintenance guidelines:

- Keep the device dry and away from extreme temperatures.
- Clean the screen and body with a soft, dry cloth. Avoid abrasive cleaners.
- Protect the screen from scratches using a screen protector.
- Avoid dropping the device or subjecting it to strong impacts.

- Charge the battery regularly, even if not in frequent use, to maintain battery health.

7. TROUBLESHOOTING

If you encounter issues with your TIMMKOO Q5 MP3 Player, try the following solutions:

Problem	Possible Cause	Solution
Device won't turn on	Low battery; System crash	Charge the device; Perform a hard reset (press and hold power button for 10-15 seconds).
Cannot connect to Wi-Fi	Incorrect password; Out of range; Wi-Fi limitations	Verify password; Move closer to router; Remember Wi-Fi is only for time sync, file transfer, browsing.
Bluetooth pairing issues	Device not in pairing mode; Interference	Ensure both devices are in pairing mode; Restart Bluetooth on both devices; Move away from other wireless devices.
Music/Video files not playing	Unsupported format; Corrupted file	Check supported formats (MP3, WAV, FLAC, etc. for audio; 720p/1080p for video); Try a different file.
Slow performance	Too many apps/files; Full storage	Disable/uninstall unused apps; Delete unnecessary files; Use an external Micro SD card for storage.

8. SPECIFICATIONS

- **Product Dimensions:** 0.5 x 2.36 x 4.17 inches
- **Item Weight:** 7.4 ounces
- **Manufacturer:** TIMMKOO
- **Item Model Number:** Q5
- **Batteries:** 1 Lithium Metal battery required (included)
- **Date First Available:** July 2, 2021
- **Model Name:** mp3 player with bluetooth
- **Special Features:** FM Radio, Quick Charge, Touch Screen, Website Browsing, WiFi
- **Connectivity Technology:** Aux, Bluetooth, USB, Wi-Fi
- **Memory Storage Capacity:** 72 GB (includes internal + bundled card)
- **Color:** Black
- **Screen Size:** 4 Inches
- **Compatible Devices:** Mac PC, Personal Computer
- **Media Type:** Micro SD, Micro SDHC, Micro SDXC

9. WARRANTY AND SUPPORT

For detailed warranty information and further technical support, please refer to the official TIMMKOO website or contact their customer service. A PDF version of this user manual is also available for download at

<https://manuals.plus/m/4d5415f221a47e3fc1b5de90aed3fdb300760f89cd298d5e9cf14fd3acbba33e>.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question