MSI MAG A650BN

MSI MAG A650BN 650W Non-Modular Power Supply User Manual

Model: MAG A650BN

Introduction | Safety Information | Package Contents | Features | Setup & Installation | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This user manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your MSI MAG A650BN 650W Non-Modular Power Supply. Please read this manual thoroughly before using the product to ensure proper functionality and safety.



Figure 1: MSI MAG A650BN Power Supply and Packaging

2. Safety Information

Always observe the following safety precautions to prevent injury and damage to your equipment:

- **Disconnect Power:** Always disconnect the power cord from the wall outlet before installing, removing, or cleaning the power supply.
- **Proper Grounding:** Ensure your computer system is properly grounded to prevent electrical shock.
- **Ventilation:** Do not block the ventilation openings of the power supply. Ensure adequate airflow around the unit.
- **Moisture:** Keep the power supply away from water, humidity, and other liquids.
- **Temperature:** Operate the power supply within the specified temperature range. Avoid extreme heat or cold.
- **Opening the Casing:** Do not open the power supply casing. High voltages are present inside, and opening it will void the warranty.
- **Professional Installation:** If you are unsure about any installation steps, consult a qualified technician.

3. Package Contents

Verify that all items are present in the package before proceeding with installation:

- MSI MAG A650BN 650W Power Supply
- AC Power Cord
- Mounting Screws
- User Guide



Figure 2: Package Contents of MSI MAG A650BN Power Supply

4. Key Features

- **80 PLUS Bronze Certified:** Ensures high power efficiency, reducing energy consumption and heat generation.



Figure 3: 80 PLUS Bronze Certification

- **120mm Low-Noise Fan:** Equipped with a sleeve bearing fan designed for quiet operation while maintaining effective heat dissipation.



Figure 4: 120mm Low-Noise Fan

- **DC-to-DC Circuit Design:** Utilizes a DC-DC circuit design to enhance output voltage stability and ensure a consistent power supply to components.



Figure 5: DC-to-DC Circuit Design

- **Comprehensive Circuit Protection:** Includes multiple protection mechanisms such as Over Current Protection (OCP), Over Voltage Protection (OVP), Short Circuit Protection (SCP), Over Power Protection (OPP), and Over Temperature Protection (OTP) for system safety.




Figure 6: Comprehensive Circuit Protection

- **Non-Modular Design:** All cables are permanently attached to the power supply unit.
- **Compact Size:** Designed to fit into various PC cases.
- **Active PFC (Power Factor Correction):** Improves power efficiency and reduces harmonic distortion.

5. Setup & Installation

Follow these steps to properly install your MSI MAG A650BN power supply into your computer system.

1. **Prepare Your System:**
    - Turn off your computer and disconnect the AC power cord from the wall outlet.
    - Open your computer case.
    - If replacing an existing power supply, disconnect all cables from the old PSU and remove it from the case.
2. **Mount the Power Supply:**
    - Carefully place the MSI MAG A650BN into the power supply bay of your computer case.

- Align the screw holes on the PSU with those on the case.
- Secure the power supply using the provided mounting screws.

3. **Connect Main Power Cables:**
   - Connect the 24-pin ATX main power connector to the corresponding port on your motherboard. Ensure it clicks into place.
   - Connect the 4+4-pin or 8-pin EPS/CPU power connector to the CPU power port on your motherboard.
4. **Connect Peripheral Power Cables:**
   - Connect SATA power cables to your storage drives (HDDs, SSDs) and optical drives.
   - Connect PCIe power cables (6+2-pin) to your graphics card(s) if required.
   - Connect Molex power cables to any other peripherals that require them (e.g., case fans, older devices).
5. **Cable Management:**
   - Organize the cables to improve airflow and aesthetics within your case. Use cable ties if necessary.
6. **Close the Case and Connect AC Power:**
   - Close your computer case.
   - Connect the AC power cord to the power supply's AC inlet and then to a grounded wall outlet.

6. Operation

Operating the MSI MAG A650BN power supply is straightforward once installed.

1. **Power On:**
   - Ensure the power switch on the back of the power supply is in the "ON" (I) position.
   - Press the power button on your computer case.
2. **Power Off:**
   - Shut down your computer through the operating system.
   - For complete power disconnection, switch the power supply's switch to the "OFF" (O) position and unplug the AC power cord from the wall outlet.

7. Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your power supply.

- **Dust Removal:** Periodically clean dust from the power supply's fan and ventilation grilles using compressed air. Ensure the system is powered off and unplugged before cleaning.
- **Cable Inspection:** Occasionally check all power cables for secure connections and signs of wear or damage.
- **Environment:** Ensure the computer is operated in a clean, dry, and well-ventilated environment to prevent dust buildup and overheating.

8. Troubleshooting

If you encounter issues with your MSI MAG A650BN power supply, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Computer does not power on.	AC power cord not connected. Power supply switch is OFF. Loose cable connections. Faulty power supply or component.	Ensure AC power cord is securely plugged into the PSU and wall outlet. Flip the power switch on the PSU to the "ON" (I) position. Check all internal power connections (24-pin, CPU, PCIe, SATA). Test with another known-good power supply if possible.
System powers on but shuts down unexpectedly.	Overload (OPP triggered). Overheating (OTP triggered). Short circuit (SCP triggered).	Ensure total power draw does not exceed 650W. Check for proper ventilation and clean any dust from the PSU fan. Inspect cables and components for any short circuits.
Loud fan noise from PSU.	Dust buildup in fan. Fan malfunction.	Clean the fan and ventilation grilles with compressed air. If noise persists, contact MSI support.

9. Specifications

Feature	Detail
Brand	MSI
Model Number	MAG A650BN
Item Model Number (Internal)	306-7ZP2B11-CE0
Wattage	650W
Efficiency Certification	80 PLUS Bronze
Form Factor	ATX
Power Supply Design	Non-Modular
Cooling Method	Air (120mm Low-Noise Fan)
Dimensions (LxWxH)	9.29 x 7.2 x 4.13 inches (23.6 x 18.3 x 10.5 cm)
Item Weight	2.2 pounds (1 kg)
Input Voltage	220V (Typical, check product label for full range)
Protection Features	OCP, OVP, SCP, OPP, OTP

10. Warranty & Support

The MSI MAG A650BN Power Supply comes with a **7-year limited warranty**, guaranteeing long-term reliable operation.

For technical support, warranty claims, or further assistance, please visit the official MSI website or contact their customer service department.

- **MSI Official Website:** www.msi.com
- **Support Contact:** Refer to the support section on the MSI website for regional contact information.

© 2023 MSI. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question