

[Manuals.plus](#) /

› [BISNIE](#) /

› BISNIE 12-Piece Square Air Fryer Accessories Set User Manual

BISNIE 5.5L - 6.5L Air Fryer Compatibility

BISNIE 12-Piece Square Air Fryer Accessories Set User Manual

Model: 5.5L - 6.5L Air Fryer Compatibility

1. INTRODUCTION

Thank you for choosing the BISNIE 12-Piece Square Air Fryer Accessories Set. This manual provides essential information for the safe and effective use of your new accessories. Please read it thoroughly before first use and keep it for future reference.

This set is designed to enhance your air frying experience, offering versatility for various cooking tasks. It is compatible with square air fryers ranging from 5.5 liters to 6.5 liters, including models like Philips 6.2L, COSORI 5.5L, COSORI 6L, COSORI 6.2L, and Cecotec 6L. Always measure your air fryer basket dimensions to ensure proper fit before purchase and use.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always use oven mitts or silicone gloves when handling hot accessories.
- Ensure accessories are properly placed and stable within the air fryer basket before cooking.
- Do not use abrasive cleaners or metal scouring pads on non-stick surfaces to prevent damage.
- Keep all accessories out of reach of children.
- Verify that accessories are suitable for the temperature settings of your air fryer.
- The cake barrel and pizza pan feature a Teflon non-stick coating; avoid using sharp metal utensils that could scratch the surface.

3. PACKAGE CONTENTS

Your BISNIE 12-piece air fryer accessories set includes the following items:

- 1 x 8-inch Square Non-Stick Cake Barrel
- 1 x 8-inch Non-Stick Pizza Pan
- 1 x 8-inch Skewer Rack with Skewers
- 1 x 8.1-inch Silicone Egg Bite Mold

- 100 x Square Air Fryer Parchment Liners
- 1 x 7.7-inch Metal Holder
- 1 x 7-inch Heat-Resistant Silicone Mat
- 1 x 9.1-inch Food Tong
- 1 x Toast Rack
- 1 x Silicone Oil Brush
- 1 x Silicone Spatula
- 2 x Silicone Oven Mitts

Ottimo per friggitrici ad aria calda Philips 6,2 L, COSORI 5,5 L, COSORI 6 L, COSORI 6,4 L, Cecotec 6 L



Figure 1: Overview of the 12-piece BISNIE Air Fryer Accessories Set.

4. SETUP AND FIRST USE

1. **Unpack:** Carefully remove all accessories from their packaging.

2. **Clean:** Wash all accessories with warm, soapy water before first use. Rinse thoroughly and dry completely. The cake barrel and pizza pan are coated with Teflon; avoid harsh scrubbing.
3. **Compatibility Check:** Before using any accessory, ensure it fits comfortably within your air fryer basket without touching the heating element or obstructing air circulation. This set is suitable for square air fryers with capacities between 5.5L and 6.5L.

5. OPERATING INSTRUCTIONS

5.1. Cake Barrel

Use the square non-stick cake barrel for baking cakes, bread, quiches, and other desserts. Pour batter into the barrel and place it inside the air fryer basket. Always use the silicone oven mitts when removing the hot barrel.

FORNO PER TORTE

Cuocere le più deliziose torte, pane e quiche. Ideale per la friggitrice ad aria quadrata.

22cm/8.5in

19.5cm/7.5in



TEGLIA PER PIZZA E TEGLIA DA FORNO

Preparate le più deliziose pizze, biscotti, torte dolci e salate.

20cm/8.0in



TAPPETINO IN SILICONE

Superficie resistente al calore per teglie, stampo per bocconcini d'uovo e scrivania.

18cm/7in



Figure 2: Cake Barrel for baking cakes, bread, and quiches.

5.2. Pizza Pan

The non-stick pizza pan is ideal for preparing pizzas, biscuits, and other flat baked goods. Place your pizza on the pan and insert it into the air fryer. Use the silicone oven mitts for safe handling.



Figure 3: Pizza Pan for pizzas, biscuits, and sweet or savory tarts.

5.3. Skewer Rack and Metal Holder

The skewer rack allows you to cook kebabs, barbecue items, hot dogs, and s'mores. The metal holder maximizes cooking space by allowing you to cook multiple layers or elevate items for better air circulation. Use the food tongs for easy handling of cooked items.

STAMPI MULTIUSO IN SILICONE DA 20,6 CM PER BOCCONCINI D'UOVO

- ✓ Compatibili con friggitrici ad aria, pentole a pressione, forni, microonde e congelatori
- ✓ Resistente alle temperature di 40°C - 218°C (104°F - 425°F)
- ✓ Silicone alimentare di prima qualità - senza tossine



Cubo di Ice



Morsi d'uovo



Cuocere cupcakes



Alimenti per bambini

Figure 4: Skewer Rack and Metal Holder for grilling and maximizing cooking area.

5.4. Silicone Egg Bite Mold

This versatile mold is compatible with air fryers, pressure cookers, ovens, microwaves, and freezers. It is made from food-grade silicone, resistant to temperatures from 40°C to 218°C (104°F - 425°F). Ideal for egg bites, cupcakes, and baby food portions.



Figure 5: Silicone Egg Bite Mold for versatile cooking and freezing.

5.5. Parchment Liners and Silicone Mat

The square parchment liners prevent food from sticking and make cleanup easier. The heat-resistant silicone mat can be used under hot accessories to protect surfaces or as a trivet.

5.6. Toast Rack

The toast rack allows you to toast multiple slices of bread simultaneously in your air fryer, ensuring even browning.

5.7. Food Tongs, Oil Brush, and Spatula

These tools are provided for convenient and safe handling of food and accessories. The silicone oil brush is perfect for applying oil or marinades, and the silicone spatula is ideal for mixing and serving without scratching non-stick surfaces.



Figure 6: Essential tools: Food Tongs, Oil Brush, and Spatula.

5.8. Official Product Video

Watch the official product video for a visual guide on how to use the BISNIE air fryer accessories.

Your browser does not support the video tag.

Video 1: Demonstration of BISNIE Air Fryer Accessories in use.

6. CARE AND MAINTENANCE

- **Cleaning:** Most accessories are dishwasher safe for quick and easy cleaning. For items with non-stick coatings (cake barrel, pizza pan), hand washing with a soft sponge and mild detergent is recommended to prolong their lifespan.
- **Drying:** Ensure all accessories are completely dry before storing to prevent rust or mildew.
- **Storage:** Store accessories in a clean, dry place.

- **Non-stick Coating Care:** To protect the Teflon coating on the cake barrel and pizza pan, avoid using rough cloths, metal balls, or sharp utensils for cleaning or cooking.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Accessory does not fit in air fryer.	Incorrect size for your air fryer model.	Verify your air fryer's internal dimensions against the accessory sizes (8-inch square for most items). This set is for 5.5L-6.5L square air fryers.
Food sticking to non-stick surfaces.	Non-stick coating damaged or insufficient oil/grease.	Ensure proper care of non-stick surfaces (no metal utensils, harsh scrubbing). Lightly grease the surface before cooking.
Accessories are difficult to clean.	Food residue baked on.	Soak accessories in warm, soapy water before cleaning. For stubborn residue, use a soft brush or sponge.

8. SPECIFICATIONS

- **Brand:** BISNIE
- **Model Compatibility:** Square Air Fryers 5.5L - 6.5L (e.g., Philips 6.2L, COSORI 5.5L/6L/6.2L, Cecotec 6L)
- **Material:** Food-grade Plastic, Metal (Stainless Steel), Silicone (BPA-free, Teflon non-stick coating on specific items)
- **Color:** Black (accessories), Silver (metal racks)
- **Package Weight:** Approximately 1.61 kg
- **Key Accessory Dimensions:**
 - Cake Barrel: 8 inches (square)
 - Pizza Pan: 8 inches (round)
 - Skewer Rack: 8 inches (round)
 - Egg Bite Mold: 8.1 inches (flower shape)
 - Metal Holder: 7.7 inches
 - Silicone Mat: 7 inches (round)
- **Temperature Resistance (Silicone):** 40°C - 218°C (104°F - 425°F)

9. WARRANTY AND SUPPORT

BISNIE is committed to providing high-quality products. If you encounter any issues or have questions regarding your air fryer accessories set, please contact our customer support. We value your experience and are available to assist you. For support, please refer to the contact information provided with your purchase or visit the official BISNIE website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0993HX141>

More documents and user manuals: <https://manuals.plus/>