realme Narzo 30 5G (RMX3242)

realme Narzo 30 5G Smartphone

USER MANUAL

1. Introduction

This manual provides essential information for the safe and efficient use of your realme Narzo 30 5G smartphone. Please read it thoroughly before using the device to ensure optimal performance and longevity.

The realme Narzo 30 5G is a powerful smartphone featuring a 2.2 GHz Octa-core processor, 6GB of RAM, and 128GB of internal storage, expandable via microSDXC. It operates on Android 11 and is powered by a 5000mAh non-removable battery, supporting 5G connectivity.

2. What's in the Box

Upon unboxing your realme Narzo 30 5G, please verify that all the following items are present:

- realme Narzo 30 5G Smartphone
- USB Cable
- Quick Start Guide (may vary by region)
- SIM Ejector Tool (may vary by region)

3. Device Overview

Familiarize yourself with the physical components of your realme Narzo 30 5G smartphone.



realme

Figure 3.1: Front View. Displays the 6.5-inch IPS LCD screen, front camera cutout, and earpiece speaker.





Figure 3.2: Rear View. Shows the triple camera module (48MP main, 2MP macro, 2MP depth), LED flash, and realme branding.





Figure 3.3: Side View. Illustrates the power button (with integrated fingerprint sensor) and volume rocker on the right side, and the SIM tray on the left side.



Figure 3.4: Top and Bottom View. Displays the 3.5mm audio jack, USB-C charging port, microphone, and speaker grille at the bottom,

and a secondary microphone at the top.

4. Setup

4.1. Inserting SIM Cards and microSD Card

1. Locate the SIM tray on the left side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray. Ensure the gold contacts face downwards.
4. Carefully push the tray back into the slot until it is flush with the phone's body.

4.2. Initial Power On

Press and hold the Power button (located on the right side) until the realme logo appears on the screen. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

4.3. Charging the Device

Connect the USB cable to the USB-C port at the bottom of your phone and the other end to a compatible power adapter. Plug the adapter into a power outlet. The battery indicator on the screen will show the charging status. For optimal battery life, use the provided USB cable.

5. Operating Your Device

5.1. Basic Navigation

- **Tap:** Touch an icon or option to select it.
- **Swipe:** Drag your finger across the screen to scroll or navigate between screens.
- **Pinch:** Use two fingers to zoom in or out on photos and web pages.
- **Long Press:** Press and hold an item for more options.

5.2. Making Calls

Open the Phone app, enter the desired number using the dial pad, and tap the call icon. To answer an incoming call, swipe up on the green answer icon. To reject, swipe up on the red reject icon.

5.3. Sending Messages

Open the Messages app, tap the 'Start chat' or '+' icon, enter the recipient's number or select from contacts, type your message, and tap the send icon.

5.4. Camera Usage

Open the Camera app. Select your desired mode (Photo, Video, Portrait, Night, etc.). Tap the shutter button to capture a photo or start/stop video recording. Use the toggle to switch between front and rear cameras.

5.5. Connectivity

- **Wi-Fi:** Go to Settings > Wi-Fi, turn on Wi-Fi, and select a network to connect.
- **Bluetooth:** Go to Settings > Bluetooth, turn on Bluetooth, and pair with nearby devices.
- **Mobile Data (5G):** Ensure your SIM card supports 5G and your plan includes 5G data. Go to Settings > Mobile

network > Preferred network type and select 5G.

5.6. Security Features

- **Fingerprint Unlock:** Register your fingerprint(s) in Settings > Fingerprint, Face & Passcode. The sensor is integrated into the power button.
- **Face Unlock:** Register your face data in Settings > Fingerprint, Face & Passcode.
- **Screen Lock:** Set up a PIN, pattern, or password for screen lock in Settings > Fingerprint, Face & Passcode.

6. Maintenance

6.1. Cleaning Your Device

Use a soft, lint-free cloth to gently wipe the screen and body of the phone. Avoid using harsh chemicals or abrasive materials. Do not expose the device to excessive moisture.

6.2. Software Updates

Regularly check for system updates to ensure your device has the latest features, security patches, and performance improvements. Go to Settings > Software Update to check for and install available updates.

6.3. Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Do not leave the phone charging for extended periods after it reaches 100%.
- Use only realme-approved chargers and cables.

6.4. Storage Management

To optimize performance, regularly clear unnecessary files, uninstall unused apps, and move large media files to cloud storage or an external microSD card. Go to Settings > Storage to manage your device's storage.

7. Troubleshooting

7.1. Common Issues

- **Phone not turning on:** Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
- **Network issues:** Check if SIM card is properly inserted. Restart the phone. Verify network settings and contact your service provider if issues persist.
- **Apps crashing/freezing:** Close the app and reopen. Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). Update the app from the Play Store.
- **Slow performance:** Close background apps. Clear cache. Free up storage space. Restart the device.

7.2. Factory Reset

If persistent issues occur, a factory reset may be necessary.**Warning: This will erase all data on your phone. Back up important data before proceeding.** Go to Settings > System > Reset options > Erase all data (factory reset) and follow the on-screen instructions.

8. Specifications

Feature	Specification
Model Number	RMX3242
Dimensions	162.5 x 74.8 x 8.5 mm (6.40 x 2.94 x 0.33 in)
Weight	185 g (6.53 oz)
Display	6.5 inches, IPS LCD, 1080 x 2400 pixels
Operating System	Android 11
Processor	Mediatek Dimensity 700 (7 nm), Octa-core (2x2.2 GHz Cortex-A76 & 6x2.0 GHz Cortex-A55)
RAM	6 GB
Internal Storage	128 GB
Expandable Storage	microSDXC (dedicated slot)
Rear Camera	48 MP (wide), 2 MP (macro), 2 MP (depth)
Front Camera	16 MP (wide)
Battery	5000 mAh, non-removable
Charging	USB-C
Audio Jack	3.5 mm
Connectivity	5G, Wi-Fi, Bluetooth

9. Warranty and Support

Your realme Narzo 30 5G smartphone comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. For technical support, service, or further inquiries, please visit the official realme website or contact realme customer service in your region. Keep your proof of purchase for warranty claims.

© 2025 realme. All rights reserved.