

Nike Ck3314-400

Nike W Air Force 1 '07 Nxn Womens Ck3314-400 Shoes

INSTRUCTION MANUAL

Introduction

This manual provides essential information for the proper use, care, and maintenance of your Nike W Air Force 1 '07 Nxn Womens Ck3314-400 shoes. Designed for comfort and style, these shoes feature a durable rubber sole and a distinctive aesthetic. Please read this manual thoroughly to ensure optimal performance and longevity of your footwear.

Setup

Your Nike Air Force 1 '07 Nxn shoes are ready to wear directly out of the box. Follow these simple steps for initial setup:

1. **Unboxing:** Carefully remove the shoes from their packaging. Inspect them for any visible defects or damage.
2. **First Fit:** Try on both shoes with the type of socks you typically wear. Ensure a comfortable fit, with enough room for your toes to wiggle slightly. The lacing should be snug but not overly tight.
3. **Lacing:** Adjust the laces to achieve a secure and comfortable fit across the top of your foot. You can experiment with different lacing patterns to find what works best for your foot shape.



Image: Front view of the Nike W Air Force 1 '07 NxN shoes, showcasing the blue corduroy upper and lime green accents.

Operating (Wearing)

The Nike Air Force 1 '07 NxN shoes are designed for everyday casual wear and light athletic activities. Their durable construction provides support and comfort.

- **Daily Use:** These shoes are suitable for walking, casual outings, and general daily activities.
- **Surface Compatibility:** The rubber sole provides good traction on various dry surfaces. Exercise caution on wet or slippery surfaces.
- **Break-in Period:** New shoes may feel stiff initially. A short break-in period of a few wears will allow the materials to conform to your foot, enhancing comfort.



Image: Side profile of the Nike W Air Force 1 '07 NxN shoe, highlighting the corduroy texture and the iconic Nike swoosh.

Maintenance

Proper care will extend the life and maintain the appearance of your Nike Air Force 1 '07 NxN shoes.

- **Cleaning the Upper:** For the corduroy and synthetic leather upper, gently brush off loose dirt with a soft brush. For stains, use a mild soap solution and a soft cloth, dabbing gently. Avoid harsh chemicals or abrasive cleaners. Allow to air dry completely away from direct heat.
- **Cleaning the Sole:** The rubber sole can be cleaned with a brush and mild soap and water. Remove any debris from the tread pattern to maintain traction.
- **Drying:** Never machine wash or machine dry your shoes. Always air dry them at room temperature. You can stuff them with paper towels to help absorb moisture and maintain shape.
- **Storage:** Store shoes in a cool, dry place away from direct sunlight. If storing for extended periods, consider using shoe trees to help maintain their shape.



Image: Underside view of the shoe's rubber sole, showing the circular pivot points and traction pattern.

Troubleshooting

Here are solutions to common issues you might encounter:

- **Shoes feel too tight/loose:** Adjust lacing. Ensure you are wearing appropriate socks. If issues persist, consider consulting a shoe sizing guide or trying a different size.
- **Squeaking noise:** New shoes may sometimes squeak due to friction between parts or the sole and certain surfaces. This often resolves with wear. Ensure insoles are properly seated.
- **Odor:** To prevent odor, allow shoes to air out after each wear. You can use shoe deodorizers or sprinkle baking soda inside and let it sit overnight. Ensure shoes are completely dry before storage.
- **Discoloration:** Avoid prolonged exposure to direct sunlight or harsh chemicals which can cause material discoloration. Follow cleaning instructions carefully.

Specifications

Key specifications for the Nike W Air Force 1 '07 Nxn Womens Ck3314-400 shoes:

- **Model:** Ck3314-400
- **Department:** Womens
- **Sole Material:** Rubber
- **Closure Type:** Lace-Up
- **First Available:** August 7, 2020

Size Guide (US Women's Shoes - Narrow)

Brand Size	UK Size	EU Size	Heel to toe (in)	Shoe Width (in)
4	1.5	34.5	7.9	2.8
4.5	2	35	8.2	2.8
5	2.5	35.5	8.5	2.8
5.5	3	36	8.8	2.8
6	3.5	36.5	8.9	2.9
6.5	4	37.5	9.1	3
7	4.5	38	9.3	3.1
7.5	5	38.5	9.4	3.1
8	5.5	39	9.5	3.2
8.5	6	40	9.7	3.2
9	6.5	40.5	9.9	3.3
9.5	7	41	10	3.3
10	7.5	42	10.2	3.4
10.5	8	42.5	10.3	3.5
11	8.5	43	10.5	3.5
11.5	9	44	10.7	3.6
12	9.5	44.5	10.9	3.6
12.5	10	45	11.1	3.6
13	10.5	45.5	11.3	3.6
13.5	11	46	11.5	3.6
14	11.5	47	11.7	3.6
14.5	12	47.5	11.9	3.6
15	12.5	48	12.1	3.6
15.5	13	48.5	12.3	3.6
16	13.5	49	12.5	3.6
16.5	14	50	12.7	3.6
17	14.5	50.5	12.9	3.6
17.5	15	51	13.1	3.6
18	15.5	51.5	13.3	3.6
18.5	16	52	13.5	3.6

Warranty and Support

For information regarding warranty coverage, returns, or additional product support, please refer to the official Nike website or contact Nike customer service directly. Keep your proof of purchase for any warranty claims.

Online Support: Visit nike.com/help

Customer Service: Refer to the contact information provided on the Nike website for phone or chat support.