

[Manuals.plus](#) /

› [Dazzle Bright](#) /

› Dazzle Bright 300 LED Warm White Christmas String Lights Instruction Manual

Dazzle Bright HB-300COI

Dazzle Bright 300 LED Warm White Christmas String Lights

Model: HB-300COI

Brand: Dazzle Bright

INTRODUCTION

Thank you for choosing Dazzle Bright 300 LED Warm White Christmas String Lights. This manual provides essential information for the safe and effective use of your new lighting product. Please read these instructions carefully before installation and operation.




Image: The Dazzle Bright 300 LED Warm White Christmas String Lights are shown coiled, highlighting their compact form and the included power adapter.

SAFETY INFORMATION

- Use only the UL-certified 29V low-voltage plug provided with the product.
- Do not open the unit or attempt to repair it. Refer to qualified personnel for service.
- This product has an IP44 waterproof rating, making it suitable for both indoor and outdoor use. However, ensure the power adapter is protected from direct water exposure.
- Always unplug the lights from the power source before installation, maintenance, or when not in use.
- Keep away from heat sources and open flames.

PACKAGE CONTENTS

- 1 x Dazzle Bright 300 LED Warm White String Lights (Model: HB-300COI)
- 1 x UL-certified 29V Low-Voltage Plug

SPECIFICATIONS

Feature	Detail
---------	--------







Model Number	HB-300COI
Light Color	Warm White
Number of LEDs	300
Total Length	115 Feet (16.5 FT leading wire, 98.5 FT light string)
Bulb Spacing	3.9 inches
Wire Color	Green
Voltage	29 Volts (Low Voltage)
Wattage	8 watts
Waterproof Rating	IP44
Controller Type	Button on Plug
Connectable	Up to 4 light strings (Max 1200 LED)

SETUP INSTRUCTIONS

- 1. Unpack the Lights:** Carefully uncoil the string lights from the packaging. Avoid tangling the wire.
- 2. Placement:** Determine your desired location for the lights. These lights are suitable for both indoor and outdoor use. For outdoor installations, ensure the power adapter is placed in a dry, protected area.
- 3. Connecting Multiple Strands (Optional):** If you wish to connect multiple sets of Dazzle Bright string lights, locate the male and female connectors at the ends of each string. Remove the end cap from the female connector of the first string and the adapter from the male connector of the subsequent string. Connect the male end of one string to the female end of another. You can connect up to 4 light strings (maximum 1200 LEDs total).

8 function modes:

- 1 combination
- 2 inwaves
- 3 sequential
- 4 slogs
- 5 chasing/flash
- 6 slow fade
- 7 twinkle/flash
- 8 steady on



remove the adapter

remove the cap
of the end plug

connect the end
plug together




Image: A diagram illustrates the process of connecting multiple string lights, showing how to remove the adapter and end cap, and then join the plugs. It also lists the 8 function modes.

4. **Power Connection:** Plug the UL-certified 29V low-voltage adapter into a standard electrical outlet.

OPERATING INSTRUCTIONS

Once the lights are plugged in, they will illuminate in the last selected mode. To change the lighting mode, press the button located on the power adapter.

8 Lighting Modes:

1. Combination
2. In Waves
3. Sequential
4. Slogs (Slow Glow)
5. Chasing/Flash
6. Slow Fade
7. Twinkle/Flash
8. Steady On

Your browser does not support the video tag.

Video: This video demonstrates the Dazzle Bright Warm White Christmas String Lights in various settings, showcasing their warm glow and versatility for holiday decorations.

Your browser does not support the video tag.

Video: A brief overview of the Dazzle Bright Warm White String Lights, highlighting their appearance and ease of use for festive lighting.

MAINTENANCE

- **Cleaning:** Disconnect the lights from the power source. Gently wipe the LEDs and wires with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, carefully coil the string lights and store them in their original packaging or a dry, cool place away from direct sunlight. Avoid tightly wrapping the wires to prevent damage.
- **Inspection:** Before each use, inspect the entire string for any signs of damage, such as frayed wires, cracked bulbs, or loose connections. Do not use damaged lights.

TROUBLESHOOTING

- **Lights Not Turning On:**
 - Ensure the power adapter is securely plugged into a working electrical outlet.
 - Check if the power outlet is functional by plugging in another device.
 - Verify that all connections between multiple strands are secure.
- **Modes Not Changing:**
 - Press the button on the power adapter firmly.
 - If using multiple connected strands, ensure the button on the primary adapter is being pressed.
- **Partial Sections Not Lighting:**
 - Inspect the unlit section for any visible damage to the wires or individual LEDs.
 - Ensure connections between strands are fully inserted and secure.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Dazzle Bright customer service directly. Keep your purchase receipt for warranty claims.