

AUKEY PC-LM3

AUKEY PC-LM3 Webcam User Manual

Model: PC-LM3

1. INTRODUCTION

Thank you for purchasing the AUKEY PC-LM3 Webcam. This manual provides detailed instructions for setting up, operating, and maintaining your webcam. Please read this manual thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

- Keep the webcam away from water, moisture, and extreme temperatures.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Avoid dropping or subjecting the webcam to strong impacts.
- Clean the lens with a soft, dry cloth. Do not use liquid cleaners.

3. PACKAGE CONTENTS

Please check that all items are present in your package:

- AUKEY PC-LM3 Webcam
- User Manual
- USB Cable (integrated)



Image 1: Contents of the AUKEY PC-LM3 Webcam package, showing the webcam, manual, and packaging.

4. PRODUCT OVERVIEW

The AUKEY PC-LM3 is a 1080p USB 2.0 webcam designed for high-quality video communication and recording. It features a CMOS sensor and 5x optical zoom capability, providing clear and detailed visuals.



Image 2: AUKEY PC-LM3 Webcam in use, demonstrating its compact design and mounting flexibility on a tripod.

Key Features:

- Full HD 1080p video recording
- CMOS sensor for clear images
- USB 2.0 connectivity for universal compatibility
- 5x optical zoom for detailed framing
- Integrated microphone for audio capture
- Adjustable clip for versatile mounting options

5. SETUP

5.1 Placing the Webcam

1. **On a Monitor:** Unfold the clip and place the webcam on top of your monitor or laptop screen. Adjust the clip to secure it firmly.

2. **On a Tripod:** The webcam features a standard tripod thread. Mount it onto a compatible tripod for more flexible positioning.
3. **On a Flat Surface:** Fold the clip to form a stable stand and place the webcam on a desk or other flat surface.

5.2 Connecting to Your Computer

1. Plug the USB connector of the webcam into an available USB 2.0 or 3.0 port on your computer.
2. Your computer should automatically detect and install the necessary drivers. This process may take a few moments.
3. Once installed, the webcam will be ready for use with video conferencing software or recording applications.

Note: No additional software or drivers are typically required for Windows, macOS, or Linux operating systems.

6. OPERATING THE WEBCAM

6.1 Using with Video Conferencing Software

To use the AUKEY PC-LM3 webcam with applications like Zoom, Skype, Microsoft Teams, or Google Meet:

1. Open your preferred video conferencing application.
2. Navigate to the application's settings or preferences (usually found under "Audio & Video" or "Devices").
3. Select "AUKEY PC-LM3" as your video input device.
4. Select "AUKEY PC-LM3 Microphone" (or similar) as your audio input device, if applicable.
5. Adjust any video settings such as resolution or brightness within the application if available.

6.2 Recording Video

To record video using the webcam, use your computer's built-in camera application (e.g., Camera app on Windows, Photo Booth on macOS) or third-party recording software. Ensure the AUKEY PC-LM3 is selected as the video source.

6.3 Optical Zoom

The webcam features 5x optical zoom. This function is typically controlled via software. Check your video conferencing or recording application for zoom controls. If not available, third-party webcam control software may offer this functionality.

7. MAINTENANCE

7.1 Cleaning the Webcam

- Ensure the webcam is disconnected from your computer before cleaning.
- Use a soft, lint-free cloth to gently wipe the lens and body of the webcam.
- For stubborn smudges on the lens, slightly dampen the cloth with water or a lens cleaning solution, then wipe gently. Avoid excessive moisture.
- Do not use harsh chemicals, abrasive cleaners, or solvents.

7.2 Storage

When not in use, store the webcam in a cool, dry place, away from direct sunlight and dust. Consider using a privacy cover (if included or purchased separately) to protect the lens and ensure privacy.

8. TROUBLESHOOTING

Problem	Solution
Webcam not detected by computer.	<ul style="list-style-type: none">• Try plugging the webcam into a different USB port.• Restart your computer.• Ensure the USB cable is securely connected.• Check your computer's Device Manager (Windows) or System Information (macOS) to see if the webcam is listed.
No video output.	<ul style="list-style-type: none">• Ensure the webcam is selected as the video input device in your application settings.• Check if any privacy covers are blocking the lens.• Verify that the application has permission to access the camera in your operating system's privacy settings.
Poor video quality.	<ul style="list-style-type: none">• Ensure adequate lighting in your environment.• Clean the webcam lens.• Check your application's video settings for resolution and quality options.• Ensure your internet connection is stable if streaming video.

9. SPECIFICATIONS

Feature	Detail
Model	PC-LM3
Video Resolution	1920 x 1080 pixels (1080p)
Sensor Technology	CMOS
Connectivity	USB 2.0
Optical Zoom	5x
Video Capture Format	MP4, AVI
Supported Audio Format	AAC, MP3
Dimensions (L x W x H)	7.7 x 7.2 x 4.6 cm
Weight	130 grams
Color	Black

10. WARRANTY AND CUSTOMER SUPPORT

AUKEY products are covered by a limited warranty from the date of purchase. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official AUKEY website.

If you encounter any issues or have questions regarding your AUKEY PC-LM3 Webcam, please contact AUKEY customer support for assistance. Contact information can typically be found on the official AUKEY website or on the warranty card.